

Service Manual

General Description

Adjustment Procedures

Block / Schematic Diagrams

Exploded Views / Parts List


Video Cassette Recorder

Panasonic **VHS**
PAL/NTSC 4.43

Hi-Fi HQ

NV-HD650^A_{EA}

K-MECHANISM



SPECIFICATIONS

ITEM	SPECIFICATION		ITEM	SPECIFICATION
POWER	SOURCE: 240 V AC 50/60 Hz (NV-HD650A) 230 V AC 50/60 Hz (NV-HD650EA)		AUDIO	HEAD: 1 Stationary head (Normal Audio) 2 channels (Hi-Fi Sound-Stereo)
	CONSUMPTION: 23 watts			INPUT: AUDIO IN (AV1, 2) Connector (Phono type) More than -10dBV (316mV), more than 47k Ω MICROPHONE JACK -70dBV
RECORDING SYSTEM	2 rotary heads, helical scanning system			OUTPUT: AUDIO OUT Connector (Phono type) -8dBV (400mV), less than 1k Ω
	PAL/NTSC 4.43			
TV TUNER SYSTEM	NV-HD650A	VHF I: CH0~CH5 (PAL B) VHF III: CH5A~CH12 (PAL B) UHF: CH21~CH69 (PAL G) 75 Ω terminated	TAPE FORMAT	VHS Cassette tape (Tape width 12.7 mm)
	NV-HD650EA	VHF I: CH1~CH3 (PAL B) VHF III: CH4~CH11 (PAL B) UHF: CH21~CH69 (PAL G) 75 Ω terminated	TAPE SPEED	SP: 23.39 mm/s LP: 11.695 mm/s Record/Playback Time: SP: 4 hours with 240 min. type tape LP: 8 hours with 240 min. type tape FF/REW Time: 2.5 min. with 180 min. type tape
RF OUT SYSTEM	NV-HD650A	UHF: CH37 $\pm$ 6 (PAL B) 73 $\pm$ 3 dB μ , 75 Ω terminated		OPERATING TEMPERATURE
	NV-HD650EA	VHF: CH2/3 (PAL B) 73 $\pm$ 3 dB μ , 75 Ω terminated	OPERATING HUMIDITY	35% - 80%
VIDEO	HEADS: 4 rotary heads 1 pair for SP recording, playback and trick play (L-R heads) 1 pair for LP recording, playback and trick play (L' - R' heads)		DIMENSIONS	430(W) $\times$ 91(H) $\times$ 312(D) mm
			WEIGHT	4.6 kg
	INPUT: VIDEO IN (AV1, 2) Connector (Phono type) 1.0Vp-p, 75 Ω unbalanced		STANDARD ACCESSORIES	1 pc. DIN-RF Cable 1 pc. Infra-red Remote Controller 1 pc. AC Mains Lead 1 pc. Audio Cables
	OUTPUT: VIDEO OUT Connector (Phono type) 1.0Vp-p, 75 Ω unbalanced			

Weight and dimensions shown are approximate.
Specifications are subject to change without notice.

Panasonic

© 1995 Matsushita Electric Industrial Co., Ltd.
All rights reserved. Unauthorized copying and
distribution is a violation of law.

△ WARNING

This service information is designed for experienced repair technicians only and is not designed for use by the general public. It does not contain warnings or cautions to advise non-technical individuals of potential dangers in attempting to service a product. Products powered by electricity should be serviced or repaired only by experienced professional technicians. Any attempt to service or repair the product or products dealt with in this service information by anyone else could result in serious injury or death.

INTRODUCTION

This service manual contains technical information which will allow service personnels to understand and service this model.

Section 1 presents you with technical know how for actual servicing and general information of features and controls, enabling you to become familiar with each function.

Section 2 presents to your mechanical and electrical adjustment information as well disassembly and replacement procedures.

In the case of very common information relating to other models like mechanical adjustments, please refer to the appropriate service manual.

Section 3, 4 contains block diagrams which provides you with information for checking and understanding each circuit. Schematic diagrams which give you detailed information such as waveforms, voltage data, function e.t.c. ...

Section 5 contains exploded views and parts list.

Please place orders using the parts list and not the drawing reference numbers.

If the circuit is changed or modified, this information will be followed by supplementary service manual to be filed with original service manual.

CONTENTS


SECTION 1 GENERAL DESCRIPTIONS	1-1
1-1. SERVICE INFORMATION	1-1
1-2. SELF-TEST INDICATION DISPLAY	1-6
1-3. SERVICE INFORMATION DISPLAY	1-7
1-4. OPERATING INSTRUCTIONS	1-18
SECTION 2 ADJUSTMENT PROCEDURES	2-1
2-1. DISASSEMBLY METHOD	2-1
2-2. MECHANICAL ADJUSTMENT PROCEDURES	2-3
2-3. DISASSEMBLY PROCEDURES OF MECHANISM	2-3
2-4. ASSEMBLY PROCEDURES OF MECHANISM	2-3
2-5. ELECTRICAL ADJUSTMENT PROCEDURES	2-6

SECTION 3 ABBREVIATIONS & BLOCK DIAGRAMS.....	3-1
3-1. ABBREVIATIONS.....	3-1
3-2. SYSTEM CONTROL & SERVO BLOCK DIAGRAM.....	3-5
3-3. LUMINANCE & CHROMINANCE BLOCK DIAGRAM	3-10
3-4. HI-FI AUDIO BLOCK DIAGRAM.....	3-15
 SECTION 4 SCHEMATIC DIAGRAMS.....	 4-1
4-1. POWER SUPPLY SECTION IN MAIN SCHEMATIC DIAGRAM.....	4-1
4-2. RF SECTION IN MAIN SCHEMATIC DIAGRAM	4-4
4-3. SYSTEM CONTROL & SERVO SECTION IN MAIN SCHEMATIC DIAGRAM.....	4-8
4-4. LUMINANCE/CHROMINANCE & AUDIO SECTION IN MAIN SCHEMATIC DIAGRAM	4-12
4-5. MAIN C.B.A.	4-16
4-6. MOTOR DRIVE & SUB AUDIO PACK SCHEMATIC DIAGRAM.....	4-19
4-7. MOTOR DRIVE & SUB AUDIO PACK C.B.A.	4-23
4-8. LUMINANCE & CHROMINANCE PACK SCHEMATIC DIAGRAM.....	4-26
4-9. LUMINANCE & CHROMINANCE PACK C.B.A.....	4-30
4-10. HI-FI AUDIO PACK SCHEMATIC DIAGRAM	4-33
4-11. HI-FI AUDIO PACK C.B.A.....	4-36
4-12. INPUT/OUTPUT PACK SCHEMATIC DIAGRAM	4-39
4-13. INPUT/OUTPUT PACK C.B.A.	4-42
4-14. HEAD AMP SCHEMATIC DIAGRAM	4-44
4-15. HEAD AMP C.B.A.	4-46
4-16. TV DEMODULATOR PACK SCHEMATIC DIAGRAM.....	4-48
4-17. TV DEMODULATOR PACK C.B.A.	4-50
4-18. TIMER C.B.A. & OPERATION C.B.A.....	4-51
4-19. TIMER & OPERATION SCHEMATIC DIAGRAM.....	4-56
4-20. NICAM DECODER PACK SCHEMATIC DIAGRAM (NV-HD650EA)	4-60
4-21. NICAM DECODER PACK C.B.A. (NV-HD650EA)	4-64
4-22. DECODER PACK SCHEMATIC (NV-HD650A).....	4-67
4-23. DECODER PACK C.B.A. (NV-HD650A).....	4-69
 SECTION 5 EXPLODED VIEWS & PARTS LIST.....	 5-1
5-1. EXPLODED VIEW & MECHANICAL REPLACEMENT PARTS LIST.....	5-1
1. CHASSIS PARTS SECTION (1)	5-1
2. CHASSIS PARTS SECTION (2)	5-3
3. CASING PARTS SECTION	5-4
4. PACKING PARTS SECTION.....	5-6
5. REMOTE CONTROLLER UNIT	5-7
5-2. ELECTRICAL REPLACEMENT PARTS LIST.....	5-8

1-4. OPERATING INSTRUCTIONS

Controls and Connection Sockets

This gives a detailed explanation of the function of each button, switch and connection socket.




- 1 POWER** Press to switch the unit from on to standby mode or vice versa. In standby mode, the unit is still connected to the mains.
- 2 EJECT** To eject a video cassette.
- 3 Cassette Compartment** Insert a video cassette here.
- 4** To select the required programme position (TV station).
- 5 REC** To start a recording.
- 6 PAUSE/STILL** In the stop mode: Still picture (Jog/Shuttle mode). During playback: Still picture (Jog/Shuttle mode). During recording: To interrupt recording.
- 7 STOP** To stop any playback or recording.
- 8 Shuttle Ring** In the stop mode: To rewind or fast forward the tape. In the playback mode: To search picture backward or forward. In the still playback mode: To adjust playback speed backward or forward. In the rewind or fast forward mode: To obtain high speed picture.
- 9 Jog Dial** To locate any desired frame with utmost precision.
- 10 PLAY** To start playback. ">" is lit. For the repeat playback function.
- 11 SYNC. EDIT** To connect a movie camera or another VTR equipped with synchronized editing capability.
- 12 VIDEO IN (AV2)** To connect the video cable to a movie camera or to another VTR.
- 13 AUDIO IN (AV2)** To connect the audio cable to a movie camera or to another VTR.
- 14 MIC** To connect a microphone for recording. Once connected, this socket has priority.
- 15 Infra-red Remote Control Receiver Window**
- 16 Display**
- 17 CVC Indicator** When the CVC function is on, this indicator is lit.
- 18 CVC (Crystal View Control)** ON: Using the CVC function, playback and recording are performed in the state which achieves optimum picture quality in light of characteristics of a tape.
 - The CVC indicator is lit.
 - This control should normally be left in the ON position.
 - Turn off the CVC function.
 - The CVC indicator is not lit.
 - With certain tapes, the OFF position may result in a better picture.
 OFF:
- 19 TIMER REC** To turn the timer recording function on and off. [] is lit or not lit. Once operating timer recording function, the normal VTR operation is not possible unless this button is set to off.
- 20 AUDIO DUB** To set up the VTR for audio dubbing. A.DUB is appeared on screen display.
- 21 INSERT** To set up the VTR for insert editing. INSERT is appeared on screen display.
- 22 NTSC SELECT** Set according to the colour TV system. For TV's that can only receive PAL signals. When receiving PAL signals. For TV's that can receive NTSC 4.43 signals. When receiving NTSC 4.43 signals.
- 23 COUNTER RESET** To reset the tape counter (elapsed time) to "0:00.00".
 - The tape counter is automatically reset to "0:00.00" when a video cassette is inserted.
- 24 RF IN** To connect to the external aerial.
- 25 VIDEO IN (AV1)** To connect a video cable from a Movie Camera or another video recorder.
- 26 VIDEO OUT** To connect a video cable to a TV or another video recorder.
- 27 TEST SIGNAL (NV-HD650A only)** The test signal is transmitted on channel AU37.
- 28 AC IN~** To connect to the main power supply.
- 29 CH ADJ. (NV-HD650A only)** To adjust the RF transmitting channel AU31-43.
- 30 RF OUT** To connect to the aerial terminal on a TV set.
- 31 AUDIO IN (AV1)** To connect an audio cable from a Movie Camera or another video recorder.
- 32 AUDIO OUT** To connect an audio cable to a TV or another video recorder.
- 33 EDIT** By connecting the optional Editing Controller (VW-EC300E/VW-EC310E) to this socket, such editing functions as Assemble Editing, Insert Editing and Audio Dubbing can be performed more quickly and efficiently between two VTRs or between a VTR and a movie camera.
- 34 Video Playback Channel Selector (NV-HD650EA only)** To select the video playback channel.


Controls and Connection Sockets

- 18 CVC (Crystal View Control)** ON: Using the CVC function, playback and recording are performed in the state which achieves optimum picture quality in light of characteristics of a tape.
 - The CVC indicator is lit.
 - This control should normally be left in the ON position.
 - Turn off the CVC function.
 - The CVC indicator is not lit.
 - With certain tapes, the OFF position may result in a better picture.
 OFF:
- 19 TIMER REC** To turn the timer recording function on and off. [] is lit or not lit. Once operating timer recording function, the normal VTR operation is not possible unless this button is set to off.
- 20 AUDIO DUB** To set up the VTR for audio dubbing. A.DUB is appeared on screen display.
- 21 INSERT** To set up the VTR for insert editing. INSERT is appeared on screen display.
- 22 NTSC SELECT** Set according to the colour TV system. For TV's that can only receive PAL signals. When receiving PAL signals. For TV's that can receive NTSC 4.43 signals. When receiving NTSC 4.43 signals.
- 23 COUNTER RESET** To reset the tape counter (elapsed time) to "0:00.00".
 - The tape counter is automatically reset to "0:00.00" when a video cassette is inserted.
- 24 RF IN** To connect to the external aerial.
- 25 VIDEO IN (AV1)** To connect a video cable from a Movie Camera or another video recorder.
- 26 VIDEO OUT** To connect a video cable to a TV or another video recorder.
- 27 TEST SIGNAL (NV-HD650A only)** The test signal is transmitted on channel AU37.
- 28 AC IN~** To connect to the main power supply.
- 29 CH ADJ. (NV-HD650A only)** To adjust the RF transmitting channel AU31-43.
- 30 RF OUT** To connect to the aerial terminal on a TV set.
- 31 AUDIO IN (AV1)** To connect an audio cable from a Movie Camera or another video recorder.
- 32 AUDIO OUT** To connect an audio cable to a TV or another video recorder.
- 33 EDIT** By connecting the optional Editing Controller (VW-EC300E/VW-EC310E) to this socket, such editing functions as Assemble Editing, Insert Editing and Audio Dubbing can be performed more quickly and efficiently between two VTRs or between a VTR and a movie camera.
- 34 Video Playback Channel Selector (NV-HD650EA only)** To select the video playback channel.

Infra-red Remote Controller



- 1 POWER (TV)**
To switch the TV from on to standby mode or vice versa. In standby mode, the TV is still connected to the mains.
• With some TV models, it may only be possible to switch the TV to standby mode using this button. In this case, use TV/AV or $\nabla/\wedge$ (TV) to switch the TV on.
- 2 TV/AV**
To select the TV input.
- 3 POWER (VTR)**
To switch the VTR from on to standby mode or vice versa. In standby mode, the VTR is still connected to the mains.
- 4 OSD**
For the On Screen Display Function.
- 5 REW (REWIND)**
In the stop mode: To rewind the tape
In the playback mode: To search backward
In the rewind mode: To obtain high speed picture
"◀◀" is lit.
- 6 PLAY**
To start playback. "▶" is lit.
For the repeat playback function.
- 7 PAUSE/STILL**
During playback: Still picture.
During recording: To interrupt recording.



- 8 REC**
To start a recording.
• Press both buttons simultaneously.
- 9 $\nabla/\wedge$ (VTR)**
To select the required programme position (TV station) of the VTR.
- 10 TRACKING-LOCK**
For manual tracking adjustment
When the + and - buttons are used to adjust the tracking when, for example, noise bars on the picture are better removed manually than by the automatic digital tracking control. After making a manual adjustment, press both buttons together to return to automatic digital tracking control.
- For slow tracking adjustment**
When noise bars appear during Still or Slow playback, switch over to slow playback and adjust with the + or - Button to reduce the noise bars.
- For vertical locking adjustment**
Use the + and - buttons to minimize any vertical jitter during still-picture playback.
- 11 SLOW**
For the slow motion playback function. "◀▶" is lit.
- 12 FF (FAST FORWARD)**
In the stop mode: To fast forward the tape
In the playback mode: To search forward
In the fast forward mode: To obtain high speed picture
"▶▶" is lit.

- 13 STOP**
To stop any playback or recording.
- 14 INDEX**
For the index search function.
- 15 $\nabla/\wedge$ (TV)**
To select the required programme position (TV station) of the TV.
- 16 VOLUME**
To adjust the volume of the TV.
- 17 Infra-red Transmitter**
- 18 $\nabla/\wedge$**
To programme a timer recording.
- 19 DATE**
To programme a timer recording.
- 20 DISPLAY**
To change the indication on the VTR Display.
Clock→Counter→Remaining Tape Time
- 21 RESET**
To reset the tape counter (elapsed time) to "0:00.00".
• The tape counter is automatically reset to "0:00.00" when a video cassette is inserted.
- 22 PROG**
To set and check timer programmes.
- 23 ZERO STOP**
For the zero stop function.
- 24 CANCEL**
To cancel the settings made for a timer recording.
- 25 INPUT SELECT**
To select the A1 or A2 external recording source.
- 26 VTR/TV**
To select the VTR mode or TV mode.
(NV-HD650A: No function.)
- 27 SPEED**
To select the tape speed desired for recording.
SP gives the best picture quality.
LP gives the longest recording time.
- 28 TV SELECT**
To set the remote controller for operation of the TV.
- 29 MENU**
To make OSD menu appear on the TV screen.
- 30 ENTER**
To confirm the selection, or to store.
- 31 $\blacktriangle/\blacktriangledown$**
To make selections from On Screen Display.
- 32 Programme Position Selector Buttons**
• To select the programme positions (1-99).
9: 9
19: 19
• To programme a G-Code number.
For the G-Code programming.
- 33 G-Code**
For the G-Code programming.

Infra-red Remote Controller


- 34 TIMER REC**
To turn the timer recording function on and off.
[] is lit or not lit.
Once operating timer recording function, the normal VTR operation is not possible unless this button is set to off.
- 35 AUDIO OUT**
To select the desired sound mode.
At the every push of this button, the audio output mode changes as follows.
[] Stereo→Left→Right→Normal audio track
The Left (L) and Right (R) Indicators show which sound mode is selected in the following way.
Stereo: Both the Left (L) and Right (R) Indicators appear.
Left: The Left (L) Indicator appears.
Right: The Right (R) Indicator appears.
Normal: Both the Left (L) and Right (R) Indicators don't appear.
- 36 OFF**
To programme a timer recording.
- 37 ON**
To programme a timer recording.

Power Source for the Remote Controller
The remote controller is powered by 2 "AA", "UM3" or "R6" size batteries. The life of the batteries is about one year, although this depends on the frequency of use.

Precautions for Battery Replacement

- Load the new batteries with their polarity (+ and -) aligned correctly.
- Do not apply heat to the batteries, or an internal short-circuit may occur.
- If you do not intend to use the remote controller for a long period of time, remove the batteries and store them in a cool and dry place.
- Remove spent batteries immediately and dispose of them.
- Do not use an old and a new battery together, and never use an alkaline battery with a manganese battery.

Installing the Batteries




Connections


This tells you how to connect with an aerial, TV, etc.

Basic Connections

The following connections are required to record and play back the VTR through TV set:



Connection to a TV Set with the Audio/Video Input Sockets




Note:
To obtain stereo performance when playing stereo, Hi-Fi tapes it is necessary to make connections as shown above.

Tuning the TV to your VTR

Connections
Tuning the TV to your VTR

NV-HD650A



Operations

1 Turn on the TV and VTR.

2 To generate a test pattern, set **TEST SIGNAL** to ON.

3 Set the TV to an unused position which you wish to use for your video playback.


4 Set **TEST SIGNAL** to OFF.

Note:
The test signal is transmitted on video channel AU37. If you are encountering interference from a TV broadcast on this video channel, you may readjust to another free channel (AU31-43) by using the CH ADJ. screw which is located on the rear of the VTR.
Please note that if the CH ADJ. screw is used then you will have to retune your TV to the test signal as in item 2 to 4 above.

Setting the Remote Controller for Operation of your TV

Tuning the TV to your VTR
Setting the Remote Controller
for Operation of your TV

NV-HD650EA




Select the channel or AV.

It is possible to view the video picture on your TV in the same way that you watch TV broadcasts.
If you have connected the VTR to the TV through the video and audio input sockets then you do not need to follow the procedure mentioned below. Instead, simply select AV mode on the television.

Operations Display Symbol

- 1 Turn on the TV and VTR.
- 2 Select the VTR mode.
- 3 Select the video playback channel which is not occupied with any TV station.
H: Channel 3
L: Channel 2
- 4 Insert a pre-recorded cassette tape and press **PLAY**.
- 5 Select a programme number on the TV set which you wish to use as the video viewing channel. Then tune in the TV to the picture from the cassette tape currently playing.
- 6 Stop the playback.

You can operate some manufacturer of TVs (see following table) using the supplied Remote Controller after this setting up.



Preparation
Install the batteries in the remote controller. See page 7.

Operations

- 1 Turn on the TV.
- 2 Press corresponding operation button to your TV manufacturer (see following table) while keeping **TV SELECT** pressed.
• If setting is correct, TV will be turned off automatically.

TV Manufacturer	Operation Button
Panasonic/National	TV SELECT + DISPLAY
	TV SELECT + PROG
	TV SELECT + CANCEL
	TV SELECT + TIMER REC
SONY	TV SELECT + 1
TOSHIBA	TV SELECT + 2
JVC	TV SELECT + 3
HITACHI	TV SELECT + 4
MITSUBISHI	TV SELECT + 5
SHARP	TV SELECT + 6
PHILIPS	TV SELECT + 8
NEC	TV SELECT + 0
SANYO	TV SELECT + -/++


When the TV manufacturer is Panasonic/National or MITSUBISHI:
When the TV's power is turned off in step 2 above, turn it back on and adjust the TV's volume using this remote controller. The volume can be adjusted if the operation button matches the manufacturer of TV.
If it is not possible to adjust the TV's volume, try pressing the other operation button to match the manufacturer of TV again until the volume can be adjusted.

Note:
Some TV models cannot be operated using this remote controller.

Language Setting of On Screen Display

Preparations

- Confirm that the TV is on and the VTR viewing channel is selected.
- Turn on the VTR.
- Press VTR/TV to select the VTR mode. (NV-HD650EA only)




To select the Desired Language

Select one of the two languages displayed: English and Russian.

1 Press MENU.



On Screen Display



2 Select LANGUAGE.



3 Select the desired language.



4 Press MENU twice.



Setting the Clock of the VTR

The built-in clock is used to activate the timer for automatic recording and must be set to the correct time.
The built-in digital clock employs the 24-hour system.

Preparation

- Confirm that the TV is on and the VTR viewing channel is selected.
- Press VTR/TV to select the VTR mode. (NV-HD650EA only)

Operations On Screen Display

1



Press MENU.

2



Select CLOCK SET.

3



Set each item by pressing ▲ or ▼ and ►.



Set Year "1999".



Set Month "10".



Set Date "16".



Set Time "20:15".

- When it is kept pressed, the indication changes in 30-minute steps.
- There is no need to press ►.

4



Press MENU.

- The clock will start.



Time Reset Function

If the clock is less than two minutes slow or fast, it can easily be reset to the proper time.

For example:

Resetting the clock to 12:00.00.

- 1 Select CLOCK SET from OSD menu and press ENTER.
- 2 When the current clock display on the VTR is between 11:58 to 12:01, press MENU as soon as you hear the 12:00.00 time signal. This resets the time to 12:00.00.

Note:
The clock operates for at least 60 minutes by its backup system in the event of power failure.

Storing TV Broadcasts into your VTR


Introduction

The VTR is fitted with its own tuner (just like a normal TV set) and can be pre-set to receive up to 99 TV broadcast stations.

Preparations


- Confirm that the TV is on and the VTR viewing channel is selected.
- Turn on the VTR and select the programme position except A1 or A2.
- Press VTR/TV to select the VTR mode.
- (NV-HD650EA only)

Auto Tuning Procedure




Operations On Screen Display


1 Press MENU.



2 Select TUNER PRESET.




3 Select AUTO TUNE and press $\blacktriangle$ or $\blacktriangledown$.
• When the Auto Tuning finished, On Screen Display disappears and programme position 1 is selected.



Manual Tuning Procedure

- 1 Press MENU.
- 2 Select TUNER PRESET by pressing $\blacktriangle$ or $\blacktriangledown$ and ENTER.
- 3 Select CH by pressing $\blacktriangle$ or $\blacktriangledown$ and then select the programme position by pressing $\blacktriangle$ or $\blacktriangledown$.
- 4 Confirm that CLEAR is set to OFF.
- 5 Select SEARCH by pressing $\blacktriangle$ or $\blacktriangledown$ and then press $\blacktriangleright$.



- If the desired TV station is not be tuned, press $\blacktriangleright$ again.
- Press MENU and repeat steps 3-5 for each programme position you want to tune to a station.
- 6 Press MENU three times.

Channel Plan

	VHF	UHF
NV-HD650A	0-12	21-69
NV-HD650EA	1-11	21-69

NV-HD650A:


Broadcast TV Channel	Positioned on VTR
2 ABC	2
7 ATN	7
9 TCN	9
10 TEN	10
28 SBS	28

This table will be required when programming the G-Code.

Storing TV Broadcasts into your VTR

Fine Tuning Procedure

- 1 Press MENU.
- 2 Select TUNER PRESET by pressing $\blacktriangle$ or $\blacktriangledown$ and ENTER.
- 3 Select CH by pressing $\blacktriangle$ or $\blacktriangledown$ and then select the programme position by pressing $\blacktriangle$ or $\blacktriangledown$.
- 4 Select FINE by pressing $\blacktriangle$ or $\blacktriangledown$.
- 5 Press $\blacktriangle$ or $\blacktriangledown$ to obtain the best tuning condition.



- To return the tuning to its former state, press ENTER.
- 6 Press MENU.

Blanking of Unoccupied Programme positions

- 1 Press MENU.
 - 2 Select TUNER PRESET by pressing $\blacktriangle$ or $\blacktriangledown$ and ENTER.
 - 3 Select CH by pressing $\blacktriangle$ or $\blacktriangledown$ and then select the programme position by pressing $\blacktriangle$ or $\blacktriangledown$.
 - 4 Select CLEAR by pressing $\blacktriangle$ or $\blacktriangledown$.
 - 5 Select ON by pressing $\blacktriangle$ or $\blacktriangledown$.
- Repeat steps 3-5 for another unoccupied programme positions to skip during the selection of the programme positions.
 - To cancel the blanking of a programme position, select that programme position and then select CLEAR OFF.
 - 6 Press MENU twice.

Notes:

- The Auto Tuning is searching for TV station from VHF minimum to UHF maximum and memorizing the data for every programme position. The other programme positions are skipped.
- The Auto Tuning takes seven or more minutes to complete the search.
- If VTR is not correctly tuned by Auto Tuning, follow the procedure on next page.


Preparations for G-Code Programming

Identification numbers must be set for G-Code programming. Simply proceed with the G-Code programming operation described on page 26, and the identification numbers of the TV stations concerned will be set automatically. This means that G-Code programming is possible even without performing the operation described on this page. However, you can follow the setting procedure described below if you wish to set the identification numbers of all the TV stations prior to actual programming.

"Identification numbers" refer to the numbers used for identifying the TV stations. The programme positions on the VTR receiving the TV stations are set in these identification numbers. Have a newspaper or magazine on hand which lists today's local TV station programmes and G-Code numbers.

Preparations

- Set the clock of the VTR. See page 13.
- Store TV broadcasts into your VTR. See pages 14 and 15.
- Confirm that the TV is on and the VTR viewing channel is selected.
- Turn on the VTR.
- Press VTR/TV to select the VTR mode. (NV-HD650EA only)




Operations On Screen Display

1 Press MENU.



2 Select G-CODE CH SET.



3 Select the identification number (Guide Channel) (001-255).



4 Press ◀ or ▶ and then select the programme position (1-99, A1, A2).



- To set the other TV stations, press ◀ or ▶ and then repeat steps 3 and 4.

5 Press MENU twice.



Note:


To receive satellite stations, the satellite receiver must be connected to the VTR and programme position must be set depending on the type of the connection mode.
A1/A2: When the satellite receiver is connected to the Audio/Video input sockets (AV1/AV2).
• When the satellite receiver is connected by means of the RF coaxial cable, set to a free programme position between 1 and 99.

For Example:
(NV-HD650A)

TV Station	Programme Position on VTR	Guide Channel
ABC	2	002
ATN	7	007
TCN	9	009
TEN	10	010
SBS	28	028/001

For Example:
(NV-HD650EA)

TV Station	Programme Position on VTR	Guide Channel
TV ONE	1	001
CHANNEL 2	2	002
TV3	3	003
SKY TV MOVIES	4	004
SKY TV SPORTS	5	005
SKY TV NEWS	6	006
SKY ORANGE	7	007
SKY DISCOVERY & TRACKSIDE	8	008
CTV	11	011




Operations Display Symbols


- 1 Insert a recorded cassette tape.



- 2 Start viewing the picture.



- 3 Search forward by tapping **FF**.
• To change back to normal playback, press **PLAY**.



- 4 Search backward by tapping **REW**.
• To change back to normal playback, press **PLAY**.




- 5 View a still picture.
• To continue the normal playback, press **PLAY** or **PAUSE/STILL**.



- 6 View the slow motion picture.
• To continue the normal playback, press **PLAY**.




- 7 Stop viewing the picture.



Other Playback Functions


To change the Playback Speed

- 1 Press **PAUSE/STILL** on the VTR.
- 2 Rotate Shuttle Ring.



To locate the Desired Picture Exactly

- 1 Press **PAUSE/STILL** on the VTR.
- 2 Turn Jog Dial.




To obtain High Speed Picture During Fast Forward or Rewind

Keep **FF** pressed during fast forward.
Keep **REW** pressed during rewind.



To playback the Recorded Part Repeatedly

Keep **PLAY** pressed for more than 5 seconds.




- Press **STOP** to release from Repeat Playback mode.

To return to a Specified Scene

- 1 Press **RESET** to set the counter to 0:00.00.
- 2 After playback, press **ZERO STOP** in the stop mode.
• The tape will be rewound or fast forwarded to 0:00.00 approximately.



- Notes:**
- Audio reproduction of linear (conventionally recorded) tapes will be monaural when played back on the FM Hi-Fi video recorders.
 - Cue, review or slow playback will be automatically released after 10 minutes, and still playback after 5 minutes.
 - In LP mode only:
1. During any playback mode other than normal playback, the picture may have some noise bars, the colour may be unstable, or a black and white picture may appear.
2. When playing back a tape which was recorded on another VTR, it may be necessary to adjust the Tracking Control. In some cases the picture quality may still be inferior. This is due to limitation of format.



Operations Display Symbols



-  Insert a cassette tape.
• If it has already been inserted, press **POWER** to turn the VTR on.

-  Select the VTR mode.
(NV-HD650EA only)

-  Select TV station.


-  Start recording.

-  Stop recording.



To select the Desired Tape Speed

Press **SPEED** before recording.



To interrupt Recording

Press **PAUSE/STILL** during recording.
Press again to continue recording.




To record One TV Programme while Viewing Another Programme

- Refer to the manual recording operations steps 1 to 4.
- Press **VTR/TV** to select the TV mode.
(NV-HD650EA only)
- Select the TV programme on your TV set you wish to view at the present time.

To display the Approximate Remaining Tape Time

- Select **TAPE SELECT** on screen display and select the corresponding cassette tape length. See page 18.

On Screen Display



E180: For E30, -60, -90, -120, -150 and -180 tapes

E195: For E195 tape

E240: For E240 tape

E260: For E260 and -300 tapes

- Press **DISPLAY**.



⏰ Clock → Counter → Remaining Tape Time

- The remaining tape time may not be displayed correctly depending on the tape used.

Notes:

- When a video cassette with a broken off tab is inserted, the "RE" indication will flash to indicate that recording is not possible.
- The recording pause mode will be automatically released after 5 minutes. Revert back to the stop mode.

The NICAM Broadcast System

(NV-HD650EA only)

NV-HD650EA is equipped with the NICAM sound system. NICAM is a 2 channel sound broadcast system to provide either a high quality stereo sound track or 2 independent MONO sound tracks, M1 and M2. NICAM programmes are always accompanied by standard sound broadcasts and you can select the desired sound with **AUDIO OUT** during playback.

- The NICAM digital stereo sound can only be recorded on the Hi-Fi audio track.
- When NICAM programme is being received, the indicators are lit to inform you of the type of broadcast.

(See page 30).

- To record the regular sound (ordinary normal sound) on the FM audio tracks when a NICAM programme is received, select **MONAURAL ON**. (See page 19.)

- To hear stereo performance connect as shown on page 8 to a TV or Stereo Amplifier with left and right audio inputs.

Important Note for the NICAM System

When NV-HD650EA is switched on, the tuner will automatically switch to a NICAM broadcast, if NICAM is being transmitted.

At this time the NICAM signal is transmitted on stereo channels only, since the M1 and M2 formats are not yet available. Even if the sound track is in MONO, the stereo indicator will appear.

Timer Recording

Up to 8 timer programmes can be recorded up to one month in advance by setting the timer, including weekly and daily programmes.


Preparations

- Insert a cassette tape with an intact erasure prevention tab.
- Confirm that the TV is on and the VTR viewing channel is selected.

- Turn on the VTR.
- Press VTR/TV to select the VTR mode. (NV-HD650EA only)

For Example:

Timer programme number: 1
 Programme position (channel): 2
 Date: 27th, October
 Starting time: 20:02
 Ending time: 21:30
 (Present date: 16th, October)



Operations On Screen Display

1 Select Timer Programme number "1".



2 Set Programme position (channel) "2".



3 Set Date "27".



4 Set Starting time "20:02".



- When it is kept pressed, the indication changes in 30-minute steps.

5 Set Ending time "21:30".




6 To activate timer recording, press TIMER REC.



Weekly Timer Recording

In step 3, select the desired day by pressing DATE —. For example, SU (Sunday)



(SU=Sunday, MO=Monday, TU=Tuesday, WE=Wednesday, TH=Thursday, FR=Friday, SA=Saturday)

Daily Timer Recording

For this timer function, several groups of days can be selected.


- Ⓐ Daily recording from Monday to Friday
- Ⓑ Daily recording from Monday to Saturday
- Ⓒ Daily recording from Sunday to Saturday

In step 3, select the desired days by pressing DATE —. For example, Ⓒ



Timer Recording from External Signal Source

If Timer Recording is performed by a unit connected to the Audio/Video input sockets (AV1/AV2), select the A1 or A2 indicator in step 2 for the programme position.



Selecting the Desired Tape Speed

Press ◀ and then select the desired tape speed by pressing ▲ or ▼ in any of steps 2-5.



Setting other Programmes in succession


Repeat steps 1-5.

Timer Recording

Checking a Timer Programme

- The VTR must be turned on, or the timer recording indicator "TV" is lit.
- Confirm that the TV is on and the VTR viewing channel is selected.

1 Press PROG.




2 Press VTR/TV to select the VTR mode. (NV-HD650EA only)




Cancelling a Timer Programme

- The VTR must be turned on, or the timer recording indicator "TV" is lit.
- Confirm that the TV is on and the VTR viewing channel is selected.


1 Press PROG.



2 Press VTR/TV to select the VTR mode. (NV-HD650EA only)



3 Press PROG repeatedly until the desired timer programme number is flashed on and off.



4 Press CANCEL.



Note:

If a timer recording is not performed to the end (due to insufficient tape or cancellation by the user), the programmed timer recording data will be cancelled from the memory by 4 a.m. one day later. However, if the Timer Record Function is activated at that time, the programmed timer recording data will be cancelled at 4 a.m. the next day.


Editing

G-Code Programming

Programming is now easier than ever: simply enter the G-Code number provided in the programme schedule column carried by newspapers and magazines. G-Code numbers are numbers which are assigned to each programme listed in the TV programme schedule carried in newspapers and TV guides. When these numbers are entered, the numbers are converted into the actual programming.

Preparations

- Insert a cassette tape with an intact erasure prevention tab.
- Confirm that the TV is on and the VTR viewing channel is selected.
- Turn on the VTR.
- Press **VTR/TV** to select the VTR mode. (NV-HD650EA only)



Operations


On Screen Display

1 Press G-CODE.



2 Enter a G-Code number.

Example: 123456




- If you have entered the wrong number, press **CANCEL** and then enter the proper number.

3 Press ENTER.



- Confirm that the number corresponds to the right programme. If the display looks like this:



select the programme position of your VTR which receives the TV station you entered at step 2 using button **2** and then press **ENTER**.

- To make any corrections, use buttons **2-5** as the same way on page 24.

4 Press TIMER REC.



Notes:

- To select the desired tape speed, press **SPEED** before programming.
- When the G-Code number is used for programming, the recording time may be slightly longer than the actual programme time.
- Repeat steps 2 and 3 if "PROGRAMME IS INCOMPLETE." appears.
- When programming two or more programmes, repeat steps 1-3 before pressing **TIMER REC**.
- The procedures for checking and cancelling a timer programme are the same as on page 25.

Assembly Editing

This function can be used to make up an edited tape from other recordings or video sources.

A new scene can be added to the end of a previous one.

Preparations

- Connect a movie camera or another VTR to this VTR as shown.
- Insert a recorded cassette tape with an intact erasure prevention tab.
- Select the video source required by pressing **INPUT SELECT** to set A1 or A2.
- A1: Through the AV1 (AUDIO IN/VIDEO IN) sockets.
- A2: Through the AV2 (AUDIO IN/VIDEO IN) sockets on front panel.
- Set **NTSC SELECT**.
- When recording in the PAL system.
- NTSC P.B.: When recording NTSC 4.43 signals from External Signal Source.
- When dubbing an NTSC tape, keep the **NTSC SELECT** on both the recording and playback units at the 4.43 position.

Operations

1 Press PAUSE/STILL on the recording VTR.



2 Search for the end of the previous recording.



3 Press REC to switch the VTR from the pause mode to the recording standby mode.



4 Start the new recording by pressing PAUSE/STILL again.



5 Press STOP to stop recording.



Note:

The new sound will be recorded on both the normal and Hi-Fi sound tracks, only monaural sound recording is possible on the normal sound tracks.

Synchronized Editing

It is possible to synchronize the playback start and stop of the Movie Camera with the recording start and stop of this VTR.

Preparation

Connect a Movie Camera to this VTR with Synchro Connection Cord (VW-K1E).


- 1 Put the VTR in the recording pause mode by pressing **PAUSE/STILL (VTR)** and **REC**.
- 2 Put the Movie Camera in the still playback mode at the point where you want to start editing.
- 3 Press **PAUSE/STILL** on the VTR.

- The Movie Camera changes over to the playback mode and the dubbing will start automatically.

Synchronized Editing between the VTRs

When editing from another VTR equipped with Synchro Edit Socket, synchronized start and stop of both VTRs can be activated from this VTR.

The operation is the same as described for synchronized editing from a Movie Camera.




Insert Editing

This is used to substitute one scene for another, providing.

Preparations

- Insert a recorded cassette with an intact erasure prevention tab.
- Select the video source required by pressing **INPUT** SELECT to set A1 or A2.
- A1: Through the AV1 (AUDIO IN/VIDEO IN) sockets.
- A2: Through the AV2 (AUDIO IN/VIDEO IN) sockets on front panel.



Operations

Display Symbols

1		Press PAUSE/STILL on recording the VTR.
2		Search for the Edit out (ending) point, and set the counter to 0:00.00 by pressing COUNTER RESET .
3		Search for the Edit in (starting) point, and press INSERT . • If you want to replace the sound on the "normal" audio track, press AUDIO DUB , too. (AV Insert Editing)
4		Start insert editing by pressing PAUSE/STILL . • The insert editing will finish when the counter reaches 0:00.00.

Note:
Insert Editing cannot be used on blank sections of a tape. In this case use Assembly Editing first.


The new sound will be recorded on the Hi-Fi sound track. If **AUDIO DUB** selected, the new sound will also be recorded on the normal sound track.
Only monaural sound recording is possible on the normal sound tracks.

Audio Dubbing

The audio dubbing is made on the normal audio track and erases the original sound on this track. On Hi-Fi audio tracks, however, the original sound is maintained.

Preparations

- Insert a recorded cassette with an intact erasure prevention tab.
- Select the video source required by pressing **INPUT** SELECT to set A1 or A2.
- A1: Through the AV1 (AUDIO IN) sockets.
- A2: Through the AV2 (AUDIO IN) sockets on front panel.



Operations

Display Symbols

1		Search for the starting point for audio dubbing.
2		Press PAUSE/STILL at the starting point.
3		Set for audio dubbing by pressing AUDIO DUB . • On some televisions, the screen image may become unstable or begin to scroll at this point. However, this is not an indication of a malfunction.
4		Start recording the new sound by pressing PAUSE/STILL . • Stop recording by pressing STOP .



Note:
The new sound will be recorded on the normal sound track of the tape, and the original sound will remain on the Hi-Fi sound track. Only monaural sound recording is possible on the normal sound track.
To hear the new sound, select the normal sound track by pressing **AUDIO OUT**.
To hear the new sound and original sound mixed together, set **AUDIO MIX** to ON. (See page 19.)

Other Functions

On Screen Display

Press OSD to make the On Screen Display appear on the TV screen.

- To make this display disappear, press OSD again.



1 Audio Output Mode Indicators

The Left (L) and Right (R) Indicators show which sound mode is selected with **AUDIO OUT**.

Stereo: Both the Left (L) and Right (R) Indicators appear.

Left: The Left (L) Indicator appears.

Right: The Right (R) Indicator appears.

Normal: Both the Left (L) and Right (R) Indicators don't appear.

2 STEREO or BILINGUAL Indicator (NV-HD650A)

When receiving a TV programme, the type of sound system in which it is broadcast is automatically indicated.

STEREO, M1 and M2 Indicator (NV-HD650EA)

When receiving a TV programme with the NICAM sound system, the type of sound system in which it is broadcast is automatically indicated.

STEREO: When receiving a NICAM stereo broadcast.

M1 M2: When receiving a NICAM dual-sound broadcast.

M1: When receiving a NICAM monaural broadcast.

M2: When receiving a NICAM dual-sound broadcast.

VHS Index Search System

It is very easy to find the beginning of each recording, because a special index signal is recorded at the start of each recorded segment on the tape.

For example:

Searching for the 2nd recorded segment in the forward direction.

Press **INDEX** twice.



- After finding the specific recorded segment, playback starts automatically.

- For the reverse direction, press **INDEX** .

- Up to 20 index signals can be searched for in both directions.

- When the opposite **INDEX** button is pressed, the number shall be decreased till 1.

- The figure on the display is decremented by 1 each time an index signal is located.

- The **INDEX** search function can only work correctly, if the index signals are spaced at least 3 minutes apart in the SP mode and 5 minutes apart in the LP mode.

Recording Index Signals

Index signals are recorded in following cases.

- When a recording is started by pressing **REC**.

- When **REC** is pressed during recording.

- When timer recording is activated.

Note:

To hear stereo performance connect as shown on page 8 to a TV or Stereo Amplifier with left and right audio inputs.

3 Programme position

4 Tape running display

Stop, Eject	◀◀
Rewind, Review	▶▶
Fast Forward, Cue	▶▶▶▶
Playback	▶▶▶▶▶▶
Still Playback	
Recording	●
Recording Pause	●
Slow Playback	▶▶▶▶▶▶▶▶

5 Present time/Tape counter

Information	Display
Present time	17:24
Tape counter	-2:35:47
Remaining Tape Time	REMAIN 2:34
Dew	DEW
Index search	S 01

6 Tape speed indicator

7 Cassette-in indicator

8 Edit mode

When edit mode (Insert Editing, AV Insert Editing, Audio Dubbing) is set, the On Screen Display appears.


INSERT: Insert Editing

AV INSERT: AV Insert Editing

A.DUB: Audio Dubbing

Note:

On Screen Display may be disturbed or disappear during special playback.



NTSC Playback

Tapes recorded in the NTSC system can be played back with this VTR via a PAL system TV set.

- Set **NTSC SELECT** according to the colour TV system of the TV set.
- NTSC P.B.: For TV's that can only receive PAL signals. 4.43: For TV's that can receive NTSC 4.43 signals.

A note about NTSC playback on PAL TV

On some TVs, the playback picture may roll up or down: adjust this using the V-HOLD control on the TV. TVs not equipped with a V-HOLD control cannot correct this condition. The playback picture will shrink vertically, and black bars will appear both on the top and bottom of the screen. This is not an indication of a malfunction.

- During Cue, Review, Still or Slow playback, the picture may not be in colour.
- This function is designed only to allow the playback of tapes recorded by NTSC signals on a PAL system TV. The NTSC signal is not completely converted to a PAL signal. For this reason, images played back by this function cannot be recorded on another VTR.

Other Automatic Functions

Automatic playback

When a cassette without an erasure prevention tab is inserted, the VTR starts playback automatically.

VTR-off playback

When the VTR is off, an inserted cassette can be played back by pressing **PLAY**.

Automatic rewinding

When the tape reaches its end during recording (except for timer recording) or playback, it will automatically be rewound to the beginning.

Automatic switching off and ejection

When the VTR is switched off, an inserted cassette can be ejected simply by pressing **EJECT**. The VTR will eject the cassette and automatically turn itself off again.

S-VHS Quasi Playback (SQPB)

It is also possible to playback tapes recorded in the S-VHS system.

- Some picture noise may occur depending on the type of tape used.
- It is not possible to fully obtain the high resolution that S-VHS is capable of.
- It is not possible to record in the S-VHS system with this VTR.

SECTION 2 ADJUSTMENT PROCEDURES

2-1. DISASSEMBLY METHOD

2-1-1. DISASSEMBLY FLOW CHART

This flow chart indicates disassembly steps of the cabinet parts and the circuit boards in order to find the necessary items for servicing.

When reassembling, perform the steps in the reverse order.




Fig. D1

2-1-2. DETAIL OF DISASSEMBLY METHOD

1. REMOVAL OF THE TOP PANEL

Remove..... 4 Screws (A)




Fig. D2

2. REMOVAL OF THE BOTTOM PLATE

Remove..... Screw (B)

Remove..... 2 Screws (C)

Unlock 4 tabs (D)




Fig. D3

3. REMOVAL OF THE FRONT PANEL UNIT

Pull out JOG & SHUTTLE Knob
Remove Screw (D)
Unlock 8 Tabs (E)




Fig. D4

4. REMOVAL OF THE TIMER C.B.A. & OPERATION C.B.A.

Unlock 6 Tabs (F)




Fig. D5

5. REMOVAL OF THE MECHANISM UNIT

Remove 4 Screws (G) [Fig. D3]
Remove 3 Screws (H)
Remove Screw (I)
Unlock Tab (J) and PACK HOLDER

6. REMOVAL OF THE MAIN C.B.A.

Remove 2 Screws (C) [Fig. D3]
Unlock 7 Tabs (K)




Fig. D6

7. SERVICING POSITION

Remove 2 Screws (C) [Fig. D3]
Remove 3 Screws (H)
Unlock Screw (I)
Unlock Tab (J) and PACK HOLDER
Unlock 7 Tabs (K)




Fig. D7

2-2. MECHANICAL ADJUSTMENT PROCEDURES

The mechanical chassis of this model is the K Mechanical Chassis.
Therefore refer to the Service Manual for K Mechanical Chassis. (Order No. VRD9307M131)

CAUTIONS:

To make a Adjustment Mode for Tape Interchangeability, turn off the Auto Tracking as follows.

Turn the Shuttle Ring to FF then push the EJECT button 3 times to set the Service Mode 2.





2-3. DISASSEMBLY PROCEDURES OF MECHANISM

The mechanical chassis of this model is the K Mechanical Chassis.
Therefore refer to the Service Manual for K Mechanical Chassis. (Order No. VRD9307M131)


2-4. ASSEMBLY PROCEDURES OF MECHANISM

The mechanical chassis of this model is the K Mechanical Chassis.
Therefore refer to the Service Manual for K Mechanical Chassis. (Order No. VRD9307M131)



LOCATION OF TEST POINTS & CONTROLS



LUMINANCE & CHROMINANCE PACK C.B.A.



CIRCUIT BOARD LAYOUT



2-5. ELECTRICAL ADJUSTMENT PROCEDURES

This section provides complete adjustment procedures required for electric circuits of VHS Video Cassette Recorders.

2-5-1. TEST EQUIPMENT

To perform electrical adjustments following equipment is required.

1. Dual-Trace Oscilloscope. (More than 35MHz)
Voltage Range: 0.005-5V/div
Frequency Range: DC-35MHz
Probes: 10:1 OR 1:1
2. Frequency Counter.
Frequency Range: 0-10MHz
Probes: 1:1
3. Universal Counter.
4. Digital Volt Meter. (D.V.M.)
5. Video Sweep Generator.
6. Sine Wave Generator.
7. Video Pattern Generator.
8. VHS Alignment Tape. (VFJ8125H3F)
9. VHS Blank Tape.
10. Monitor.
11. Plastic Tip Driver.
12. DC Power Supply.

2-5-2. PREPARATION

During adjustment, set each selector as follows: when no indication in the procedure.

CVC SW ON
TAPE SPEED SP
CHANNEL.....AV1/AV2
(Set to signal input terminal number)
TEST SIGNAL SW (REAR) OFF
(NV-HD650A ONLY)
NTSC SELECT SW NTSC P.B

2-5-3. HOW TO READ ADJUSTMENT PROCEDURES




Fig. E1




Fig. E2

SERVO SECTION

2-5-4. PG SHIFTER ADJUSTMENT

TP	ADJ.	MODE	INPUT
TW2001 VIDEO OUT	VR2001	PLAYBACK	
TAPE	M. EQ.	SPEC.	
ALIGNMENT TAPE VFJ8125H3F	OSCILLO- SCOPE	7.0+—0.5 (H)	




Fig. E3

LUMINANCE & CHROMINANCE SECTION

2-5-5. RECORDING CURRENT ADJUSTMENT

TP	ADJ.	MODE	INPUT
TP507 (HOT) TP508 (GND)	VR3001 (Y) VR8001 (C)	SP RECORDING	PAL COLOUR BAR
TAPE	M. EQ.	SPEC.	
BLANK TAPE	OSCILLO- SCOPE	Y=130+ $\pm$ 5 (mVp-p) C=32+ $\pm$ 2 (mVp-p)	

- Note: 1. Adjust the Luminance level until the peak level of V-SYNC is 130+ $\pm$ 5mVp-p.
2. When adjusting the Chrominance level, Supply +5V DC to Pin 6 of PP3001 to eliminate Luminance component.




Fig. E4

2-5-6. VIDEO FREQUENCY RESPONSE ADJUSTMENT

TP	ADJ.	MODE	INPUT
VIDEO OUT	VR3012 (SP) VR3013 (LP)	SP/LP (SELF RECORD) PLAYBACK	VIDEO SWEEP SIGNAL (Shown in Fig. E7)
TAPE	M. EQ.	SPEC.	
BLANK TAPE	OSCILLOSCOPE/ VIDEO SWEEP GENERATOR	SP: 0+-1 (dB) (90-110%) LP: 0+-1 (dB) (90-110%)	

Note: 1. Set the Video Sweep Signal as shown in Fig. E5.
2. Set the CVC SW to OFF position.




Fig. E5




Fig. E6

2-5-7. PLAYBACK LEVEL ADJUSTMENT

TP	ADJ.	MODE	INPUT
VIDEO OUT	VR303	PLAYBACK	
TAPE	M. EQ.	SPEC.	
ALIGNMENT TAPE VFJ8125H3F	OSCILLOSCOPE	Y: 2.0+-0.1 Vp-p CYAN: 1.1+-0.3 Vp-p	




Fig. E7

2-5-8. DEVIATION ADJUSTMENT

TP	ADJ.	MODE	INPUT
VIDEO OUT	VR301 VR302	(SELF RECORDED) PLAYBACK	PAL COLOUR BAR
TAPE	M. EQ.	SPEC.	
BLANK TAPE	OSCILLOSCOPE	Y: 2.0+-0.1 (Vp-p) (VIDEO: SYNC=70:30)	

Note: 1. Before this adjustment, the PLAYBACK LEVEL ADJUSTMENT (2-5-7) must be done.
2. Record the colour bar signal and adjust VR301 and VR302 during recording.
3. Playback the just recorded portion and confirm the playback Y-signal level is 2.0+-0.1 Vp-p.
4. If the signal level is out of the specification, repeat 2 and 3 until the signal level is the specification.




Fig. E8

2-5-9. AI FUNCTION ADJUSTMENT

TP	ADJ.	MODE	INPUT
TW7	VR3014	PLAYBACK (SELF RECORDED)	PAL COLOUR BAR
TAPE	M. EQ.	SPEC.	
BLANK TAPE	D.V.M	2.5+-0.3 (V)	

AUDIO SECTION

2-5-10. BIAS CURRENT ADJUSTMENT

TP	ADJ.	MODE	INPUT
TP4002 (HOT) TP4003 (GND)	VR4001	RECORDING	
TAPE	M. EQ.	SPEC.	
BLANK TAPE	D.V.M.	2.6+-0.1 (mVrms)	

Note: 1. Connect the Audio Input and GND.

2-5-11. CARRIER FREQUENCY ADJUSTMENT

TP	ADJ.	MODE	INPUT
IC4501-34 (L) IC4501-47 (R)	VR4501 (NTSC-L) VR4509 (NTSC-R) VR4551 (PAL-L) VR4552 (PAL-R)	SP RECORDING	
TAPE	M. EQ.	SPEC.	
BLANK TAPE	FREQUENCY COUNTER	NTSC-L: 1.3+-0.003 (MHz) NTSC-R: 1.7+-0.003 (MHz) PAL-L: 1.4+-0.003 (MHz) PAL-R: 1.8+-0.003 (MHz)	

Note: 1. When adjusting the NTSC mode, connect a jumper wire between PP3002-2 and GND.
2. When adjusting the PAL mode, disconnect a jumper wire.

2-5-12. DEVIATION ADJUSTMENT

TP	ADJ.	MODE	INPUT
BETWEEN VR4502 and R4511 (L) BETWEEN VR4507 and R4561 (R)	VR4502 (L) VR4507 (R)	SP RECORDING	SINEWAVE 1 KHz/-6 dB (AV1 IN)
TAPE	M. EQ.	SPEC.	
BLANK TAPE	V.T.V.M./ SINEWAVE GENERATOR	110 (mVrms)	

Note: 1. Before recording the sinewave, set the sinewave generator until the audio outputs (L) and (R) are 400mVrms.

2-5-13. FM B.P.F. ADJUSTMENT

TP	ADJ.	MODE	INPUT
IC4501-33 (L) IC4501-48 (R)	VR4550	PLAYBACK	SINEWAVE 1.608MHz/ 200mVp-p (PK4003-8)
TAPE	M. EQ.	SPEC.	
NTSC RECORDED TAPE	OSCILLO- SCOPE/ SINEWAVE GENERATOR	Lch (IC4501-33)= Rch (IC4501-48)	

Note: 1. Disconnect P501 (from MAIN C.B.A. to HEAD AMP C.B.A.).
2. The GND lead of oscilloscope must be connected to GND on HIFI AUDIO PACK C.B.A. to reduce the noise.
3. Supply the sinewave signal (1.608MHz/200mVp-p) to PK4003-8.
4. After this adjustment, connect P501.

TIMER SECTION

2-5-14. TIMER REFERENCE CLOCK ADJUSTMENT

TP	ADJ.	MODE	INPUT
TL7501	VC7501	STOP	
TAPE	M. EQ.	SPEC.	
	UNIVERSAL COUNTER	7812.5+/-0.015 (usec)	

2-5-15. LEVEL METER SENSITIVITY ADJUSTMENT

TP	ADJ.	MODE	INPUT
LEVEL METER ON THE FIP	VR4004	STOP	SINEWAVE 1 KHz/-6dB (AVI IN)
TAPE	M. EQ.	SPEC.	
		0dB INDICATOR ON THE AUDIO LEVEL METER JUST LIGHTS UP	

- Note: 1. Select the STEREO mode.
(Both Left and Right indicators on the FIP are lit.)
2. Before recording the sinewave, set the sinewave generator until the audio outputs (L) and (R) are 400mVrms.
3. Before this adjustment, the HIFI EE LEVEL ADJUSTMENT (2-5-11) must be done.

Memo

SECTION 3

ABBREVIATIONS & BLOCK DIAGRAMS

3-1. ABBREVIATIONS

443NT [L]	4.43 NTSC ①	BIL. [H]	BILINGUAL ⑥
A. COMP	AUDIO COMPONENT SIGNAL	BIL/M1 [L]	BILINGUAL ①
A. COMPO	AUDIO COMPONENT SIGNAL	BS CLOCK	BS CLOCK
A. D.P [L]	AUDIO DUBBING PAUSE ①	BS DATA	BS DATA
A. D/L [L]	AUDIO DUBBING PAUSE ①	BS LCH IN	BS L CHANNEL INPUT
A. DEF [S]	AUDIO DEFEAT	BS MIX [H]	BS MIX ⑥
A. DEF [S] [L]	AUDIO DEFEAT	BS MON [H]	BS MONITOR ⑥
A. DUB P [L]	AUDIO DUBBING PAUSE ①	BS MONI [H]	BS MONITOR ⑥
A. DUB [H]	AUDIO DUBBING ⑥	BS RCH IN	BS R CHANNEL INPUT
A. ERASE	AUDIO ERASE	BS VIDEO	BS VIDEO SIGNAL
A. H. SW	AUDIO HEAD SWITCHING PULSE	BS VIDEO/BS1	BS VIDEO SIGNAL
A. HEAD [R]	AUDIO HEAD (REC)	BS [H]	BS ⑥
A. HEAD [W]	AUDIO HEAD (PLAY)	BS. LEVEL	BS LEVEL
A. IN [L]	AUDIO INPUT (L)	BS. M [H]	BS MONITOR ⑥
A. IN [R]	AUDIO INPUT (R)	BS/VTR [H]	BS/VTR ⑥
A. MUT [H]	AUDIO MUTE ⑥	BUS CLK	BUS CLOCK
A. MUTE [H]	AUDIO MUTE ⑥	BUS LSN	BUS LISTEN
A. OUT [L]	AUDIO OUTPUT (L)	BUS TLK	BUS TALK
A. OUT [R]	AUDIO OUTPUT (R)	BUZZER	BUZZER
A. RF OUT	AUDIO RF SIGNAL OUTPUT	CAP EC	CAPSTAN TORQUE CONTROL
A/VS/S. DATA	AV SW/SERIAL DATA	CAP M GND	CAPSTAN MOTOR GND
AC ONLINE	AC ONLINE	CAP. ET	CAPSTAN TORQUE CONTROL
AC. O/EE. H	AC ONLINE/EE ⑥	CAP. FG1	CAPSTAN FG1 PULSE
AFC S C	AFC S CURVE	CAP. FG2	CAPSTAN FG2 PULSE
AFC [S]	AFC S CURVE	CAS. SW	CASSETTE SW
AFC. DEF	AFC DEFEAT	CCN	PLAYBACK CONTROL SIGNAL (-)
ARFC OUT	AUDIO RF SIGNAL OUTPUT	CCP	PLAYBACK CONTROL SIGNAL (+)
ART. V	ARTIFICIAL VERTICAL SYNC SIGNAL	CHM	CONTROL SIGNAL (+)
ART. V. MM	ARTIFICIAL VERTICAL SYNC	CHP	CONTROL SIGNAL (-)
	SIGNAL MONO MULTI	CINEM [L]	CINEMA ①
ART. V/H/N	ARTIFICIAL VERTICAL SYNC	CINEMA [L]	CINEMA ①
	SIGNAL ⑥/NORMAL	CINEMA/MIX	CINEMA/MIX
AT. V/H/N	ARTIFICIAL VERTICAL SYNC SIGNAL	CKL	RATCH LOCK
ATSW/TEST/NOR/SE	TEST/NORMAL/SERVICE	CKS	SHIFT LOCK
AUDIO IN [L]	AUDIO INPUT (L)	CL	CLOCK
AUDIO IN [R]	AUDIO INPUT (R)	CLK	CLOCK
AUDIO OUT [L]	AUDIO OUTPUT (L)	CLK (C.G)	CLOCK
AUDIO OUT [R]	AUDIO OUTPUT (R)	CLOCK. IN	CLOCK INPUT
AUDIO SELECT [H]	AUDIO SELECT ⑥	CLP	CLAMP
AUDIO. L	AUDIO (L)	COL/B/W/NOR	COLOUR/BLACK & WHITE/NORMAL
AUDIO. R	AUDIO (R)	COLOR [H]	COLOUR ⑥
AV CNT	AV CONTROL	CONV	CONVERTOR
AV CTL	AV CONTROL	CS	CHIP SELECT
AV CTL/S. CLK	AV CONTROL/SERIAL CLOCK	CTL GND	CONTROL GND
AV. C.M.	AV CONTROL MODE	CTL HEAD [+]	CONTROL HEAD (+)
AVCNT/METER. R	AV CONTROL/LEVEL METER (R)	CTL HEAD [-]	CONTROL HEAD (-)
AVSW/METER. L	AV SW/LEVEL METER (L)	CTL [+]	CONTROL HEAD (+)
B MODE. H	B MODE ⑥	CTL [-]	CONTROL HEAD (-)
B.G.P	BURST GATE PULSE	CUE BIAS	CUE BIAS
BACKUP 5V	BACK UP 5V	CURRENT LIM	CURRENT LIMMETER
BAND. U.E.	BAND U	CYL ET	CYLINDER TORQUE CONTROL
BANDVL. D	BAND VL	CYL GND	CYLINDER GND
BI/MI [L]	BILINGUAL/MIX ①	D.F.M. REC [H]	DELAIED FM RECORDING ⑥
BIL	BILINGUAL	D. FM REC [L]	DELAIED FM RECORDING ①
BIL [L]	BILINGUAL ①	D. GND	DIGITAL GND

ABBREVIATIONS


D. REC [H]	DELAYED RECORDING ④	H. SYNC	HORIZONTAL SYNC
D4/S. LED	D4/STILL LED	H. AMP. SW	HEAD AMP SW PULSE
D4/STILLED	D4/STILL LED	H. P <R>	HEAD PHONE (R)
DAC [CLK]	TUNER DAC (CLOCK)	H. P <L>	HEAD PHONE (L)
DAC/FSCS	TUNER DAC/FS CHIP SELECT	H. P GND	HEAD PHONE GND
DAREC [H]	DELAYED AUDIO RECORDING ④	H. P OUT [L]	HEAD PHONE OUTPUT (L)
DATA	DATA	H. P OUT [R]	HEAD PHONE OUTPUT (R)
DECODER [L]	DECODER (L)	H. SW	HEAD SW PULSE
DECODER [R]	DECODER (R)	HEAD PHONE [L]	HEAD PHONE (L)
DEW	DEW	HEAD PHONE [R]	HEAD PHONE (R)
DEW SNS	DEW SENSOR	HEAD SW	HEAD SW
DFMRE [H]	DELAYED FM AUDIO RECORDING ④	HEATER [+]	HEATER (+)
E. REC 5V	EXCEPT RECORDING 5V	HEATER [-]	HEATER (-)
EC	ERROR TORQUE CONTROL	HSS	HORIZONTAL SYNC SIGNAL
ECR	ERROR TORQUE CONTROL	HTR [+]	HEATER (+)
	REFERENCE VOLTAGE	HTR [-]	HEATER (-)
EDT TRIG [L]	EDIT TRIGGER ①	I RFE	REFERENCE CURRENT
EDIT [H]	EDIT ④	ICL	CONTROL AGC CIRCUIT
EE [H]	EE ④	IF	INTERMEDIATE FREQUENCY
EE [H]/INS [M]	EE ④/INSERT ④	IN SELA1	INPUT SELECT A1 POSITION
EE. VV. TR	EE/VV/TRICK PLAY	IN SELA2	INPUT SELECT A2 POSITION
EJECT. PO	EJECT POSITION	IN SELA3	INPUT SELECT A3 POSITION
EJECT/VDET	EJECT/REVERSE SLOW LOCK	INS L/R [L]	INSERT Lch/Rch ①
ENV. SEL	ENVELOPE SELECT	INS. [H]	INSERT ④
ENVE. OUT	ENVELOPE OUTPUT	INSEL A1	INPUT SELECT A1 POSITION
ENVE. SEL	ENVELOPE SELECT	INSEL A2	INPUT SELECT A2 POSITION
ENV SELECT	ENVELOPE SELECT	INSERT	INSERT
EP [H]	LP ④	INSERT [H]	INSERT ④
EP/LP [H]	LP ④	IO CS	INPUT/OUTPUT CHIP SELECT
EP/LP/SP	LP/SP	JOG1	JOG1
EP/SS [H]	LP/SLOW/STILL/STOP ④	JOG S3 LED/FOWRD	JOG LED/FORWARD LED
EPROMCS	EPROM CHIP SELECT	JOG/F. LED	JOG LED/FORWARD LED
EX. REC 5V	EXCEPT RECORDING 5V	JSB [H]	JSB ④
FF/REW [L]	FIRST FORWARD/REWIND ①	JST. CLCK	JUST CLOCK
FG1 IN	FG1 PULSE INPUT	JST. CLK	JUST CLOCK
FG2 IN	FG2 PULSE INPUT	JST. CLOCK	JUST CLOCK
FILTER ADJUSTMEN	FILTER ADJUSTMENT	L. OUT	Lch OUTPUT
FLY ERASE [H]	FLYING ERASE HEAD ON ④	L. CH [H]	Lch ④
FLY ON [H]	FLYING ERASE E HEAD ON ④	L. CH [L]	Lch ①
FLY. E [H]	FLYING ERASE HEAD ON ④	LED (MAIN)	LED (MAIN)
FM MUT [H]	FM AUDIO MUTE ④	LED (STEREO)	LED (STEREO)
FM MUTE [H]	FM AUDIO MUTE ④	LED (SUB)	LED (SUB)
FM OUT [L]	FM OUTPUT (L)	LED CKL	LED SERIAL CLOCK
FM OUT [R]	FM OUTPUT (R)	LED CKS	LED SERIAL CLOCK
FM PACK OUT [L]	FM PACK OUTPUT (L)	LED DATA	LED SERIAL DATA
FM PACK OUT [R]	FM PACK OUTPUT (R)	LINE IN 1 [L]	LINE INPUT 1 (L)
FM/BS SEL [L]	FM/BS SELECT (L)	LINE IN 1 [R]	LINE INPUT 1 (R)
FM/BS SEL [R]	FM/BS SELECT (R)	LINE IN 2 [L]	LINE INPUT 2 (L)
FS. CLK	FS CLOCK	LINE IN 2 [R]	LINE INPUT 2 (R)
FUL. E [H]	FULL ERASE HEAD ON ④	LINE IN V	LINE INPUT VIDEO
FULL. E [H]	FULL ERASE HEAD ON ④	LINE IN [L]	LINE INPUT (L)
FULL. E. 12V	FULL ERASE 12V	LINE IN [R]	LINE INPUT (R)
GND [A]	GND (ANALOGUE)	LINE OUT [L]	LINE OUTPUT (L)
GND [TU]	GND (TUNER)	LINE OUT [R]	LINE OUTPUT (R)
GND/N. SW. 12V	GND/NON SW 12V	LP [H]	LP ④

LPTRI [L]	LP TRICK PLAY ①	P. OFF [L]	POWER OFF ①
Lch/A. DUB	Lch/AUDIO DUBBING	PAL [H]	PAL ②
M GND	MOTOR GND	PAL [L]/NTSC [H]	PAL ①/NTSC ②
M REG	MOTOR REGULATOR	PB ADJ OUT	PLAYBACK ADJUST OUTPUT
MAIN OUT	MAIN OUTPUT	PB OUT	PLAYBACK OUTPUT
MAIN [L]	MAIN ①	PB. H	PLAYBACK ②
MAIN/MONO	MAIN/MONAUURAL	PFG	PG/FG
MAX IN	MAXIMAM INPUT	PHOTSN +B	PHOTO SENSOR +B
MES [H]	MESECAM ②	PICT. CNT	PICTURE CONTROL
MESE [H]	MESECAM ②	PLAY LED/RVS LED	PLAY LED/REVERSE LED
MESE [L]	MESECAM ①	PLAY. PO	PLAY POSITION
METER 5V	LEVEL METER 5V	PLAY/R. LED	PLAY LED/REVERSE LED
METER [L]	LEVEL METER (L)	PLY/DEW	PLAY/DEW ②
METER [R]	LEVEL METER (R)	POWER OFF [L]	POWER OFF ①
METER. L/AVS	LEVEL METER (L)	PREROLL [H]	PREROLL ②
METER. R/AVC	LEVEL METER (R)	PWRFAIL	POWER FAILURE DETECT
MI/BI [L]	MIX ②/BILIGUAL	R. CH [H]	Rch ②
MIC GND	MIC GND	R. CH [L]	Rch ①
MIC IN	MIC INPUT	R. ST	RESET
MIC IN [L]	MIC INPUT (L)	R/S/F	REVERSE ②/STOP ③/FORWARD ①
MIC IN [R]	MIC INPUT (R)	RCH [H]	Rch ②
MIC [H]	MIC ②	REC 12V	RECORDING 12V
MIX [H]	MIX ②	REC CHROMA	RECORDING CHROMINANCE SIGNAL
MIX [H]/CINEMA [L]	MIX ②/CINEMA SOUND ①	REC H	RECORDING ②
MIX/CINE	MIX ②/CINEMA SOUND ①	REC IN	RECORDING INPUT
MIX/CINEMA [L]	MIX ②/CINEMA SOUND ①	REC OUT [L]	RECORDING OUTPUT ①
MN. H/M. L	MONAURAL ②/MAIN ①	REC START	RECORDING START
MN. H/MAI. L	MONAURAL ②/MAIN ①	REC VR [C]	RECORDING VOLUME (COMMON)
MN2/MES. L	MONAURAL 2/MESECAM ①	REC VR [L]	RECORDING VOLUME (L)
MODE SEL	AUDIO MODE SELECT	REC VR [R]	RECORDING VOLUME (R)
MODE SW	AUDIO MODE SW	REC Y	RECORDING LUMINANCE SIGNAL
MODE. S. IN	AUDIO MODE SELECT INPUT	REC [H]	RECORDING ②
MODE. S. OUT	AUDIO MODE SELECT OUTPUT	REC. C	RECORDING CHROMINANCE SIGNAL
MONO [H]	MONAURAL ②	REC. Y	RECORDING LUMINANCE SIGNAL
MONO [H]/MAIN [L]	MONAURAL ②/MAIN ①	REC/EE CTL	RECORDING/EE CONTROL
MONO2 [L]	MONAURAL 2	REEL-T	REEL PULSE (TAKE-UP)
MONO2/MESE (FM(L))	MONAURAL 2/MESECAM (FM ①)	REEL-S	REEL PULSE (SUPPLY)
MOTOR GND	MOTOR GND	REGULATOR FILTER	REGULATOR FILTER
MUTE	MUTE	RESET	RESET
N. A. REC [L]	NORMAL AUDIO RECORDING	REV M F/R	REVIEW MOTOR
N. SW 12V	NON SW 12V	REV M V1	FORWARD/REVERSE
N. SW. 5. DET	NON SW 5V DETECT	REV M V2	REVIEW MOTOR V1
NICAM	NICAM	REV MOTOR F/R	REVIEW MOTOR V2
NICAM [L]	NICAM ①		REVIEW MOTOR
NOL [H]	PAL ②/4.43 NTSC ③/3.58 NTSC ①		FORWARD/REVERSE
NOR/SOFT [H]	NORMAL/SOFT TAPE PLAY ②	REV MOTOR V1	REVIEW MOROR V1
NORMAL [H]	NORMAL ②	REV MOTOR V2	REVIEW MOTOR V2
NR BIAS	NR BIAS	REV MOTOR [+]	REVIEW MOTOR (+)
NTSC [L]	NTSC ①	REV MOTOR [-]	REVIEW MOTOR (-)
OCH	CONTROL AGC CIRCUIT	REV. M. GND	REVIEW MOTOR GND
OUT	OUTPUT	RF. CHROMA	RF CHROMINANCE SIGNAL
P-OFF [H]	POWER OFF ②	RF OUT	RF OUTPUT
P-OFF [L]	POWER OFF ①	RF Y	RF LUMINANCE SIGNAL
P. FAIL	POWER FAILURE DETECT	RF. Y. IN	RF LUMINANCE SIGNAL INPUT
P. OFF [H]	POWER OFF ②	RF. Y. OUT	RF LUMINANCE SIGNAL OUTPUT


ABBREVIATIONS

ROTAR. SW	ROTARY SW	T. BUSCLK	TIMER BUS CLOCK
ROTARY	ROTARY SW	T. BUSLSN	TIMER BUS LISTEN
RST	RESET	T. BUSTLK	TIMER BUS TALK
RST [L]	RESET ①	T. END [L]	TAPE END ①
Rch/INST	Rch/INSERT	T. PHOTO	TAKE-UP PHOTO TRANSISTOR
S IN	SERIAL DATA INPUT	TAPE END [L]	TAPE END ①
S OUT	SERIAL DATA OUTPUT	TAPE END [L]/CAM	TAPE END ①/CAMERA PAUSE
S-PHOTO	SUPPLY PHOTO TRANSISTOR	TEST	TEST MODE
S-RL. PLS	SUPPLY REEL PULSE	TPZ	TRAPEZOIDAL WAVE CIRCUIT
S. CLK	SERIAL CLOCK	TRIC [L]	TRIC PLAY ①
S. CLK/AV	SERIAL CLOCK/AV	TRICK [L]	TRIC PLAY ①
S. DATA	SERIAL DATA	TRK. ENV	AUTO TRACKING ENVELOPE DETECT
S. DATA/A	SERIAL DATA	TU. AUDIO	TUNER AUDIO
S. PHOTO	SUPPLY PHOTO TRANSISTOR	TU. GND	TUNER GND
S. TAB [L]	SAFETY TAB SW ON ①	TU. V. IN	TUNER VIDEO SIGNAL INPUT
S/P/N	SECAM/PAL/NTSC	TU. VIDEO	TUNER VIDEO
SC IN	SERIAL CLOCK INPUT	TUN NOR IN	TUNER NORMAL INPUT
SC OUT	SERIAL CLOCK OUTPUT	TUN R	TUNER AUDIO (R)
SCK SELECT	SERIAL CLOCK SELECT	TUN. AUDIO IN	TUNER AUDIO INPUT
SEL OUT [L]	SELECT OUTPUT (L)	TUNER 12V	TUNER 12V
SEL OUT [R]	SELECT OUTPUT (R)	TUNER L	TUNER AUDIO (L)
SHUTTLE 1	SHUTTLE 1	TUNER V IN	TUNER VIDEO SIGNAL INPUT
SIF	SOUND INTERMEDIATE FREQUENCY	TUNER [L]	TUNER AUDIO (L)
SLMUT [H]	INPUT SELECT MUTE ②	TUNER [N]	TUNER AUDIO (NORMAL)
SLNID [+]	SOLENOID (+)	TUNER [R]	TUNER AUDIO (R)
SLNID [-]	SOLENOID (-)	TUNER. 12	TUNER 12V
SLW TR. MM	SLOW TRACKING MONO MULTI	TUOFF [H]	TUNER OFF ②
SLW TR. REF	SLOW TRACKING REFERENCE	TV. AUDIO	TV AUDIO
	VOLTAGE	TV/VTR	TV/VTR
SNS. GND	SENSOR GND	TXTON [L]	TEXT ON ①
SOFT [H]	SOFT TAPE PLAY ②	U. REG45V	UNREGULATOR 45V
SOFT [H]/NORMAL	SOFT TAPE PLAY ②/NORMAL ②	UNREG	UNREGULATOR
SOLENOID ON [L]	SOLENOID ON ①	UNREG19V	UNREGULATOR 19V
SP [H]	SP ②	V. REF	REFERENCE VOLTAGE
SP/L/SLP	SP/LP	V. EE [H]	VIDEO EE ②
SSS [L]	SLOW/STILL/STOP	V. EE [L]	VIDEO EE ①
STEREO LED	STEREO LED	VCO REF	RERERENCE OSCILLATER
STEREO [H]	STEREO ②	VD. IN	VIDEO SIGNAL INPUT
STEREO [L]	STEREO ①	VD. OUT	VIDEO SIGNAL OUTPUT
STOP. PO	STOP POSITION	VIDEO EE [L]	VIDEO EE ①
STOP/5V	STOP POSITION/5V	VIDEO IN	VIDEO SIGNAL INPUT
STOP1/TAPE SEL	STOP1 POSITION/TAPE SELECT	VIDEO OUT	VIDEO SIGNAL OUTPUT
STOP1/PAL:ST	STOP1 POSITION/PAL	VM	MOTOR VOLTAGE
STOP2. PO	STOP 2 POSITION	VM DOWN [L]	MOTOR VOLTAGE DOWN ①
STOP2/S-TAB	STOP 2 POSITION/SAFETY TAB SW	VSS	VERTICAL SYNC SIGNAL
STREO [H]	STEREO ②	VTR [H]	VTR ②
SUB BIAS	SUB BIAS	VTR. 12V	VTR 12V
SUB. SW	SUB SW	X IN	OSCILLATOR INPUT
SVHS CAS [L]	S-VHS CASSETTE ①	X OUT	OSCILLATOR OUTPUT
SW. 5. DET	SW 5V DETECT		
SYNC [L]	SYNC ①		
SYSCON 5V	SYSTEM CONTROL 5V		
SYSTEM	SYSTEM SW		
T-PHOTO	TAKE-UP PHOTO TRANSISTOR		
T-RL. PLS	TAKE-UP REEL PULSE		

3-2. SYSTEM CONTROL & SERVO BLOCK DIAGRAM





SYSTEM CONTROL & SERVO BLOCK LUMINANCE & CHROMINANCE BLOCK LUMINANCE & CHROMINANCE BLOCK





3-4. Hi-Fi AUDIO BLOCK DIAGRAM






SECTION 4 SCHEMATIC DIAGRAMS

4-1. POWER SUPPLY SECTION IN MAIN SCHEMATIC DIAGRAM

CAUTION

THE RED MARK INDICATES THE PRIMARY CIRCUIT TO DISTINGUISH THE PRIMARY FROM THE SECONDARY CIRCUIT.
PAY ATTENTION NOT TO RECEIVE AN ELECTRIC SHOCK DURING REPAIR AND SERVICE THE PRODUCTS.



NOTE 1. WHEN MEASURE THE VOLTAGE OR WAVEFORM ON THE POWER TRANSFORMER CIRCUIT, SET THE GND TERMINAL OF MEASURING POINT AS FOLLOWS

PRIMARY SIDE $\frac{1}{2}$
SECONDARY SIDE . . . $\frac{1}{4}$

NOTE 2. THE DC VOLTAGE INDICATED IN PRIMARY SIDE IS SHOWN THE VOLTAGE WHEN INPUT AC IS 240V. .

NOTE: DO NOT USE ANY PART NUMBER SHOWN ON THIS SCHEMATIC DIAGRAM FOR ORDERING. WHEN YOU ORDER A PART, PLEASE REFER TO PARTS LIST.


4-2. RF SECTION IN MAIN SCHEMATIC DIAGRAM

VIDEO MAIN SIGNAL PATH IN REC MODE

VIDEO MAIN SIGNAL PATH IN PLAYBACK MODE

AUDIO MAIN SIGNAL PATH IN REC MODE

AUDIO MAIN SIGNAL PATH IN PLAYBACK MODE



SYSTEM CONTROL & SERVO TR.s DC VOLTAGE CHART (SP MODE)

[illegible]

CAPSTAN SE




CAPSTAN SERVO SPEED LOOP

CAPSTAN SERVO PHASE LOOP


CYLINDER SERVO SPEED LOOP

CYLINDER SERVO PHASE LOOP




NOTE: DO NOT USE ANY PART NUMBER SHOWN ON THIS SCHEMATIC DIAGRAM FOR ORDERING. WHEN YOU ORDER A PART, PLEASE REFER TO PARTS LIST.

4-13




4-5. MAIN C.B.A. (VEP06980P: NV-HD650A) (VEP06980Q: NV-HD650EA)



CAUTION


THE RED MARK INDICATES THE PRIMARY OR TO DISTINGUISH THE PRIMARY FROM SECONDARY CIRCUIT. PAY ATTENTION NOT TO REMOVE AN ELECTRONIC DURING REPAIR AND SERVICE OF PARTS.



CAUTION

THE RED MARK INDICATES THE PRIMARY CIRCUIT TO DISTINGUISH THE PRIMARY FROM THE SECONDARY CIRCUIT.

PAV ATTENTION NOT TO REMOVE AN ELECTRIC SHOCK DURING REPAIR AND SERVICE OF THE PRODUCT.



MAIN C.B.A. ADDRESS INFORMATION

POWER SUPPLY SECTION	
Transistor	
Q1005	B-3
Q1006	A-1
Q1007	A-2
Q1008	B-3
Q1009	B-3
Q1101	D-2
Q1102	E-1
Q1111	C-2
Transistor & Resistor	
QR1101	E-1
Integrated Circuit	
IC1001	B-3
IC1101	D-2
IC1102	B-3

ADDRESS INFORMATION

SYSTEM CONTROL & SERVO SECTION			
Transistor		Test Point	
Q1501	E-13	T.2001	A-8
Q6001	G-8	T.2002	A-7
Q6002	D-6	T.2009	B-4
		TW7	B-4
		TW2001	F-6
		TW2002	B-4
Transistor & Resistor		Adjustment	
QR6001	B-10	VR2001	C-6
QR6002	B-7		
QR6004	H-10		
QR6005	H-11		
QR6009	C-7		
QR6010	C-8		
QR6012	C-3		
Integrated Circuit		Connector	
IC2001	A-8	P2001	B-8
IC6001	C-6	P3001	A-3
IC6002	B-10	P3004	D-7
IC6003	B-9	P3151	B-12
		P2001	H-10
		P2002	H-7
		P36035	A-10
		P3151	A-13
		P36035	A-11

ADDRESS INFORMATION

PF SECTION	
Transistor	
Q7601	G-3
Transistor & Resistor	
QR7601	E-4
Test Point	
TW23	F-3
TW24	F-3
TW30	G-3
TW7601	C-3
Connector	
PK7301	E-3
PK7302	F-3

ADDRESS INFORMATION


LUMINANCE/CHROMINANCE & AUDIO SECTION			
Transistor			
Q3001	E-5	QR3027	D-5
Q3002	E-7	QR4001	G-7
Q3004	F-6	QR4002	G-8
Q3005	E-6	QR4003	G-9
Q3006	E-7	QR4005	F-8
Q3007	E-7		
Q3008	G-5		
Q3009	G-5		
Q3010	F-5		
Q3011	G-5		
Q3012	G-5		
Q3013	D-5		
Q3014	D-5		
Q3016	E-6		
Q3017	E-5		
Q3018	E-6		
Q3019	E-6		
Q3020	D-8		
Q3021	D-5		
Q3023	F-7		
Q4003	G-6		
Q4004	G-6		
Q4005	H-9		
Transistor & Resistor		Test Point	
QR3001	F-8	T-1	E-7
QR3002	F-5	T-2	E-7
QR3003	F-5	T-3001	G-5
QR3005	F-7	T-3002	H-4
QR3007	D-8	T-3003	H-4
QR3008	D-8	T-4503	G-8
QR3009	D-9	T-4504	H-8
QR3010	E-9	T-4505	H-8
QR3011	E-8	T-4506	H-8
QR3012	E-9	T-4521	H-6
QR3013	E-9	T-4522	G-8
QR3014	E-8	TW4	B-3
QR3015	F-9	TW11	G-6
QR3016	F-9	TW15	G-6
QR3017	F-9	TW19	G-7
QR3018	F-5	TW28	G-6
QR3019	D-3	TW3001	G-5
QR3020	G-5	TW3025	E-5
QR3021	E-8	TW3026	C-5
QR3023	E-8	TW4510	F-6
QR3026	E-5		
Adjustment		Connector	
VR3001	F-5	P3002	G-5
VR3012	F-5	P3001	D-5
VR3013	F-5	P3003	G-4
VR3014	C-5	P3002	E-4
VR3001	F-5	P3003	D-4
		P3004	C-4
		P3001	H-4
		P3002	H-6
		PK4001	G-8
		PK4002	G-7
		PK4003	G-7

ADDRESS INFORMATION

CAPSTAN SERVO SPEED 1
CYLINDER SERVO SPEED



PACK SCHEMATIC DIAGRAM



MOTOR DRIVE & SUB AUDIO PACK ICs DC VOLTAGE CHART (SP MODE)

		IC2501																			
REF. NO.	MODE	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20
	STOP	0.6	4.4	0.6	13.2	0.1	13.9	0	4.5	0.7	2.8	0.2	0.4	0	4.9	1.5	0	2.3	2.3	2.3	2.2
	PLAY	2.6	4.3	2.6	12.4	1.9	13.6	0	0.7	0.7	2.8	2.5	0.4	0.1	4.9	1.5	0	2.3	2.3	2.3	2.3
	REC	2.7	4.3	2.7	12.4	2.0	13.6	0	0.7	0.7	2.8	2.5	0.4	0.1	5.0	1.5	0	2.3	2.3	2.3	2.3
	F.F	7.5	13.4	7.5	4.3	11.6	13.5	0.1	0.8	0.8	2.8	2.0	0.5	0.2	4.9	1.5	0	2.3	2.3	2.3	2.3
	REW	7.0	13.5	7.0	6.9	11.7	13.6	0	0.7	0.8	2.8	2.3	0.5	0.1	4.9	1.5	0	2.3	2.3	2.3	2.3

		IC2501															
REF. NO.	MODE	21	22	23	24	25	26	27	28	29	30	31	32				
	STOP	2.2	2.3	0	6.3	6.3	6.3	6.3	12.3	2.0	0.6	0	0				
	PLAY	2.3	2.3	0	6.3	6.3	6.3	6.3	12.3	0	2.6	0	0				
	REC	2.3	2.3	0	6.3	6.3	6.3	6.3	12.3	0	2.6	0.1	0				
	F.F	2.3	2.3	0	6.3	6.3	6.3	6.3	12.3	0	7.5	0.2	0				
	REW	2.3	2.3	0	6.3	6.3	6.3	6.3	12.3	4.9	7.4	0.2	0				

		IC2901															
REF. NO.	MODE	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16
	STOP	13.1	13.1	0.1	0.6	0	2.5	2.4	2.6	2.5	2.6	4.9	3.7	3.6	3.7	1.3	13.8
	PLAY	13.8	12.8	0.2	0.6	0	2.5	2.4	2.6	2.5	2.7	4.9	3.7	3.7	3.7	1.4	13.6
	REC	13.7	13.7	0.2	0.6	0	2.5	2.4	2.6	2.5	2.7	4.9	3.8	3.7	3.7	1.5	13.6
	F.F	13.8	13.8	0.1	0.6	0	2.5	2.4	2.6	2.5	2.7	4.9	3.8	3.7	3.7	1.5	13.5
	REW	13.8	13.8	0.2	0.6	0	2.5	2.4	2.6	2.5	2.7	4.9	3.7	3.7	3.7	1.5	13.7

MOTOR DRIVE & SUB AUDIO PACK PINS DC VOLTAGE CHART (SP MODE)

		PS2501															
REF. NO.	MODE	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16
	STOP	12.3	0	13.8	0.2	4.9	2.0	4.9	0	6.3	6.3	4.4	0	0	0	2.4	5.0
	PLAY	12.3	0	13.6	2.5	4.9	0	4.9	0	6.3	6.3	4.4	0	0	0	2.4	4.9
	REC	12.3	0	13.6	2.5	4.9	0	4.9	0	6.3	6.3	4.4	0	0	0	2.4	4.9
	F.F	12.3	0	13.5	2.1	4.9	0	4.9	0	6.3	6.3	4.4	0	0	0	2.4	4.9
	REW	12.3	0	13.5	2.1	4.9	4.9	4.9	0	6.3	6.3	4.4	0	0	0	2.4	4.9


		PS4701										
REF. NO.	MODE	1	2	3	4	5	6	7	8	9	10	11
	STOP	0	0	0	0	0	12.3	0	0	0	4.9	0
	PLAY	0	0	0	0	0	12.3	0	0	0	0	4.9
	REC	3.5	3.5	0	0	0	12.3	4.9	4.7	0	4.9	0
	F.F	0	0	0	0	0	12.3	0	0	0	4.9	0
	REW	0	0	0	0	0	12.3	0	0	0	4.9	0

MOTOR DRIVE & SUB AUDIO PACK TR.s DC VOLTAGE CHART (SP MODE)

		Q4701			Q4703			Q4706			Q4707					
REF. NO.	MODE	E	C	B	E	C	B	E	C	B	E	C	B			
	STOP	0	0.2	0.2	12.3	0.3	12.3	12.5	0.4	12.5	0	0.4	0.3			
	PLAY	0	0.3	0.3	12.3	0.3	12.3	12.5	0.4	12.5	0	0.4	0.3			
	REC	0	11.3	-1.4	12.3	11.9	11.9	12.5	12.5	11.7	0	12.2	0			
	F.F	0	0.3	0.3	12.3	0.3	12.3	12.5	0.4	12.5	0	0.4	0.3			
	REW	0	0.3	0.3	12.3	0.3	12.3	12.5	0.4	12.5	0	0.4	0.3			


		QR4702			QR4703											
REF. NO.	MODE	E	C	B	E	C	B									
	STOP	0	12.5	0	0	12.3	0									
	PLAY	0	12.5	0	0	12.3	0									
	REC	3.6	11.7	4.7	4.1	11.5	4.9									
	F.F	0	12.5	0	0	12.3	0									
	REW	0	12.5	0	0	12.3	0									

4-7. MOTOR DRIVE & SUB AUDIO PACK C.B.A. (VEP04469N)




MOTOR DRIVE & SUB AUDIO PACK C.B.A.					
Transistor			Adjustment		
Q4701	B-1		VR2008	C-4	
Q4703	A-1		VR2011	C-4	
Q4706	A-1		VR4001	C-2	
Q4707	B-2				
Transistor & Resistor			Connector		
QR4702	A-2		P2003	C-2	
QR4703	A-1		P2501	C-2	
			P2502	C-5	
Integrated Circuit			P2901	A-9	
IC2501	B-3		P2902	A-13	
IC2502	B-8		P4002	C-1	
			P4303	C-7	
Test Point			P6303	C-3	
TP2026	B-5		PS2501	A-4	
TP2050	C-7		PS4701	A-1	
TP2651	C-4				
TP4002	C-1				
TP4003	C-1				
TP SERV	C-7				
TP TEST	C-7				


ADDRESS INFORMATION



CYLINDER DRIVE C.B.A. (VEX0129)




4-8. LUMINANCE & CHROMINANCE PACK SCHEMATIC DIAGRAM




LUMINANCE & CHROMINANCE PACK C.B.A. (VEP03D27G)

S-VHS PLAYBACK

The schematic diagram illustrates the internal circuitry of a VCR, specifically the LUMINANCE & CHROMINANCE PACK C.B.A. (VEP03D27G). The circuit is organized into three main sections: A, B, and C. Section A (bottom left) includes components like PS301, PS302, and PS303. Section B (middle left) features IC301 and IC302. Section C (top left) contains various resistors and capacitors. The central part of the diagram shows a diamond-shaped component, likely a video head or drum, with pins numbered 1 through 84. To the right, there are more components including diodes (D301, D302, D303, D304, D305, D306, D307, D308, D309, D310, D311, D312, D313, D314, D315, D316, D317, D318, D319, D320, D321, D322, D323, D324, D325, D326, D327, D328, D329, D330, D331, D332, D333, D334, D335, D336, D337, D338, D339, D340, D341, D342, D343, D344, D345, D346, D347, D348, D349, D350, D351, D352, D353, D354, D355, D356, D357, D358, D359, D360, D361, D362, D363, D364, D365, D366, D367, D368, D369, D370, D371, D372, D373, D374, D375, D376, D377, D378, D379, D380, D381, D382, D383, D384, D385, D386, D387, D388, D389, D390, D391, D392, D393, D394, D395, D396, D397, D398, D399, D400, D401, D402, D403, D404, D405, D406, D407, D408, D409, D410, D411, D412, D413, D414, D415, D416, D417, D418, D419, D420, D421, D422, D423, D424, D425, D426, D427, D428, D429, D430, D431, D432, D433, D434, D435, D436, D437, D438, D439, D440, D441, D442, D443, D444, D445, D446, D447, D448, D449, D450, D451, D452, D453, D454, D455, D456, D457, D458, D459, D460, D461, D462, D463, D464, D465, D466, D467, D468, D469, D470, D471, D472, D473, D474, D475, D476, D477, D478, D479, D480, D481, D482, D483, D484, D485, D486, D487, D488, D489, D490, D491, D492, D493, D494, D495, D496, D497, D498, D499, D500, D501, D502, D503, D504, D505, D506, D507, D508, D509, D510, D511, D512, D513, D514, D515, D516, D517, D518, D519, D520, D521, D522, D523, D524, D525, D526, D527, D528, D529, D530, D531, D532, D533, D534, D535, D536, D537, D538, D539, D540, D541, D542, D543, D544, D545, D546, D547, D548, D549, D550, D551, D552, D553, D554, D555, D556, D557, D558, D559, D560, D561, D562, D563, D564, D565, D566, D567, D568, D569, D570, D571, D572, D573, D574, D575, D576, D577, D578, D579, D580, D581, D582, D583, D584, D585, D586, D587, D588, D589, D590, D591, D592, D593, D594, D595, D596, D597, D598, D599, D600, D601, D602, D603, D604, D605, D606, D607, D608, D609, D610, D611, D612, D613, D614, D615, D616, D617, D618, D619, D620, D621, D622, D623, D624, D625, D626, D627, D628, D629, D630, D631, D632, D633, D634, D635, D636, D637, D638, D639, D640, D641, D642, D643, D644, D645, D646, D647, D648, D649, D650, D651, D652, D653, D654, D655, D656, D657, D658, D659, D660, D661, D662, D663, D664, D665, D666, D667, D668, D669, D670, D671, D672, D673, D674, D675, D676, D677, D678, D679, D680, D681, D682, D683, D684, D685, D686, D687, D688, D689, D690, D691, D692, D693, D694, D695, D696, D697, D698, D699, D700, D701, D702, D703, D704, D705, D706, D707, D708, D709, D710, D711, D712, D713, D714, D715, D716, D717, D718, D719, D720, D721, D722, D723, D724, D725, D726, D727, D728, D729, D730, D731, D732, D733, D734, D735, D736, D737, D738, D739, D740, D741, D742, D743, D744, D745, D746, D747, D748, D749, D750, D751, D752, D753, D754, D755, D756, D757, D758, D759, D760, D761, D762, D763, D764, D765, D766, D767, D768, D769, D770, D771, D772, D773, D774, D775, D776, D777, D778, D779, D780, D781, D782, D783, D784, D785, D786, D787, D788, D789, D790, D791, D792, D793, D794, D795, D796, D797, D798, D799, D800, D801, D802, D803, D804, D805, D806, D807, D808, D809, D810, D811, D812, D813, D814, D815, D816, D817, D818, D819, D820, D821, D822, D823, D824, D825, D826, D827, D828, D829, D830, D831, D832, D833, D834, D835, D836, D837, D838, D839, D840, D841, D842, D843, D844, D845, D846, D847, D848, D849, D850, D851, D852, D853, D854, D855, D856, D857, D858, D859, D860, D861, D862, D863, D864, D865, D866, D867, D868, D869, D870, D871, D872, D873, D874, D875, D876, D877, D878, D879, D880, D881, D882, D883, D884, D885, D886, D887, D888, D889, D890, D891, D892, D893, D894, D895, D896, D897, D898, D899, D900, D901, D902, D903, D904, D905, D906, D907, D908, D909, D910, D911, D912, D913, D914, D915, D916, D917, D918, D919, D920, D921, D922, D923, D924, D925, D926, D927, D928, D929, D930, D931, D932, D933, D934, D935, D936, D937, D938, D939, D940, D941, D942, D943, D944, D945, D946, D947, D948, D949, D950, D951, D952, D953, D954, D955, D956, D957, D958, D959, D960, D961, D962, D963, D964, D965, D966, D967, D968, D969, D970, D971, D972, D973, D974, D975, D976, D977, D978, D979, D980, D981, D982, D983, D984, D985, D986, D987, D988, D989, D990, D991, D992, D993, D994, D995, D996, D997, D998, D999, D1000, D1001, D1002, D1003, D1004, D1005, D1006, D1007, D1008, D1009, D1010, D1011, D1012, D1013, D1014, D1015, D1016, D1017, D1018, D1019, D1020, D1021, D1022, D1023, D1024, D1025, D1026, D1027, D1028, D1029, D1030, D1031, D1032, D1033, D1034, D1035, D1036, D1037, D1038, D1039, D

ADDRESS INFORMATION

MAIN SIGNAL PATH IN REC MC





NOTE: THE MEASUREMENT MODE OF THE DC VOLTAGE IN THE BRACKETS() ON THIS DIAGRAM IS RECORD MODE WITH PAL COLOUR SIGNAL. (SP MODE)


THE MEASUREMENT MODE OF THE DC VOLTAGE OUT OF THE BRACKETS ON THIS DIAGRAM IS PLAYBACK MODE WITH PAL COLOUR SIGNAL. (SF MODE)

MAIN SIGNAL PATH IN PLAYBACK MODE



4-11. Hi-Fi AUDIO PACK C.B.A. (VEP04447PQ: NV-HD650A) (VEP04447PP: NV-HD650EA)






4-38

ADDRESS INFORMATION


4-12. INPUT/OUTPUT PACK SCHEMATIC DIAGRAM



ATIC DIAGRAM

VIDEO MAIN SIGNAL PATH IN REC MODE
VIDEO MAIN SIGNAL PATH IN PLAYBACK MODE

AUDIO MAIN SIGNAL PATH IN REC MODE
AUDIO MAIN SIGNAL PATH IN PLAYBACK MODE




NOTE: THE MEASUREMENT MODE OF THE DC VOLTAGE IN THE BRACKETS () ON THIS DIAGRAM IS RECORD MODE WITH PAL COLOUR SIGNAL. (SP MODE)
THE MEASUREMENT MODE OF THE DC VOLTAGE OUT OF THE BRACKETS ON THIS DIAGRAM IS PLAYBACK MODE WITH PAL COLOUR SIGNAL. (SP MODE)

NOTE: DO NOT USE ANY PART NUMBER SHOWN ON THIS SCHEMATIC DIAGRAM FOR ORDERING. WHEN YOU ORDER A PART, PLEASE REFER TO PARTS LIST.


4-13. INPUT/OUTPUT PACK C.B.A. (VEP03B27F: NV-HD650A) (VEP03B27A: NV-HD650EA)

INPUT/OUTPUT PACK C.B.A.	
Transistor	
Q3901	C-4
Integrated Circuit	
IC3901	B-5
IC3902	B-5
IC7701	C-1
Connector	
P3901	C-5
PS3901	A-4
PS3902	A-2

ADDRESS INFORMATION




4-14. HEAD AMP SCHEMATIC DIAGRAM



4-15. HEAD AMP C.B.A. (VEP05227A)


HEAD AMP C.B.A.	
Transistor & Resistor	
QR501	A-3
Integrated Circuit	
IC501	E-2
IC502	E-4
Test Point	
TL501	E-4
TP507	C-1
TP508	C-1
TP4502	E-4
TP4507	E-3
Connector	
P501	C-2
P502	A-2

ADDRESS INFORMATION



4-16. TV DEMODULATOR PACK SCHEMATIC DIAGRAM

VIDEO SIGNAL PATH AUDIO SIGNAL PATH




NOTE: DO NOT USE ANY PART NUMBER SHOWN ON THIS SCHEMATIC DIAGRAM FOR ORDERING. WHEN YOU ORDER A PART, PLEASE REFER TO PARTS LIST.


4-17. TV DEMODULATOR PACK C.B.A. (VEP07801S)

TV DEMODULATOR PACK C.B.A.	
Transistor	
Q0701	B-1
Q0702	B-1
Integrated Circuit	
IC0701	B-2
Test Point	
TL0703	B-2
Adjustment	
T0703	A-2
T0704	A-3
VR0701	C-1
Connector	
PK0701	C-2
PP0701	B-3


ADDRESS INFORMATION




4-18. TIMER C.B.A. (VEP07773D: NV-HD650A) (VEP07773E: NV-HD650EA) & OPERATION C.B.A. (VEP06995C: NV-HD650A) (VEP06995H: NV-HD650EA)




V-HD650A) (VEP06995H: NV-HD650EA)





OPERATION C.B.A. (VEP06995C: NV-HD650A) (VEP06995H: NV-HD650EA)




TIMER C.B.A.	
Transistor	
Q6501	B-1E
Transistor & Resistor	
QR7501	B-3
QR7508	C-2
QR7509	C-4
QR7505	C-4
QR7506	C-3
QR7507	C-3
QR7505	C-3
QR7509	B-4
QR7513	B-4
QR7511	A-5
QR7512	A-5
QR7513	A-5
Integrated Circuit	
IC6501	A-14
IC7501	B-10
IC7502	C-2
IC7504	B-12
IC7505	A-12
IC7506	B-7
Test Point	
TL7501	B-9
TL7502	B-5
TL7505	B-5
TW1	C-6
TW2	C-7
TW3	C-7
TW4	B-6
TW5	C-5
Adjustment	
VC7501	A-11
VR4004	B-5
Connector	
P6501	B-16
P7501	C-5
P7502	B-4
PT503	C-3
PP7501	A-12
PS6501	B-13


ADDRESS INFORMATION

[illegible]

4-20. NICAM DECODER PACK SCHEMATIC DIAGRAM (NV-HD650EA)



AUDIO SIGNAL PATH



TV SYSTEM SELECT

IC7305		TV SYSTEM	SOUND MODULATION
SW1	SW2		
L	L	B/G	FM-MONONICAM GERMAN MULTIPLEX
H	L	I	FM-MONONICAM
*	H	M	FM-MONO

*: DO NOT CARE

FM-MONO MODE SELECT

IC7305	FM-MONO	FM-MONO SOURCE
SW3	MODE	
L	INT	SIF (IF INPUT 1, IF INPUT 2)
H	EXT	AUDIO MULT. (MONO IN)

SIF INPUT SELECT

IC7305	SIF INPUT
SW4	
L	IF INPUT 1
H	IF INPUT 2

AUDIO OUTPUT SELECT

INPUT TV SYSTEM	SOUND MODULATION	FM-MONO MODE	MAIN OUTPUT		SUB OUTPUT	
			INPUT SOURCE	MATRIX	INPUT SOURCE	MATRIX
B/G	MONO	INT	IF INPUT 1/2 (FM)	MCNAURAL	IF INPUT 1/2 (FM)	MONAUFAL
		EXT	MONO IN	MCNAURAL	MONO IN	MONAUFAL
	NICAM STEREO	INT	IF INPUT 1/2 (NICAM)	STEREO	IF INPUT 1/2 (FM)	MONAUFAL
		EXT	IF INPUT 1/2 (NICAM)	STEREO	MONO IN	MONAUFAL
	NICAM M1/DATA	INT	IF INPUT 1/2 (NICAM)	MCNAURAL	IF INPUT 1/2 (FM)	MONAUFAL
		EXT	IF INPUT 1/2 (NICAM)	MCNAURAL	MONO IN	MONAUFAL
	NICAM M1/M2	INT	IF INPUT 1/2 (NICAM)	STEREO	IF INPUT 1/2 (FM)	MONAUFAL
		EXT	IF INPUT 1/2 (NICAM)	STEREO	MONO IN	MONAUFAL
	NICAM DATA	INT	IF INPUT 1/2 (FM)	MCNAURAL	IF INPUT 1/2 (FM)	MONAUFAL
		EXT	MONO IN	MCNAURAL	MONO IN	MONAUFAL
	STEREO BILINGUAL	INT	IF INPUT 1/2 (FM)	STEREO	IF INPUT 1/2 (FM)	MONAUFAL
		EXT	IF INPUT 1/2 (FM)	STEREO	IF INPUT 1/2 (FM)	MONAUFAL
I	MONO	INT	IF INPUT 1/2 (FM)	MCNAURAL	IF INPUT 1/2 (FM)	MONAUFAL
		EXT	MONO IN	MCNAURAL	MONO IN	MONAUFAL
	NICAM STEREO	INT	IF INPUT 1/2 (NICAM)	STEREO	IF INPUT 1/2 (FM)	MONAUFAL
		EXT	IF INPUT 1/2 (NICAM)	STEREO	MONO IN	MONAUFAL
	NICAM M1/DATA	INT	IF INPUT 1/2 (NICAM)	MCNAURAL	IF INPUT 1/2 (FM)	MONAUFAL
		EXT	IF INPUT 1/2 (NICAM)	MCNAURAL	MONO IN	MONAUFAL
	NICAM M1/M2	INT	IF INPUT 1/2 (NICAM)	STEREO	IF INPUT 1/2 (FM)	MONAUFAL
		EXT	IF INPUT 1/2 (NICAM)	STEREO	MONO IN	MONAUFAL
	NICAM DATA	INT	IF INPUT 1/2 (FM)	MCNAURAL	IF INPUT 1/2 (FM)	MONAUFAL
		EXT	MONO IN	MCNAURAL	MONO IN	MONAUFAL
M	MONO	INT	IF INPUT 1/2 (FM)	MCNAURAL	IF INPUT 1/2 (FM)	MONAUFAL
		EXT	MONO IN	MCNAURAL	MONO IN	MONAUFAL

Note: When the IC7305-5 (F MONO) is high, both the MAIN OUTPUT and the SUB OUTPUT apply the FM-MONO audio.


NOTE: MODE OF THE DC VOLTAGE ON THIS DIAGRAM IS STOP MODE.


NOTE: DO NOT USE ANY PART NUMBER SHOWN ON THIS SCHEMATIC DIAGRAM FOR ORDERING. WHEN YOU ORDER A PART, PLEASE REFER TO PARTS LIST.

C



(COMPONENT SIDE)





4—66


N/CAM DECODER PACK C.B.A.	
Transistor	
Q7301	E-5
Q7302	E-5
Q7304	A-5
Q7305	C-7
Q7308	E-6
Q7309	E-6
Q7310	A-2
Q7311	A-1
Q7312	A-1
Q7313	A-1
Transistor & Resistor	
QR7501	A-6
QR7502	A-2
Integrated Circuit	
IC7301	C-2
IC7302	E-6
IC7303	E-1
IC7304	E-6
IC7305	E-7
IC7306	E-6
Test Point	
TL7301	E-6
TL7302	C-6
Adjustment	
C7519	E-5
Connector	
PK7301	A-3
PK7301	A-5
PK7302	A-2
PK7302	A-6

ADDRESS INFORMATION


4-22. DECODER PACK SCHEMATIC DIAGRAM (NV-HD650A)

AUDIO MAIN SIGNAL PATH

AUDIO SUB SIGNAL PATH



4-23. DECODER PACK C.B.A. (VEP07784A: NV-HD650A)




DECODER PACK C.B.A.	
Transistor	
Q7301	A-2
Transistor & Resistor	
QR7304	B-2
Integrated Circuit	
IC7301	B-2
IC7302	C-1
Adjustment	
T7301	C-2
T7304	C-1
T7305	C-1
VR7301	B-3
VR7302	C-2
Connector	
PK7301	A-1
PK7302	A-2

ADDRESS INFORMATION

SECTION 5 EXPLODED VIEWS & PARTS LIST

5-1. EXPLODED VIEW & MECHANICAL REPLACEMENT PARTS LIST

1 CHASSIS PARTS SECTION (1)




Note: 1. * Be sure to make your orders of replacement parts according to this list.
2. IMPORTANT SAFETY NOTICE:
Components identified with the mark (X) have the special characteristics for safety. When replacing any of these components, use only the same type.

Ref. No.	Part No.	Part Name & Description	Pcs	Remarks
1(1)	VAL0043	FLEXIBLE CABLE (SP)	1	P4002-P1001
1(1)	W28444	TOP PLATE	1	
3(1)	W284787	CASSETTE GUIDE	1	
4(1)	W284660	SIDE PLATE (L) UNIT	1	
5(1)	W284602	OPENER LEVER	1	
6(1)	W284661	CASSETTE HOLDER PLATE UNIT	1	
7(1)	W284606	SIDE PLATE (R) UNIT	1	
8(1)	W284639	MAIN SHAFT UNIT	1	
9(1)	W284640	CLEANER ARM UNIT	1	
10(1)	W284652	FE HEAD	1	
11(1)	W284671	CARRIAGE CONNECTION GEAR	1	
12(1)	W284685	FINCH CAM GEAR	1	
13(1)	W284602	IMPEDANCE ROLLER UNIT	1	
20(1)	W284617	P/C HEAD (L) UNIT	1	
22(1)	W284624	P/C HEAD BASE	1	
23(1)	W284615	P/C HEAD SPRING	3	
25(1)	W284676	POINT ANGLE	1	
26(1)	W284658	HEAD ARM MOUNT ANGLE (L)	1	
27(1)	W284617	SAFETY SPRING	1	
28(1)	W284674	INCLINE BASE HOLDER (S)	1	
29(1)	W284678	PS STOPPER BASE	1	
30(1)	W284627	PS POST STOPPER UNIT	1	
31(1)	W284673	INCLINE BASE HOLDER (T)	1	
32(1)	W284610	OPENER PIECE	1	
33(1)	W284676	TENSION SPRING ARM	1	
34(1)	W284644	P4 UPPER LIMITER	1	
35(1)	W284675	P4 SLIDE	1	
36(1)	W284676	P4 LOWER LIMITER	1	
40(1)	W284658KIT	INCLINE BASE (S) UNIT	1	OR W284682KIT
41(1)	W284615	ROLLER POST	2	
42(1)	W284677KIT	INCLINE BASE (T) UNIT	1	OR W284682KIT
43(1)	W284670	HEAD ARM MOUNT ANGLE (R) U.	1	
45(1)	W284683	CASSETTE POSITION FIXTURE	1	
46(1)	W284610	REVIEW ARM UNIT	1	
47(1)	W284636	PS ARM UNIT	1	
48(1)	W284694	TAKE UP TENSION REGULATOR	1	
49(1)	W284646	FINCH ARM UNIT	1	
50(1)	W284634	TENSION SPRING	1	
51(1)	W284639	TENSION ARM (L) UNIT	1	
52(1)	W284630	TENSION BAND UNIT	1	
60(1)	W284636	SUPPLY REEL TABLE UNIT	1	
61(1)	W284637	TAKE UP REEL TABLE UNIT	1	
62(1)	W284641	SAFETY PLATE	1	
63(1)	W284632	SUPPLY BRAKE ARM UNIT	1	
64(1)	W284633	TAKE UP BRAKE ARM UNIT	1	
65(1)	2S81370Y001E	POWER TRANSISTOR	1	
70(1)	W284677	CYLINDER UNIT	1	
71(1)	W284615	UPPER CYLINDER UNIT	1	
72(1)	W284617	CYLINDER SHIELD PLATE	1	
80(1)	W284680	RELEASE LEVER	1	
81(1)	W284633	RELEASE SPRING	1	
81(1)	W284673	SCREW	2	
82(1)	W284666	SCREW	5	
83(1)	W284646	SCREW	1	
84(1)	W284682	SCREW	1	
85(1)	W284610E	SCREW	1	
86(1)	W284652	SCREW	3	
87(1)	W284662	SCREW	2	
88(1)	W284688	SCREW	2	
89(1)	W284647	SCREW	2	
91(1)	W284642	SCREW	3	
91(1)	W284629	SCREW	2	
92(1)	W284612	NUT	3	
92(1)	W284613	NUT	1	
93(1)	W284628	WASHER	3	
94(1)	W284628	WASHER	1	


Note: 1. * Be sure to make your orders of replacement parts according to this list.
2. IMPORTANT SAFETY NOTICE:
Components identified with the mark (X) have the special characteristics for safety. When replacing any of these components, use only the same type.

Ref. No.	Part No.	Part Name & Description	Pcs	Remarks
100(1)	W284627	CASSETTE STATOR UNIT	1	
101(1)	W284661	PC HEAD	1	
103(1)	W284630	ROTOR STOPPER	1	
104(1)	W284627	OIL SEAL	2	
105(1)	W284640	HOUSING UNIT	1	
106(1)	W284619	CAPSTAN ROTOR UNIT	1	
107(1)	W284627	THROUST SCREW UNIT	1	
108(1)	W284613	WAVE CAM GEAR	1	
109(1)	W284656	SUPPLY REEL GEAR	1	
110(1)	W284657	TAKE UP REEL GEAR	1	
111(1)	W284658	WORM WHEEL GEAR	1	
112(1)	W284685	SUB CAM GEAR	1	
113(1)	W284635	TIMING BELT	1	
120(1)	W284666	WORM GEAR	1	
121(1)	W284627	LOADING MOTOR (L) UNIT	1	
123(1)	W284642	ROTOR BRACKET	1	
125(1)	W284625	ROTOR CONTROL LEVER	1	
127(1)	W284635	ROTOR G.	1	
128(1)	W284638	PS BRAKE BRG UNIT	1	
129(1)	W284679	TENSION ROLLER UNIT	1	
140(1)	W284638	ROTOR ARM UNIT	1	
141(1)	W284632	DIRECT LEVER UNIT	1	
142(1)	W284639	SUPPLY LOADING ARM UNIT	1	
143(1)	W284630	TAKE UP LOADING ARM UNIT	1	
144(1)	W284637	MAIN LEVER UNIT	1	
145(1)	W284649	CENTRE CLATCH	1	
1102(1)	W28468F	SCREW	1	
1103(1)	W28466F	SCREW	3	
1104(1)	W284653	SCREW	4	
1105(1)	W284654	SCREW	1	
1106(1)	W284642	SCREW	1	
1101(1)	W284628	WASHER	4	

② CHASSIS PARTS SECTION (2)

SECTION 5

3 CASING PARTS SECTION




Note:1.* Be sure to make your orders of replacement parts according to this list.
2. IMPORTANT SAFETY NOTICE
Components identified with the mark (!) have the special characteristics for safety. When replacing any of these components, use only the same type.

Ref. No.	Part No.	Part Name & Description	Pcs	Remarks
200(3)	WQM1105	TOP PANEL	1	
201(3)	VYF6125	FRONT PANEL UNIT	1	NV-HD650A
201(3)	VYF6126	FRONT PANEL UNIT	1	NV-HD650EA
202(3)	WKF226C	BLINDER PANEL	1	
203(3)	WMB2521	BLINDER SPRING	1	
204(3)	WKA0176	LEG	2	
205(3)	WQ0555C	DOOR LOCK PIECE	2	
206(3)	WKF2526	FRONT DOOR (R)	1	
207(3)	VYF2184	FRONT DOOR (L) UNIT	1	
208(3)	WKA0404	BOTTOM PLATE	1	
209(3)	WJF1134	PACK HOLDER	1	
210(3)	WKA0122	FOOT	2	
211(3)	WKA065	DOOR SPRING	1	
212(3)	WKB077C	DOOR DIAL	1	
213(3)	WCB0772	SHUTTLE RING	1	
214(3)	WKC1062	JACK EARTH SPRING	1	
215(3)	WAL0875	FLAT CARD CABLE (2CP)	1	P501-P502
216(3)	WAL3205160BD	FLAT CARD CABLE (3CP)	1	P6001-P7561
217(3)	WJH079C	ANTENNA JACK PLATE	1	NV-HD650A
217(3)	WJH0799	ANTENNA JACK PLATE	1	NV-HD650EA
218(3)	WAL0906	FLAT CARD CABLE (1CP)	1	P4001-P7562
219(3)	WAL0906	FLAT CARD CABLE (8P)	1	P3901-P6501
B201(3)	XTW3-1CTF2	SCREW	4	
B202(3)	WHD0055	SCREW	3	
B203(3)	WHD0772	SCREW	4	
B204(3)	WHD0773	SCREW	1	
B205(3)	WHD0168	SCREW	3	
B206(3)	WHD0874	SCREW	1	
B207(3)	XTV26-HPR	SCREW	3	
B208(3)	XTV26-10F	SCREW	1	
B210(3)	XTN2-8C	SCREW	1	


Note:1.* Be sure to make your orders of replacement parts according to this list.
2. IMPORTANT SAFETY NOTICE
Components identified with the mark (!) have the special characteristics for safety. When replacing any of these components, use only the same type.

Ref. No.	Part No.	Part Name & Description	Pcs	Remarks
300(4)	VYI5984	OPERATING INSTRUCTIONS (ENGLISH)	1 (!)	
301(4)	VQ01638	REMOTE CONTROLLER	1	
304(4)	VIA0376	DIN RF CABLE	1	
305(4)	VIA0754	AC CORD	1 (!)	
306(4)	VIA0231	AUDIO CABLE	1	
310(4)	WPK1726	ACCESSORIES PACKING	1	
311(4)	WPK034	CUSHION (R)	1	
312(4)	WPK035	CUSHION (L)	1	
315(4)	WPK0367	PACKING	1	NV-HD650A
315(4)	WPK0368	PACKING	1	NV-HD650EA
		SERVICE FIXTURES & TOOLS		
	VJH12583P	VHS ALIGNMENT TAPE (PAL)	1	
	WPK0335	REPAIRING RING REMOVER (3mm/4mm)	1	
	VK0329	POST ADJUSTMENT SCREWDRIVER	1	
	VK0326	HEX WRENCH SET	1	
	VK0132	BACK TENSION METER	1	
	VK027	HEAL CLEANING STICK	1	
	VK1024	MULTI-PURPOSE GREASE	1	
	VK0041	UPPER CYLINDER REMOVER	1	
	VK0680	WHITE GREASE	1	
	VK0051	CENTRE FIXING TOOL	1	
	VK0330	FINE ADJUSTMENT GEAR DRIVER	1	
	VK1139	20P EXTENSION CABLE	1	
	VK0678	10P EXTENSION CABLE	2	
	VK0917	11P EXTENSION CABLE	1	

④ PACKING PARTS SECTION



5 REMOTE CONTROLLER UNIT



Note:1.* Be sure to make your orders of replacement parts according to this list.

2. IMPORTANT SAFETY NOTICE

2. IMPORTANT SAFETY NOTICE
Components identified with the mark (!) have the special characteristics for safety. When replacing any of these components, use only the same type.

Ref.No.	Part No.	Part Name & Description	Pcs	Remarks
400(5)	VYK6261	TOP COVER UNIT	1	
401(5)	VYK5446	BOTTOM COVER UNIT	1	
402(5)	VYK6388	DOOR PANEL UNIT	1	
403(5)	VKF2115	BATTERY COVER	1	
404(5)	VKW1802	IR WINDOW	1	
406(5)	VSP0849	RUBBER CONTACT	1	
409(5)	-----	REMOTE CONTROLLER C.B.A.	1	THE C.B.A. IS NOT
				SUPPLIED AS SPARE
				PART.
B401(5)	XTB2+6G	SCREW	1	
B402(5)	XTB2+8GFZ	SCREW	1	

[illegible]

5-2. ELECTRICAL REPLACEMENT PARTS LIST

Note: 1. Be sure to make your orders of replacement parts according to this list.
 2. IMPORTANT SAFETY NOTICE : Components identified with the mark (!) have the special characteristics for safety. When replacing any of these components, use only the same type.
 3. Unless otherwise specified, All resistors are in OHMS, K=1,000 OHMS. All capacitors are in MICRO-FARADS(uf), P=uuF.
 4. The P.C. Board units marked with "■" show below the main assembled parts.
 5. The marking (RTL) indicates the retention time is limited for this item. After the discontinuation of this assembly in production, it will no longer be available.

Ref.No.	Part No.	Part Name & Description	Pcs	Remarks
	VEPO6980P	MAIN C.B.A. (Page:5-8)	1 (RTL) <1> NV-HD650A INCLUDING THE	
			LUMINANCE & CHROMINANCE PACK C.B.A. (VEPO3D27G), HI-FI AUDIO PACK C.B.A. (VEPO4447PQ), DECODER PACK C.B.A. (VEPO7784A), TV DEMODULATOR PACK C.B.A. (VEPO7801S).	
	VEPO3D27G	LUMINANCE & CHROMINANCE PACK C.B.A.	1 (RTL) INCLUDING THE S-VHS PB PACK C.B.A. (VEPO3A03A), INCLUDED IN MAIN C.B.A. (VEPO6980P).	
	VEPO3A03A	S-VHS PB PACK C.B.A.	1 (RTL) INCLUDED IN LUMINANCE & CHROMINANCE PACK C.B.A. (VEPO3D27G).	
	VEPO4447PQ	Hi-Fi AUDIO PACK C.B.A.	1 (RTL) INCLUDED IN MAIN C.B.A. (VEPO6980P).	
	VEPO7784A	DECODER PACK C.B.A.	1 (RTL) INCLUDED IN MAIN C.B.A. (VEPO6980P).	
	VEPO7801S	TV DEMODULATOR PACK C.B.A.	1 (RTL) INCLUDED IN MAIN C.B.A. (VEPO6980P).	
	VEPO6980Q	MAIN C.B.A. (Page:5-15)	1 (RTL) <1> NV-HD650EA INCLUDING THE LUMINANCE & CHROMINANCE PACK C.B.A. (VEPO3D27G), HI-FI AUDIO PACK C.B.A. (VEPO4447PP), NICAM DECODER PACK C.B.A. (VEPO7787E), TV DEMODULATOR PACK C.B.A. (VEPO7801S).	
	VEPO3D27G	LUMINANCE & CHROMINANCE PACK C.B.A.	1 (RTL) INCLUDING THE S-VHS PB PACK C.B.A. (VEPO3A03A), INCLUDED IN MAIN C.B.A. (VEPO6980Q).	
	VEPO3A03A	S-VHS PB PACK C.B.A.	1 (RTL) INCLUDED IN LUMINANCE & CHROMINANCE PACK C.B.A. (VEPO3D27G).	
	VEPO4447PP	Hi-Fi AUDIO PACK C.B.A.	1 (RTL) INCLUDED IN MAIN	

Ref.No.	Part No.	Part Name & Description	Pcs	Remarks
				C.B.A. (VEPO6980Q).
	VEPO7787E	NICAM DECODER PACK C.B.A.	1 (RTL) INCLUDED IN MAIN C.B.A. (VEPO6980Q).	
	VEPO7801S	TV DEMODULATOR PACK C.B.A.	1 (RTL) INCLUDED IN MAIN C.B.A. (VEPO6980Q).	
	VEPO3B27F	INPUT/OUTPUT C.B.A. (Page:5-22)	1 (RTL) NV-HD650A	
	VEPO3B27A	INPUT/OUTPUT C.B.A. (Page:5-23)	1 (RTL) NV-HD650EA	
	VEPO4469N	MOTOR DRIVE C.B.A. (Page:5-23)	1 (RTL)	
	VEPO5227A	HEAD AMP C.B.A. (Page:5-24)	1 (RTL)	
	VEPO7773D	TIMER C.B.A. (Page:5-25)	1 (RTL) NV-HD650A	
	VEPO7773E	TIMER C.B.A. (Page:5-26)	1 (RTL) NV-HD650EA	
	VEPO6995C	OPERATION C.B.A. (Page:5-27)	1 (RTL)	
	VEPO0V29A	MAIN INTERFACE C.B.A. (Page:5-27)	1 (RTL)	
	VEPO0V88A	S-TAB C.B.A. (Page:5-27)	1 (RTL)	
	VEPO129	CYLINDER DRIVE C.B.A. (Page:5-27)	1 (RTL)	
	-----	MOTOR C.B.A. (Page:5-27)	1 (RTL)	
	ENG47228G	TUNER	1 <1> NV-HD650A	
	ENG47229G	TUNER	1 <1> NV-HD650EA	
F1101	XBA2C16TBO	FUSE	1 <1>	
	■ VEPO6980P	MAIN C.B.A.		(RTL) <1> NV-HD650A
C301	ECUM1H101JCN	C.CAPACITOR CH 50V 100P	1	
C302	ECUM1H330JCN	C.CAPACITOR CH 50V 33P	1	
C303	ECUM1H820JCN	C.CAPACITOR CH 50V 82P	1	
C304	ECUM1H120JCN	C.CAPACITOR CH 50V 12P	1	
C305	ECUM1H060DCN	C.CAPACITOR CH 50V / 6P	1	
C306	ECUM1H100DCN	C.CAPACITOR CH 50V 10P	1	
C307	ECUM1H1032FN	C.CAPACITOR CH 50V 0.01U	1	
C308	ECUM1H1042FN	C.CAPACITOR CH 50V 0.1U	1	
C309	ECEA1HKA0R1	E.CAPACITOR 50V 0.1U	1	
C310-12	ECUM1H1042FN	C.CAPACITOR CH 50V 0.1U	3	
C313	ECEAOJKA101	E.CAPACITOR 6.3V 100U	1	
C314	ECUM1H103KBN	C.CAPACITOR CH 50V 0.01U	1	
C315	ECUM1H472KBN	C.CAPACITOR CH 50V 4700P	1	
C316	ECUM1H1032FN	C.CAPACITOR CH 50V 0.01U	1	
C317	ECUM1H080DCN	C.CAPACITOR CH 50V 8P	1	
C318,19	ECUM1H101JCN	C.CAPACITOR CH 50V 100P	2	
C321	ECUM1H270JCN	C.CAPACITOR CH 50V 27P	1	
C322	ECEAOJKA101	E.CAPACITOR 6.3V 100U	1	
C323	ECUM1H1042FN	C.CAPACITOR CH 50V 0.1U	1	

Ref.No.	Part No.	Part Name & Description	Pcs	Remarks	Ref.No.	Part No.	Part Name & Description	Pcs	Remarks
C324	ECUM1H1032FN	C. CAPACITOR CH 50V 0.01U	1		C1005	ECEAOJKA220	E. CAPACITOR 6.3V 220U	1	
C325	ECUM1H223KBN	C. CAPACITOR CH 50V 0.022U	1		C1006	ECUM1H1032FN	C. CAPACITOR CH 50V 0.01U	1	
C326	ECEA1HKA3R3	E. CAPACITOR 50V 3.3U	1		C1007	ECEAOJKA101	E. CAPACITOR 6.3V 100U	1	
C327	ECUM1E823KBN	C. CAPACITOR CH 25V 0.082U	1		C1008	ECUM1H1032FN	C. CAPACITOR CH 50V 0.01U	1	
C328	ECEA1HKN010	E. CAPACITOR 50V 1U	1		C1009	ECEAOJKA220	E. CAPACITOR 6.3V 22U	1	
C329	ECEAOJKA470	E. CAPACITOR 6.3V 47U	1		C1010	ECEAOJKA101	E. CAPACITOR 6.3V 100U	1	
C331,32	ECEA1CKA100	E. CAPACITOR 16V 10U	2		C1011	ECUM1H1032FN	C. CAPACITOR CH 50V 0.01U	1	
C333	ECEA1HKN010	E. CAPACITOR 50V 1U	1		C1012	ECEAOJKA101	E. CAPACITOR 6.3V 100U	1	
C334	ECUM1H821JCN	C. CAPACITOR CH 50V 820P	1		C1013	ECEAOJKA220	E. CAPACITOR 6.3V 22U	1	
C335	ECUM1H221JCN	C. CAPACITOR CH 50V 220P	1		C1101	ECRMS471MBH	C. CAPACITOR 470P	1	<1>
C336	ECUM1H220JCN	C. CAPACITOR CH 50V 22P	1		C1104	ECRMS471MBH	C. CAPACITOR 470P	1	<1>
C340	ECUM1H330JCN	C. CAPACITOR CH 50V 33P	1		C1107	ECRMS102MEH	C. CAPACITOR 1000P	1	<1>
C341	ECUM1H560JCN	C. CAPACITOR CH 50V 56P	1		C1110	ECQU2A683MN	P. CAPACITOR 250V 0.068U	1	<1>
C342	ECUM1H1032FN	C. CAPACITOR CH 50V 0.01U	1		C1111	ECQU2A154MV	P. CAPACITOR 100V 0.15U	1	<1>
C343	ECUM1H103KBN	C. CAPACITOR CH 50V 0.01U	1		C1112	ECEC2GG680	E. CAPACITOR 400V 68U	1	
C344	ECUM1E104KBN	C. CAPACITOR CH 25V 0.1U	1		C1113	ECRD2H103FU	C. CAPACITOR 500V 0.01U	1	
C345	ECEA1HKA2R2	E. CAPACITOR 50V 2.2U	1		C1114	ECDD3A470KGE	C. CAPACITOR 1kV 47P	1	
C347	ECUM1E154KBN	C. CAPACITOR CH 25V 0.15U	1		C1115	ECA1VXLV470	E. CAPACITOR 35V 47U	1	
C348	ECUM1H332KBN	C. CAPACITOR CH 50V 3300P	1		C1116	ECA1CXLV470	E. CAPACITOR 16V 47U	1	
C349	ECEA1HKA010	E. CAPACITOR 50V 1U	1		C1117	ECQV1H104JM	P. CAPACITOR 50V 0.1U	1	
C350	ECUM1H333KBN	C. CAPACITOR CH 50V 0.033U	1		C1118	ECUM1H102KBN	C. CAPACITOR CH 50V 1000P	1	
C351	ECUM1H102KBN	C. CAPACITOR CH 50V 1000P	1		C1120	ECQB1H103JF	P. CAPACITOR 50V 0.01U	1	
C352	ECUM1H100DCN	C. CAPACITOR CH 50V 10P	1		C1121	ECUM1H391KBN	C. CAPACITOR CH 50V 390P	1	
C353	ECUM1H1032FN	C. CAPACITOR CH 50V 0.01U	1		C1131	EEUFA1E681	E. CAPACITOR 25V 680P	1	
C354	ECUM1H390JCN	C. CAPACITOR CH 50V 39P	1		C1132	ECEA1EU221	E. CAPACITOR 25V 220U	1	
C355	ECUM1H1042FN	C. CAPACITOR CH 50V 0.1U	1		C1133	ECRD2H101KB	C. CAPACITOR 500V 100P	1	
C356	ECEAOJKA221	E. CAPACITOR 6.3V 220U	1		C1134	EEUFA1A122	E. CAPACITOR 10V 1200P	1	
C357	ECUM1H1042FN	C. CAPACITOR CH 50V 0.1U	1		C1135	ECEA1AU331	E. CAPACITOR 10V 330U	1	
C358,59	ECUM1E104KBN	C. CAPACITOR CH 25V 0.1U	2		C1136	ECRD2H101KB	C. CAPACITOR 500V 100P	1	
C360	ECUM1H223KBN	C. CAPACITOR CH 50V 0.022U	1		C1137	ECA1HFQ560	E. CAPACITOR 50V 56U	1	
C361	ECUM1H1032FN	C. CAPACITOR CH 50V 0.01U	1		C1138	ECUM1H1032FN	C. CAPACITOR CH 50V 0.01U	1	
C362	ECUM1H1042FN	C. CAPACITOR CH 50V 0.1U	1		C1140	ECA1VFQ560	E. CAPACITOR 35V 56U	1	
C363	ECEAOJKA221	E. CAPACITOR 6.3V 220U	1		C1141	ECUM1H1032FN	C. CAPACITOR CH 50V 0.01U	1	
C364	ECUM1H1032FN	C. CAPACITOR CH 50V 0.01U	1		C1142	ECRD2H101KB	C. CAPACITOR 500V 100P	1	
C365	ECUM1H220JCN	C. CAPACITOR CH 50V 22P	1		C1143	ECAOJFQ221	E. CAPACITOR 6.3V 220U	1	
C366	ECUM1H270JCN	C. CAPACITOR CH 50V 27P	1		C1144,45	ECUM1H1032FN	C. CAPACITOR CH 50V 0.01U	2	
C367-72	ECUM1H1032FN	C. CAPACITOR CH 50V 0.01U	6		C1147	ECUM1H102KBN	C. CAPACITOR CH 50V 1000P	1	
C373	ECEA1HKA3R3	E. CAPACITOR 50V 3.3U	1		C1148	ECQV1H104JM	P. CAPACITOR 50V 0.1U	1	
C374	ECEA1EKN4R7	E. CAPACITOR 25V 4.7U	1		C1149	ECUM1H1032FN	C. CAPACITOR CH 50V 0.01U	1	
C375	ECEAOJKA220	E. CAPACITOR 6.3V 220U	1		C1150	ECA1GM101	E. CAPACITOR 16V 100U	1	
C376	ECUM1H181JCN	C. CAPACITOR CH 50V 180P	1		C1151	ECEA1EGE470	E. CAPACITOR 25V 47U	1	
C378	ECUM1H1042FN	C. CAPACITOR CH 50V 0.1U	1		C1153	ECQB1H103JF	P. CAPACITOR 50V 0.01U	1	
C379	ECEAOJKA221	E. CAPACITOR 6.3V 220U	1		C1155	ECRKF1H1032F	C. CAPACITOR 50V 0.01U	1	
C380	ECEAOJKA470	E. CAPACITOR 6.3V 47U	1		C2004	ECEAOJKA470	E. CAPACITOR 6.3V 47U	1	
C381	ECUM1H270JCN	C. CAPACITOR CH 50V 27P	1		C2005	ECQV1H683JM	P. CAPACITOR 50V 0.068U	1	
C383	ECUM1H1042FN	C. CAPACITOR CH 50V 0.1U	1		C2006	ECEA1CKA100	E. CAPACITOR 16V 10U	1	
C386	ECUM1H561JCN	C. CAPACITOR CH 50V 560P	1		C2007	ECEAOJKA221	E. CAPACITOR 6.3V 220U	1	
C387	ECUM1H151JCN	C. CAPACITOR CH 50V 150P	1		C2008	ECUM1H222KBN	C. CAPACITOR CH 50V 2200P	1	
C388	ECUM1H331JCN	C. CAPACITOR CH 50V 330P	1		C2009	ECUM1H471JCN	C. CAPACITOR CH 50V 470P	1	
C391	ECEA1HKN010	E. CAPACITOR 50V 1U	1		C2010,11	ECEA1EKN3R3	E. CAPACITOR 25V 3.3U	2	
C392	ECUM1H681KBN	C. CAPACITOR CH 50V 680P	1		C2012	ECEA1EKA4R7	E. CAPACITOR 25V 4.7U	1	
C393	ECUM1H470JCN	C. CAPACITOR CH 50V 47P	1		C2013	ECEA1AKS221	E. CAPACITOR 10V 220U	1	
C394	ECUM1H1042FN	C. CAPACITOR CH 50V 0.1U	1		C2014	ECUM1H1032FN	C. CAPACITOR CH 50V 0.01U	1	
C395	ECEA1CKA100	E. CAPACITOR 16V 10U	1		C2015	ECUM1H472KBN	C. CAPACITOR CH 50V 4700P	1	
C396	ECUM1H121JCN	C. CAPACITOR CH 50V 120P	1		C2016	ECUM1H392KBN	C. CAPACITOR CH 50V 3900P	1	
C0701,02	ECUX1H1032FV	C. CAPACITOR CH 50V 0.01U	2		C2019	ECUM1H222KBN	C. CAPACITOR CH 50V 2200P	1	
C0704	ECUX1H331JCV	C. CAPACITOR CH 50V 330P	1		C2021	ECUM1H1042FN	C. CAPACITOR CH 50V 0.1U	1	
C0706	ECEA1HKA0R1	E. CAPACITOR 50V 0.1U	1		C2022	ECUM1H223KBN	C. CAPACITOR CH 50V 0.022U	1	
C0707,08	ECUX1H1032FV	C. CAPACITOR CH 50V 0.01U	2		C2024,25	ECUM1C1052FN	C. CAPACITOR CH 16V 1U	2	
C0709	ECUX1H120JCV	C. CAPACITOR CH 50V 12P	1		C2030	ECUM1H102KBN	C. CAPACITOR CH 50V 1000P	1	
C0710	ECUX1H470JCV	C. CAPACITOR CH 50V 47P	1		C2032-34	ECUM1H102KBN	C. CAPACITOR CH 50V 1000P	3	
C0711	ECEA1CKA100	E. CAPACITOR 16V 10U	1		C3001	ECUM1H1042FN	C. CAPACITOR CH 50V 0.1U	1	
C0712	ECUX1H1032FV	C. CAPACITOR CH 50V 0.01U	1		C3002,03	ECUM1H1032FN	C. CAPACITOR CH 50V 0.01U	2	
C0714	ECQB1H473JF	P. CAPACITOR 50V 0.047U	1		C3004	ECEA1CKA100	E. CAPACITOR 16V 10U	1	
C0715	ECUM1H1032FN	C. CAPACITOR CH 50V 0.01U	1		C3006	ECUM1H1032FN	C. CAPACITOR CH 50V 0.01U	1	
C0716	ECEA1CKA100	E. CAPACITOR 16V 10U	1		C3007	ECEAOJKA221	E. CAPACITOR 6.3V 220U	1	
C0717	ECUX1H270JCV	C. CAPACITOR CH 50V 27P	1		C3008	ECUM1H102KBN	C. CAPACITOR CH 50V 1000P	1	
C0718	ECEA1HKA47	E. CAPACITOR 50V 0.47U	1		C3009	ECUM1H1032FN	C. CAPACITOR CH 50V 0.01U	1	
C0719	ECUX1H220JCV	C. CAPACITOR CH 50V 22P	1		C3010	ECUM1C1052FN	C. CAPACITOR CH 16V 1U	1	
C0720	ECUX1H1032FV	C. CAPACITOR CH 50V 0.01U	1		C3012	ECEAOJKA330	E. CAPACITOR 6.3V 33U	1	
C0723	ECEA1HKA0R1	E. CAPACITOR 50V 0.1U	1		C3013,14	ECUM1H102JCN	C. CAPACITOR CH 50V 1000P	2	
C0726	ECUX1H1032FV	C. CAPACITOR CH 50V 0.01U	1		C3017,18	ECUM1H1032FN	C. CAPACITOR CH 50V 0.01U	2	
C0730	ECUX1H1032FV	C. CAPACITOR CH 50V 0.01U	1		C3019	ECUM1H620JCN	C. CAPACITOR CH 50V 62P	1	
C0732	ECUX1H1032FV	C. CAPACITOR CH 50V 0.01U	1		C3027	ECEAOJKA470	E. CAPACITOR 6.3V 47U	1	
C1004	ECUM1H1032FN	C. CAPACITOR CH 50V 0.01U	1		C3028	ECUM1H151JCN	C. CAPACITOR CH 50V 150P	1	

Ref.No.	Part No.	Part Name & Description	Pcs	Remarks	Ref.No.	Part No.	Part Name & Description	Pcs	Remarks
PK7302	VJR0777B005W	CONNECTOR (MALE) 5P	1		QR316	MUN2213	TRANSISTOR-RESISTOR	1	
					QR320	XN1212	TRANSISTOR-RESISTOR	1	
					QR322	MUN2213	TRANSISTOR-RESISTOR	1	
PP0701	VJP3589A004B	CONNECTOR (MALE) 4P	1		QR1101	UN2114	TRANSISTOR-RESISTOR	1	
PP2001	VJP3042A018W	CONNECTOR (MALE) 18P	1		QR3001	MUN2111	TRANSISTOR-RESISTOR	1	
PP2002	VJP3042A011W	CONNECTOR (MALE) 11P	1		QR3002,03	DTC363EK	TRANSISTOR-RESISTOR	2	
PP3901	VJP3042G020W	CONNECTOR (MALE) 20P	1		QR3005	MUN2213	TRANSISTOR-RESISTOR	1	
PP3902	VJP3042A018W	CONNECTOR (MALE) 18P	1		QR3007	MUN2111	TRANSISTOR-RESISTOR	1	
PP6005	VJP3043A003W	CONNECTOR (MALE) 3P	1		QR3008-18	MUN2212	TRANSISTOR	11	
					QR3019	XN4213	TRANSISTOR-RESISTOR	1	
					QR3020	MUN2212	TRANSISTOR	1	
PR1101	VSF0015A10	IC PROTECTOR	1	<1>	QR3021	MUN2211	TRANSISTOR-RESISTOR	1	
					QR3023	MUN2213	TRANSISTOR-RESISTOR	1	
					QR3026,27	MUN2113	TRANSISTOR-RESISTOR	2	
PS301	VJR0776B009W	CONNECTOR (MALE) 9P	1		QR4001	MUN2212	TRANSISTOR	1	
PS302	VJR0776B015W	CONNECTOR (MALE) 15P	1		QR4002,03	MUN2213	TRANSISTOR-RESISTOR	2	
PS303	VJR0776B008W	CONNECTOR (MALE) 8P	1		QR4005	MUN2213	TRANSISTOR-RESISTOR	1	
PS304	VJR0776B003W	CONNECTOR (MALE) 3P	1		QR4508,09	UN5113	TRANSISTOR-RESISTOR	2	
					QR4510	UN5212	TRANSISTOR-RESISTOR	1	
					QR4602	UN5111	TRANSISTOR-RESISTOR	1	
Q301,02	MSD601	TRANSISTOR	2		QR4603	UN5213	TRANSISTOR-RESISTOR	1	
Q303,04	MSC2295	TRANSISTOR	2		QR6001	XN1211	TRANSISTOR-RESISTOR	1	
Q305	MSB709	TRANSISTOR	1		QR6002	XN1213	TRANSISTOR-TRANSISTOR	1	
Q0701	MSD601-S	TRANSISTOR	1		QR6004	UN2114	TRANSISTOR-RESISTOR	1	
Q0702	MSB709	TRANSISTOR	1		QR6005	MUN2113	TRANSISTOR-RESISTOR	1	
Q1002,03	2SD1996-S	TRANSISTOR	2		QR6009	MUN2112	TRANSISTOR-RESISTOR	1	
Q1004	2SD1996	TRANSISTOR	1		QR6010	XN1211	TRANSISTOR-RESISTOR	1	
Q1006,07	MSD602	TRANSISTOR	2		QR6012	MUN2211	TRANSISTOR-RESISTOR	1	
Q1101	STP3N60FI-M	IC	1		QR7304	MUN2213	TRANSISTOR-RESISTOR	1	
Q1102	2SD601A	TRANSISTOR	1		QR7601	MUN2213	TRANSISTOR-RESISTOR	1	
Q1111	MOC8104FR2	TRANSISTOR	1	<1>					
Q3001	XN4501	TRANSISTOR-RESISTOR	1						
Q3002	MSB709	TRANSISTOR	1		R301,02	ERJ6GMYJ102	M.RESISTOR CH 1/10W 1K	2	
Q3004	MSD601	TRANSISTOR	1		R303	ERJ6GMYJ272	M.RESISTOR CH 1/10W 2.7K	1	
Q3005	MSC2295	TRANSISTOR	1		R304	ERJ6GMYJ182	M.RESISTOR CH 1/10W 1.8K	1	
Q3006	MSB709	TRANSISTOR	1		R305	ERJ6GMYJ681	M.RESISTOR CH 1/10W 680	1	
Q3007	MSC2295	TRANSISTOR	1		R306	ERJ6GMYJ821	M.RESISTOR CH 1/10W 820	1	
Q3008	2SD1996	TRANSISTOR	1		R307	ERJ6GMYK225	M.RESISTOR CH 1/10W 2.2M	1	
Q3009	2SB1322	TRANSISTOR	1		R308	ERJ6GMYJ102	M.RESISTOR CH 1/10W 1K	1	
Q3010	MSB709	TRANSISTOR	1		R310	ERJ6GMYJ681	M.RESISTOR CH 1/10W 680	1	
Q3011	2SD601A	TRANSISTOR	1		R311	ERJ6GMYJ102	M.RESISTOR CH 1/10W 1K	1	
Q3012	2SB1322	TRANSISTOR	1		R312	ERJ6GMYJ122	M.RESISTOR CH 1/10W 1.2K	1	
Q3013	MSB709	TRANSISTOR	1		R313,14	ERJ6GMYJ103	M.RESISTOR CH 1/10W 10K	2	
Q3014	MSD601	TRANSISTOR	1		R315	ERJ6GMYJ684	M.RESISTOR CH 1/10W 680K	1	
Q3016,17	MSC2295	TRANSISTOR	2		R316	ERJ6GMYJ472	M.RESISTOR CH 1/10W 4.7K	1	
Q3018-20	MSD601	TRANSISTOR	3		R317	ERJ6GMYG221	M.RESISTOR CH 1/10W 220	1	
Q3021	MSB709	TRANSISTOR	1		R318	ERJ6GMYJ102	M.RESISTOR CH 1/10W 1K	1	
Q3023	MSC2295	TRANSISTOR	1		R319	ERJ6GMYJ222	M.RESISTOR CH 1/10W 2.2K	1	
Q4003,04	MSD601	TRANSISTOR	2		R320	ERJ6GMYJ682	M.RESISTOR CH 1/10W 6.8K	1	
Q4005	MSD1328	TRANSISTOR	1		R321	ERJ6GMZ0R00	M.RESISTOR CH 1/10W 0	1	
Q4501	2SD1991A-R	TRANSISTOR	1		R324	ERJ6GMYJ472	M.RESISTOR CH 1/10W 4.7K	1	
Q4551	2SB1320A-R	TRANSISTOR	1		R325	ERJ6GMYJ562	M.RESISTOR CH 1/10W 5.6K	1	
Q4552	2SD1819A	TRANSISTOR	1		R326	ERJ6GMYJ122	M.RESISTOR CH 1/10W 1.2K	1	
Q4601	2SD1819A	TRANSISTOR	1		R327	ERJ6GMYJ473	M.RESISTOR CH 1/10W 47K	1	
Q5001	MSB709	TRANSISTOR	1		R328	ERJ6GMYJ152	M.RESISTOR CH 1/10W 1.5K	1	
Q5002	MSD601	TRANSISTOR	1		R329	ERJ6GMYG471	M.RESISTOR CH 1/10W 470	1	
Q5003	2SA1022	TRANSISTOR	1		R330	ERJ6GMYJ333	M.RESISTOR CH 1/10W 33K	1	
Q5005	XN1501	TRANSISTOR-TRANSISTOR	1		R331	ERJ6GMYJ473	M.RESISTOR CH 1/10W 47K	1	
Q5006	MSB709	TRANSISTOR	1		R332	ERJ6GMYJ103	M.RESISTOR CH 1/10W 10K	1	
Q5007	MSC2295	TRANSISTOR	1		R333	ERJ6GMYJ392	M.RESISTOR CH 1/10W 3.9K	1	
Q5008	MSB709	TRANSISTOR	1		R334	ERJ6GMYJ103	M.RESISTOR CH 1/10W 10K	1	
Q5009-13	MSC2295	TRANSISTOR	5		R336	ERJ6GMYJ222	M.RESISTOR CH 1/10W 2.2K	1	
Q6001	MSB709	TRANSISTOR	1		R337	ERJ6GMYG201	M.RESISTOR CH 1/10W 200	1	
Q6002	FW205L-NC-VT	PHOTO TRANSISTOR	1		R339	ERJ6GMYJ222	M.RESISTOR CH 1/10W 2.2K	1	
Q7301	MSD601-S	TRANSISTOR	1		R340	ERJ6GMYJ103	M.RESISTOR CH 1/10W 10K	1	
					R341	ERJ6GMYJ101	M.RESISTOR CH 1/10W 100	1	
					R342,43	ERJ6GMYJ102	M.RESISTOR CH 1/10W 1K	2	
QR302	MUN2212	TRANSISTOR	1		R344	ERJ6GMYJ223	M.RESISTOR CH 1/10W 22K	1	
QR303	MUN2213	TRANSISTOR-RESISTOR	1		R345	ERJ6GMYJ102	M.RESISTOR CH 1/10W 1K	1	
QR305	MUN2212	TRANSISTOR	1		R346	ERJ6GMYJ473	M.RESISTOR CH 1/10W 47K	1	
QR306	MUN2213	TRANSISTOR-RESISTOR	1		R347,48	ERJ6GMYJ102	M.RESISTOR CH 1/10W 1K	2	
QR308	IMH5	TRANSISTOR-RESISTOR	1		R349	ERJ6GMYJ272	M.RESISTOR CH 1/10W 2.7K	1	
QR310	MUN2213	TRANSISTOR-RESISTOR	1		R350	ERJ6GMYK225	M.RESISTOR CH 1/10W 2.2M	1	
QR311	MUN2111	TRANSISTOR-RESISTOR	1		R351	ERJ6GMZ0R00	M.RESISTOR CH 1/10W 0	1	
QR312	MUN2113	TRANSISTOR-RESISTOR	1		R353	ERJ6GMZ0R00	M.RESISTOR CH 1/10W 0	1	

Ref.No.	Part No.	Part Name & Description	Pcs	Remarks	Ref.No.	Part No.	Part Name & Description	Pcs	Remarks
R358	ERJ6GMYJ103	M.RESISTOR CH 1/10W 10K	1		R2008	ERJ6GMYJ222	M.RESISTOR CH 1/10W 2.2K	1	
R359	ERJ6GMYJ124	M.RESISTOR CH 1/10W 120K	1		R2009	ERDS2FJ7R5	C.RESISTOR 1/4W 7.5	1	
R361	ERJ6GMYJ223	M.RESISTOR CH 1/10W 22K	1		R2010	ERJ6GMYJ222	M.RESISTOR CH 1/10W 2.2K	1	
R362	ERJ6GMZOR00	M.RESISTOR CH 1/10W 0	1		R2011	ERJ6GMYJ102	M.RESISTOR CH 1/10W 1K	1	
R363	ERJ6GMYJ123	M.RESISTOR CH 1/10W 12K	1		R2012	ERDS2FJ6R8	C.RESISTOR 1/4W 6.8	1	
R364	ERJ6GMYJ682	M.RESISTOR CH 1/10W 6.8K	1		R2013	ERJ6GMYJ103	M.RESISTOR CH 1/10W 10K	1	
R367	ERJ6GMYJ103	M.RESISTOR CH 1/10W 10K	1		R2014	ERJ6GMYJ221	M.RESISTOR CH 1/10W 220	1	
R369	ERJ6GMYJ393	M.RESISTOR CH 1/10W 39K	1		R2015	ERJ6GMYJ471	M.RESISTOR CH 1/10W 470	1	
R371	ERJ6GMZOR00	M.RESISTOR CH 1/10W 0	1		R2016	ERDS2FJ6R8	C.RESISTOR 1/4W 6.8	1	
R372	ERJ6GMYJ103	M.RESISTOR CH 1/10W 10K	1		R2017	ERJ6GMYJ103	M.RESISTOR CH 1/10W 10K	1	
R373	ERJ6GMYJ334	M.RESISTOR CH 1/10W 330K	1		R2023, 24	ERJ6GMYJ223	M.RESISTOR CH 1/10W 22K	2	
R375	ERJ6GMYJ682	M.RESISTOR CH 1/10W 6.8K	1		R2026, 27	ERJ6GMYJ223	M.RESISTOR CH 1/10W 22K	2	
R376	ERJ6GMYJ103	M.RESISTOR CH 1/10W 10K	1		R2028	ERJ6GMYJ272	M.RESISTOR CH 1/10W 2.7K	1	
R377	ERJ6GMYJ681	M.RESISTOR CH 1/10W 680	1		R2040	ERJ6GMYJ222	M.RESISTOR CH 1/10W 2.2K	1	
R378	ERJ6GMYJ102	M.RESISTOR CH 1/10W 1K	1		R2041	ERJ6GMYJ562	M.RESISTOR CH 1/10W 5.6K	1	
R0702	ERJ3GEYJ272	M.RESISTOR CH 1/16W 2.7K	1		R2042	ERJ6GMYJ103	M.RESISTOR CH 1/10W 10K	1	
R0704	ERJ3GEYJ222	M.RESISTOR CH 1/16W 2.2K	1		R2045	ERJ6GMZOR00	M.RESISTOR CH 1/10W 0	1	
R0705	ERJ3GEYJ562	M.RESISTOR CH 1/16W 5.6K	1		R3001, 02	ERJ6GMYJ223	M.RESISTOR CH 1/10W 22K	2	
R0706, 07	ERJ3GEYJ272	M.RESISTOR CH 1/16W 2.7K	2		R3003	ERJ6GMYJ222	M.RESISTOR CH 1/10W 2.2K	1	
R0708	ERJ3GEYJ152	M.RESISTOR CH 1/16W 1.5K	1		R3004	ERJ6GMYJ272	M.RESISTOR CH 1/10W 2.7K	1	
R0709	ERJ3GEYJ105	M.RESISTOR CH 1/16W 1M	1		R3005	ERJ6GMYJ332	M.RESISTOR CH 1/10W 3.3K	1	
R0710	ERJ6GEYJ154	M.RESISTOR CH 1/10W 150K	1		R3007	ERJ6GMYJ222	M.RESISTOR CH 1/10W 2.2K	1	
R0713	ERJ3GEYJ331	M.RESISTOR CH 1/16W 330	1		R3008, 09	ERJ6GMYJ473	M.RESISTOR CH 1/10W 47K	2	
R0714	ERJ3GEYJ470	M.RESISTOR CH 1/16W 47	1		R3010	ERJ6GMYJ683	M.RESISTOR CH 1/10W 68K	1	
R0715	ERJ3GEYJ183	M.RESISTOR CH 1/16W 18K	1		R3011	ERJ6GMYJ103	M.RESISTOR CH 1/10W 10K	1	
R0716	VRE0040E151	M.RESISTOR CH 1/10W 150	1		R3012	ERJ6GMYJ473	M.RESISTOR CH 1/10W 47K	1	
R0717	ERJ3GEYOR00	M.RESISTOR CH 1/16W 0	1		R3013	ERJ6GMYJ103	M.RESISTOR CH 1/10W 10K	1	
R0718	ERJ3GEYJ102	M.RESISTOR CH 1/16W 1K	1		R3014	ERJ6GMYJ102	M.RESISTOR CH 1/10W 1K	1	
R0719	ERJ6GEYJ822	M.RESISTOR CH 1/10W 8.2K	1		R3017	ERJ6GMYJ333	M.RESISTOR CH 1/10W 33K	1	
R0720	ERJ3GEYJ102	M.RESISTOR CH 1/16W 1K	1		R3018	ERJ6GMYJ223	M.RESISTOR CH 1/10W 22K	1	
R0722	ERJ3GEYJ101	M.RESISTOR CH 1/16W 100	1		R3019, 20	ERJ6GMYJ561	M.RESISTOR CH 1/10W 560	2	
R0728	ERJ3GEYJ471	M.RESISTOR CH 1/16W 470	1		R3021	ERJ6GMYJ391	M.RESISTOR CH 1/10W 390	1	
R0729	ERJ3GEYJ102	M.RESISTOR CH 1/16W 1K	1		R3022	ERJ6GMYJ102	M.RESISTOR CH 1/10W 1K	1	
R0732	ERJ3GEYJ471	M.RESISTOR CH 1/16W 470	1		R3023, 24	ERJ6GMYJ821	M.RESISTOR CH 1/10W 820	2	
R0783	ERJ3GEYJ393	M.RESISTOR CH 1/16W 39K	1		R3025	ERJ6GMYJ122	M.RESISTOR CH 1/10W 1.2K	1	
R1002	ERDS2FJ561	C.RESISTOR 1/4W 560	1		R3026	ERJ6GMYJ102	M.RESISTOR CH 1/10W 1K	1	
R1003	ERJ6GMYG272	M.RESISTOR CH 1/10W 2.7K	1		R3029	ERJ6GMYJ222	M.RESISTOR CH 1/10W 2.2K	1	
R1004	ERJ6GMYJ114	M.RESISTOR CH 1/10W 110K	1		R3030	ERJ6GMYJ103	M.RESISTOR CH 1/10W 10K	1	
R1005	ERJ6GMYG272	M.RESISTOR CH 1/10W 2.7K	1		R3033	ERJ6GMYJ223	M.RESISTOR CH 1/10W 22K	1	
R1006	ERJ6GMYJ122	M.RESISTOR CH 1/10W 1.2K	1		R3034	ERJ6GMYJ103	M.RESISTOR CH 1/10W 10K	1	
R1007	ERJ6GMYJ102	M.RESISTOR CH 1/10W 1K	1		R3037-39	ERJ6GMYJ102	M.RESISTOR CH 1/10W 1K	3	
R1101	ERG12SJ153	M.RESISTOR 1/2W 15K	1		R3040	ERJ6GMYJ122	M.RESISTOR CH 1/10W 1.2K	1	
R1102	ERG3SJ563	M.RESISTOR 3W 56K	1		R3041	ERJ6GMYJ561	M.RESISTOR CH 1/10W 560	1	
R1104	ERJ6GMYJ391	M.RESISTOR CH 1/10W 390	1		R3042	ERJ6GMYJ122	M.RESISTOR CH 1/10W 1.2K	1	
R1105	ERG12SJ153	M.RESISTOR 1/2W 15K	1		R3043	ERJ6GMYJ223	M.RESISTOR CH 1/10W 22K	1	
R1107	ERJ6GEYJ164	M.RESISTOR CH 1/10W 160K	1		R3044	ERJ6GMYJ683	M.RESISTOR CH 1/10W 68K	1	
R1108	ERJ6GMYJ105	M.RESISTOR CH 1/10W 1M	1		R3045	ERJ6GMYJ390	M.RESISTOR CH 1/10W 39	1	
R1109	ERJ6GMYJ221	M.RESISTOR CH 1/10W 220	1		R3046	ERJ6GMYJ473	M.RESISTOR CH 1/10W 47K	1	
R1110	ERJ6GMVJ822	M.RESISTOR CH 1/10W 8.2K	1		R3047	ERJ6GMYJ333	M.RESISTOR CH 1/10W 33K	1	
R1111	ERDS2FJ102	C.RESISTOR 1/4W 1K	1		R3048	ERJ6GMYJ222	M.RESISTOR CH 1/10W 2.2K	1	
R1112	ERJ8GEYJ304	M.RESISTOR CH 1/8W 300K	1		R3049	ERJ6GMYG821	M.RESISTOR CH 1/10W 820	1	
R1113	ERJ8GEYJ474	M.RESISTOR CH 1/8W 470K	1		R3050	ERJ6GMYG123	M.RESISTOR CH 1/10W 12K	1	
R1114	ERX12SJR75	M.RESISTOR 1/2W 0.75	1		R3051	ERJ6GMYG512	M.RESISTOR CH 1/10W 5.1K	1	
R1115	ERJ6GMYJ103	M.RESISTOR CH 1/10W 10K	1		R3052	ERJ6GMYG272	M.RESISTOR CH 1/10W 2.7K	1	
R1116	ERJ6GMYJ100	M.RESISTOR CH 1/10W 10	1		R3053	ERJ6GMYG302	M.RESISTOR CH 1/10W 3K	1	
R1117	ERJ6GMYJ472	M.RESISTOR CH 1/10W 4.7K	1		R3054	ERJ6GMYJ102	M.RESISTOR CH 1/10W 1K	1	
R1118	ERJ8GEYOR00	M.RESISTOR CH 1/8W 0	1		R3055	ERJ6GMYJ823	M.RESISTOR CH 1/10W 82K	1	
R1122	ERC12AGM334	S.RESISTOR 1/2W 330K	1		R3056	ERJ6GMYJ473	M.RESISTOR CH 1/10W 47K	1	
R1123	ERJ6GMZOR00	M.RESISTOR CH 1/10W 0	1		R3057	ERJ6GMYJ222	M.RESISTOR CH 1/10W 2.2K	1	
R1124	ERJ6GEYK475	M.RESISTOR CH 1/10W 4.7M	1		R3058	ERJ6GMYG821	M.RESISTOR CH 1/10W 820	1	
R1125	ERJ6GMYJ271	M.RESISTOR CH 1/10W 270	1		R3059	ERJ6GMYG123	M.RESISTOR CH 1/10W 12K	1	
R1127	ERJ6GMYJ333	M.RESISTOR CH 1/10W 33K	1		R3060	ERJ6GMYG512	M.RESISTOR CH 1/10W 5.1K	1	
R1128	ERJ6GMYJ332	M.RESISTOR CH 1/10W 3.3K	1		R3061	ERJ6GMYG272	M.RESISTOR CH 1/10W 2.7K	1	
R1129	ERJ6GMYJ223	M.RESISTOR CH 1/10W 22K	1		R3062	ERJ6GMYG302	M.RESISTOR CH 1/10W 3K	1	
R1131	ERJ6GMYG620	M.RESISTOR CH 1/10W 62	1		R3063	ERJ6GMYJ222	M.RESISTOR CH 1/10W 2.2K	1	
R1132	ERJ6GMYG302	M.RESISTOR CH 1/10W 3K	1		R3064, 65	ERJ6GMYJ103	M.RESISTOR CH 1/10W 10K	2	
R1135	ERJ8GEYJ274	M.RESISTOR CH 1/8W 270K	1		R3066	ERJ6GMYJ561	M.RESISTOR CH 1/10W 560	1	
R1136	ERJ8GEYJ474	M.RESISTOR CH 1/8W 470K	1		R3067	ERJ6GMYJ273	M.RESISTOR CH 1/10W 27K	1	
R1137	ERG12SJ153	M.RESISTOR 1/2W 15K	1		R3068, 69	ERJ6GMYJ103	M.RESISTOR CH 1/10W 10K	2	
R2001	ERJ6GMYG512	M.RESISTOR CH 1/10W 5.1K	1		R3070	ERJ6GMYJ222	M.RESISTOR CH 1/10W 2.2K	1	
R2002	ERJ6GMYG913	M.RESISTOR CH 1/10W 91K	1		R3073	ERJ6GMYJ103	M.RESISTOR CH 1/10W 10K	1	
R2003	ERDS2FJ7R5	C.RESISTOR 1/4W 7.5	1		R3076, 77	ERJ6GMYJ103	M.RESISTOR CH 1/10W 10K	2	
R2004	ERDS2FJ102	C.RESISTOR 1/4W 1K	1		R3079	ERJ6GMYJ334	M.RESISTOR CH 1/10W 330K	1	
R2005, 06	ERJ6GMYJ102	M.RESISTOR CH 1/10W 1K	2		R3080	ERJ6GMZOR00	M.RESISTOR CH 1/10W 0	1	
R2007	ERJ6GMYJ103	M.RESISTOR CH 1/10W 10K	1		R4001	ERJ6GMYJ332	M.RESISTOR CH 1/10W 3.3K	1	

Ref.No.	Part No.	Part Name & Description	Pcs	Remarks	Ref.No.	Part No.	Part Name & Description	Pcs	Remarks
R4002	ERJ6GMJ223	M.RESISTOR CH 1/10W 22K	1		R4651	ERJ3GEYJ471	M.RESISTOR CH 1/16W 470	1	
R4003	ERJ6GMJ221	M.RESISTOR CH 1/10W 220	1		R4653	ERJ3GEYJ821	M.RESISTOR CH 1/16W 820	1	
R4004,05	ERJ6GMJ472	M.RESISTOR CH 1/10W 4.7K	2		R4654	ERJ3GEYJ223	M.RESISTOR CH 1/16W 22K	1	
R4006,07	ERDS2TJ472	C.RESISTOR 1/4W 4.7K	2		R4655	ERJ3GEYJ562	M.RESISTOR CH 1/16W 5.6K	1	
R4008,09	ERJ6GMJ273	M.RESISTOR CH 1/10W 27K	2		R4656	ERJ3GEYJ243	M.RESISTOR CH 1/16W 24K	1	
R4014	ERJ6GMJ562	M.RESISTOR CH 1/10W 5.6K	1		R4657	ERJ3GEYJ392	M.RESISTOR CH 1/16W 3.9K	1	
R4018	ERJ6GMJ333	M.RESISTOR CH 1/10W 33K	1		R4666	ERJ3GEYJ471	M.RESISTOR CH 1/16W 470	1	
R4043	ERJ6GMJ683	M.RESISTOR CH 1/10W 68K	1		R4671	ERJ3GEYOR00	M.RESISTOR CH 1/16W 0	1	
R4046	ERJ6GMJ273	M.RESISTOR CH 1/10W 27K	1		R5003	ERJ6GMJ102	M.RESISTOR CH 1/10W 1K	1	
R4055	ERG2SJ821	M.RESISTOR 2W 820	1		R5004	ERJ6GMJ271	M.RESISTOR CH 1/10W 270	1	
R4057	ERJ6GMJ333	M.RESISTOR CH 1/10W 33K	1		R5005	ERJ6GMJ472	M.RESISTOR CH 1/10W 4.7K	1	
R4064-66	ERGISJ270	M.RESISTOR 1W 27	3		R5006	ERJ6GMJ124	M.RESISTOR CH 1/10W 120K	1	
R4067,68	ERJ6GMJ393	M.RESISTOR CH 1/10W 39K	2		R5007	ERJ6GMJ223	M.RESISTOR CH 1/10W 22K	1	
R4071,72	ERJ6GMJ221	M.RESISTOR CH 1/10W 220	2		R5012	ERJ6GMJ563	M.RESISTOR CH 1/10W 56K	1	
R4073	ERJ6GM2OR00	M.RESISTOR CH 1/10W 0	1		R5013	ERJ6GMJG123	M.RESISTOR CH 1/10W 12K	1	
R4074	ERJ6GMJ221	M.RESISTOR CH 1/10W 220	1		R5014	ERJ6GMJG223	M.RESISTOR CH 1/10W 22K	1	
R4075	ERJ6GM2OR00	M.RESISTOR CH 1/10W 0	1		R5016,17	ERJ6GMJ102	M.RESISTOR CH 1/10W 1K	2	
R4086	ERJ6GMJ221	M.RESISTOR CH 1/10W 220	1		R5018	ERJ6GMJ123	M.RESISTOR CH 1/10W 12K	1	
R4090,91	ERJ6GMJ392	M.RESISTOR CH 1/10W 3.9K	2		R5019	ERJ6GMJ682	M.RESISTOR CH 1/10W 6.8K	1	
R4092	ERJ6GEYJ101	M.RESISTOR CH 1/10W 100	1		R5020	ERJ6GMJ102	M.RESISTOR CH 1/10W 1K	1	
R4501,02	ERJ3GEYOR00	M.RESISTOR CH 1/16W 0	2		R5021,22	ERJ6GMJ681	M.RESISTOR CH 1/10W 680	2	
R4503	ERJ3GEYJ223	M.RESISTOR CH 1/16W 22K	1		R5023	ERJ6GMJ271	M.RESISTOR CH 1/10W 270	1	
R4504,05	ERJ3GEYOR00	M.RESISTOR CH 1/16W 0	2		R5025	ERJ6GMJ102	M.RESISTOR CH 1/10W 1K	1	
R4506,07	ERJ3GEYJ473	M.RESISTOR CH 1/16W 47K	2		R5027	ERJ6GMJ122	M.RESISTOR CH 1/10W 1.2K	1	
R4508	ERJ3GEYJ224	M.RESISTOR CH 1/16W 220K	1		R5028,29	ERJ6GMJ102	M.RESISTOR CH 1/10W 1K	2	
R4509	VRE0071E622	M.RESISTOR CH 1/10W 6.2K	1		R5030	ERJ6GMJ471	M.RESISTOR CH 1/10W 470	1	
R4511	ERJ3GEYJ273	M.RESISTOR CH 1/16W 27K	1		R5031	ERJ6GMJ102	M.RESISTOR CH 1/10W 1K	1	
R4512	VRE0071E163	M.RESISTOR CH 1/10W 16K	1		R6001	ERJ6GMJ201	M.RESISTOR CH 1/10W 200	1	
R4513	ERJ3GEYJ103	M.RESISTOR CH 1/16W 10K	1		R6002	ERJ6GMJG272	M.RESISTOR CH 1/10W 2.7K	1	
R4514	ERJ3GEYJ223	M.RESISTOR CH 1/16W 22K	1		R6003	ERJ6GMJ272	M.RESISTOR CH 1/10W 2.7K	1	
R4518,19	ERJ3GEYOR00	M.RESISTOR CH 1/16W 0	2		R6004	ERJ6GMJ102	M.RESISTOR CH 1/10W 1K	1	
R4522	ERJ3GEYJ225	M.RESISTOR CH 1/16W 2.2M	1		R6005	ERJ6GMJ333	M.RESISTOR CH 1/10W 33K	1	
R4527	VRE0071E333	M.RESISTOR 33K	1		R6006,07	ERJ6GMJ683	M.RESISTOR CH 1/10W 68K	2	
R4528	VRE0071E153	M.RESISTOR 15K	1		R6008	ERJ6GMJ272	M.RESISTOR CH 1/10W 2.7K	1	
R4529	ERJ3GEYJ562	M.RESISTOR CH 1/16W 5.6K	1		R6009	ERJ6GMJ333	M.RESISTOR CH 1/10W 33K	1	
R4530	ERJ3GEYJ334	M.RESISTOR CH 1/16W 330K	1		R6010	ERDS2TJ333	C.RESISTOR 1/4W 33K	1	
R4534	ERJ3GEYJ102	M.RESISTOR CH 1/16W 1K	1		R6011,12	ERJ6GMJG223	M.RESISTOR CH 1/10W 22K	2	
R4535	ERJ3GEYJ104	M.RESISTOR CH 1/16W 100K	1		R6013	ERJ6GMJ103	M.RESISTOR CH 1/10W 10K	1	
R4539	ERJ3GEYJ104	M.RESISTOR CH 1/16W 100K	1		R6015	ERJ6GM2OR00	M.RESISTOR CH 1/10W 0	1	
R4541	ERJ3GEYJ103	M.RESISTOR CH 1/16W 10K	1		R6017	ERDS2TJ271	C.RESISTOR 1/4W 270	1	
R4542	ERJ3GEYJ222	M.RESISTOR CH 1/16W 2.2K	1		R6018-20	ERJ6GM2OR00	M.RESISTOR CH 1/10W 0	3	
R4543	ERJ3GEYJ472	M.RESISTOR CH 1/16W 4.7K	1		R6021	ERJ6GMJ102	M.RESISTOR CH 1/10W 1K	1	
R4551,52	ERJ3GEYJ393	M.RESISTOR CH 1/16W 39K	2		R6022	ERJ6GM2OR00	M.RESISTOR CH 1/10W 0	1	
R4553,54	ERJ3GEYJ273	M.RESISTOR CH 1/16W 27K	2		R6023	ERJ6GMJ101	M.RESISTOR CH 1/10W 100	1	
R4558	ERJ3GEYJ224	M.RESISTOR CH 1/16W 220K	1		R6024	ERJ6GMJ104	M.RESISTOR CH 1/10W 1M	1	
R4561	ERJ3GEYJ273	M.RESISTOR CH 1/16W 27K	1		R6025	ERJ6GMJ333	M.RESISTOR CH 1/10W 33K	1	
R4562	VRE0034E10C	M.RESISTOR CH 1/10W	1		R6026	ERJ6GEYJ103	M.RESISTOR CH 1/10W 10K	1	
R4563	ERJ3GEYJ272	M.RESISTOR CH 1/16W 2.7K	1		R6027	ERJ6GM2OR00	M.RESISTOR CH 1/10W 0	1	
R4568,69	ERJ3GEYJ273	M.RESISTOR CH 1/16W 27K	2		R6028	ERJ6GMJ101	M.RESISTOR CH 1/10W 100	1	
R4572	ERJ3GEYJ473	M.RESISTOR CH 1/16W 47K	1		R6029	ERDS2TJ103	C.RESISTOR 1/4W 10K	1	
R4573	ERJ3GEYJ152	M.RESISTOR CH 1/16W 1.5K	1		R6030	ERJ6GMJ101	M.RESISTOR CH 1/10W 100	1	
R4577	ERJ3GEYJ473	M.RESISTOR CH 1/16W 47K	1		R6031	ERJ6GMJ222	M.RESISTOR CH 1/10W 2.2K	1	
R4578	VRE0071E473	M.RESISTOR CH 1/10W 47K	1		R6032	ERJ6GMJ102	M.RESISTOR CH 1/10W 1K	1	
R4581	ERJ3GEYJ104	M.RESISTOR CH 1/16W 100K	1		R6034,35	ERJ6GMJ272	M.RESISTOR CH 1/10W 2.7K	2	
R4583	ERJ3GEYJ102	M.RESISTOR CH 1/16W 1K	1		R6036	ERJ6GM2OR00	M.RESISTOR CH 1/10W 0	1	
R4584	ERJ3GEYJ472	M.RESISTOR CH 1/16W 4.7K	1		R6037,38	ERJ6GMJ221	M.RESISTOR CH 1/10W 220	2	
R4585,86	ERJ3GEYOR00	M.RESISTOR CH 1/16W 0	2		R6040,41	ERJ6GMJ272	M.RESISTOR CH 1/10W 2.7K	2	
R4587,88	ERJ3GEYJ273	M.RESISTOR CH 1/16W 27K	2		R6042	ERJ6GMJ103	M.RESISTOR CH 1/10W 10K	1	
R4591	ERJ3GEYJ473	M.RESISTOR CH 1/16W 47K	1		R6043,44	ERJ6GMJ221	M.RESISTOR CH 1/10W 220	2	
R4592	ERJ3GEYJ563	M.RESISTOR CH 1/16W 56K	1		R6045	ERJ6GMJ392	M.RESISTOR CH 1/10W 3.9K	1	
R4593	ERJ3GEYJ472	M.RESISTOR CH 1/16W 4.7K	1		R6047-50	ERJ6GMJ102	M.RESISTOR CH 1/10W 1K	4	
R4594	ERJ3GEYJ473	M.RESISTOR CH 1/16W 47K	1		R6051	ERJ6GMJ101	M.RESISTOR CH 1/10W 100	1	
R4596	ERJ3GEYJ473	M.RESISTOR CH 1/16W 47K	1		R6052	ERJ6GM2OR00	M.RESISTOR CH 1/10W 0	1	
R4597	ERJ3GEYJ103	M.RESISTOR CH 1/16W 10K	1		R6053-55	ERJ6GMJ102	M.RESISTOR CH 1/10W 1K	3	
R4598,99	ERJ3GEYJ104	M.RESISTOR CH 1/16W 100K	2		R6056,57	ERJ6GM2OR00	M.RESISTOR CH 1/10W 0	2	
R4603	ERJ3GEYJ163	M.RESISTOR CH 1/16W 16K	1		R6058	ERJ6GMJ103	M.RESISTOR CH 1/10W 10K	1	
R4606	VRE0071E562	M.RESISTOR 5.6K	1		R6059	ERJ6GMJ102	M.RESISTOR CH 1/10W 1K	1	
R4610	ERJ3GEYJ473	M.RESISTOR CH 1/16W 47K	1		R6060	ERJ6GMJ183	M.RESISTOR CH 1/10W 18K	1	
R4611	ERJ3GEYJ101	M.RESISTOR CH 1/16W 100	1		R6061	ERJ6GMJ472	M.RESISTOR CH 1/10W 4.7K	1	
R4612	VRE0071E331	M.RESISTOR CH 1/10W 330	1		R6062	ERJ6GMJ244	M.RESISTOR CH 1/10W 240K	1	
R4613	ERJ3GEYJ394	M.RESISTOR CH 1/16W 390K	1		R6063,64	ERJ6GMJ103	M.RESISTOR CH 1/10W 10K	2	
R4615	VRE0071E133	M.RESISTOR CH 1/10W 13K	1		R6068	ERJ6GM2OR00	M.RESISTOR CH 1/10W 0	1	
R4616	ERJ3GEYJ105	M.RESISTOR CH 1/16W 1M	1		R6069	ERJ6GMJ103	M.RESISTOR CH 1/10W 10K	1	
R4638	ERJ3GEYOR00	M.RESISTOR CH 1/16W 0	1		R6071	ERJ6GEYJ101	M.RESISTOR CH 1/10W 100	1	
R4649	ERJ3GEYJ470	M.RESISTOR CH 1/16W 47	1		R6072	ERJ6GEYOR00	M.RESISTOR CH 1/10W 0	1	

Ref.No.	Part No.	Part Name & Description	Pcs	Remarks
R6073	ERJ6GMJ101	M.RESISTOR CH 1/10W 100	1	
R6075-77	ERJ6GMJ103	M.RESISTOR CH 1/10W 10K	3	
R6079	ERJ6GMJ103	M.RESISTOR CH 1/10W 10K	1	
R6082	ERJ6GMJ822	M.RESISTOR CH 1/10W 8.2K	1	
R6083	ERJ6GMJ243	M.RESISTOR CH 1/10W 24K	1	
R7302	ERJ3GEYG822	M.RESISTOR CH 1/16W 8.2K	1	
R7303	ERJ3GEYJ222	M.RESISTOR CH 1/16W 2.2K	1	
R7304	ERJ3GEYG682	M.RESISTOR CH 1/16W 6.8K	1	
R7305	ERJ3GEYJ562	M.RESISTOR CH 1/16W 5.6K	1	
R7307	ERJ3GEYJ272	M.RESISTOR CH 1/16W 2.7K	1	
R7311	ERJ3GEYOR00	M.RESISTOR CH 1/16W 0	1	
R7313	ERJ3GEYJ273	M.RESISTOR CH 1/16W 27K	1	
R7320	ERJ6GEYJ103	M.RESISTOR CH 1/10W 10K	1	
R7323	ERJ3GEYG822	M.RESISTOR CH 1/16W 8.2K	1	
R7324, 25	ERJ3GEYG471	M.RESISTOR CH 1/16W 470	2	
R7326	ERJ3GEYG822	M.RESISTOR CH 1/16W 8.2K	1	
R7327	ERJ6GEYJ103	M.RESISTOR CH 1/10W 10K	1	
R7328	ERJ3GEYOR00	M.RESISTOR CH 1/16W 0	1	
R7329	ERJ3GEYG682	M.RESISTOR CH 1/16W 6.8K	1	
R7330	ERJ3GEYOR00	M.RESISTOR CH 1/16W 0	1	
R7331	ERJ3GEYG822	M.RESISTOR CH 1/16W 8.2K	1	
R7336	ERJ6GEYJ471	M.RESISTOR CH 1/10W 470	1	
R7337	ERJ3GEYJ471	M.RESISTOR CH 1/16W 470	1	
R7345	ERJ3GEYJ182	M.RESISTOR CH 1/16W 1.8K	1	
R7352, 53	ERJ3GEYJ103	M.RESISTOR CH 1/16W 10K	2	
R7354, 55	ERJ3GEYJ102	M.RESISTOR CH 1/16W 1K	2	
R7358, 59	ERJ3GEYOR00	M.RESISTOR CH 1/16W 0	2	
R7362, 63	ERJ3GEYJ103	M.RESISTOR CH 1/16W 10K	2	
R7601	ERJ6GMJ1151	M.RESISTOR CH 1/10W 150	1	
R7602, 03	ERJ6GMJ1683	M.RESISTOR CH 1/10W 68K	2	
R7604	ERJ6GMJ1151	M.RESISTOR CH 1/10W 150	1	
R7605-07	ERJ6GMJ1102	M.RESISTOR CH 1/10W 1K	3	
R7608	ERJ6GMZOR00	M.RESISTOR CH 1/10W 0	1	
R7609	ERJ6GMJ1102	M.RESISTOR CH 1/10W 1K	1	
R7612	ERG2SJ331	M.RESISTOR 2W 330	1	
R7614	ERJ6GMJ1561	M.RESISTOR CH 1/10W 560	1	
R7615	ERJ6GMJ1103	M.RESISTOR CH 1/10W 10K	1	
R7616	ERG2SJ331	M.RESISTOR 2W 330	1	
R7617	ERJ6GEYOR00	M.RESISTOR CH 1/10W 0	1	
T0703	EQV5ECO71A	TRANSFORMER	1	
T0704	EQV5ECO72A	TRANSFORMER	1	
T1101	VLT0750	TRANSFORMER	1	<1>
T7301	EQR7QGO28P	TRANSFORMER	1	
T7304	EIS5ECO17A	TRANSFORMER	1	
T7305	EQS5ECO33A	TRANSFORMER	1	
VR301	EVMEASAOOB14	V.RESISTOR	1	
VR302	EVMEASAOOB53	V.RESISTOR 5K	1	
VR303	EVMEASAOOB24	V.RESISTOR	1	
VR0701	EVNCBAABO24	V.RESISTOR 20K	1	
VR2001	EVNCAAA03B54	V.RESISTOR 50K	1	
VR3001	EVNCAAA03B23	V.RESISTOR 2K	1	
VR3012, 13	EVNCAAA03B52	V.RESISTOR 500	2	
VR3014	EVNCAAA03B54	V.RESISTOR 50K	1	
VR4501	EVMECSAOOB53	V.RESISTOR	1	
VR4502	EVMECSAOOB54	V.RESISTOR	1	
VR4507	EVMECSAOOB54	V.RESISTOR	1	
VR4509	EVMECSAOOB53	V.RESISTOR	1	
VR4550	EVMECSAOOB14	V.RESISTOR 10K	1	
VR4551, 52	EVMECSAOOB55	V.RESISTOR	2	
VR7301, 02	EVNCBAABO53	V.RESISTOR	2	
VR8001	EVNCAAA03B23	V.RESISTOR 2K	1	
X301	VX0162	CRYSTAL OSCILLATOR	1	
X0703	EFCT5R5M5	CRYSTAL OSCILLATOR	1	
X0704	VLF1035	FILTER	1	
X6001	VXS0583	CRYSTAL OSCILLATOR	1	
X7301	EFCS5R5M5	CRYSTAL OSCILLATOR	1	
X7304	EFCT5R74MS5B	CRYSTAL OSCILLATOR	1	
X7305	VXS0648	CRYSTAL OSCILLATOR	1	

Ref.No.	Part No.	Part Name & Description	Pcs	Remarks	Ref.No.	Part No.	Part Name & Description	Pcs	Remarks
C378	ECUM1H1042FN	C.CAPACITOR CH 50V 0.1U	1		C1153	ECQB1H103JF	P.CAPACITOR 50V 0.01U	1	
C379	ECEAOJKA221	E.CAPACITOR 6.3V 220U	1		C1155	ECKF1H1032F	C.CAPACITOR 50V 0.01U	1	
C380	ECEAOJKA470	E.CAPACITOR 6.3V 47U	1		C2004	ECEAOJKA470	E.CAPACITOR 6.3V 47U	1	
C381	ECUM1H270JCN	C.CAPACITOR CH 50V 27P	1		C2005	ECQV1H683JM	P.CAPACITOR 50V 0.068U	1	
C383	ECUM1H1042FN	C.CAPACITOR CH 50V 0.1U	1		C2006	ECEA1CKA100	E.CAPACITOR 16V 10U	1	
C386	ECUM1H561JCN	C.CAPACITOR CH 50V 560P	1		C2007	ECEAOJKA221	E.CAPACITOR 6.3V 220U	1	
C387	ECUM1H151JCN	C.CAPACITOR CH 50V 150P	1		C2008	ECUM1H222KBN	C.CAPACITOR CH 50V 2200P	1	
C388	ECUM1H331JCN	C.CAPACITOR CH 50V 330P	1		C2009	ECUM1H471JCN	C.CAPACITOR CH 50V 470P	1	
C391	ECEA1HKN010	E.CAPACITOR 50V 1U	1		C2010,11	ECEA1EKN3R3	E.CAPACITOR 25V 3.3U	2	
C392	ECUM1H681KBN	C.CAPACITOR CH 50V 680P	1		C2012	ECEA1EKA4R7	E.CAPACITOR 25V 4.7U	1	
C393	ECUM1H470JCN	C.CAPACITOR CH 50V 47P	1		C2013	ECEA1AKS221	E.CAPACITOR 10V 220U	1	
C394	ECUM1H1042FN	C.CAPACITOR CH 50V 0.1U	1		C2014	ECUM1H1032FN	C.CAPACITOR CH 50V 0.01U	1	
C395	ECEA1CKA100	E.CAPACITOR 16V 10U	1		C2015	ECUM1H472KBN	C.CAPACITOR CH 50V 4700P	1	
C396	ECUM1H121JCN	C.CAPACITOR CH 50V 120P	1		C2016	ECUM1H392KBN	C.CAPACITOR CH 50V 3900P	1	
C0701,02	ECUX1H1032FV	C.CAPACITOR CH 50V 0.01U	2		C2019	ECUM1H222KBN	C.CAPACITOR CH 50V 2200P	1	
C0704	ECUX1H331JCV	C.CAPACITOR CH 50V 330P	1		C2021	ECUM1H1042FN	C.CAPACITOR CH 50V 0.1U	1	
C0706	ECEA1HKA0R1	E.CAPACITOR 50V 0.1U	1		C2022	ECUM1H223KBN	C.CAPACITOR CH 50V 0.022U	1	
C0707,08	ECUX1H1032FV	C.CAPACITOR CH 50V 0.01U	2		C2024,25	ECUM1C1052FN	C.CAPACITOR CH 16V 1U	2	
C0709	ECUX1H120JCV	C.CAPACITOR CH 50V 12P	1		C2030	ECUM1H102KBN	C.CAPACITOR CH 50V 1000P	1	
C0710	ECUX1H470JFV	C.CAPACITOR CH 50V 47P	1		C2032-34	ECUM1H102KBN	C.CAPACITOR CH 50V 1000P	3	
C0711	ECEA1CKA100	E.CAPACITOR 16V 10U	1		C3001	ECUM1H1042FN	C.CAPACITOR CH 50V 0.1U	1	
C0712	ECUX1H1032FV	C.CAPACITOR CH 50V 0.01U	1		C3002,03	ECUM1H1032FN	C.CAPACITOR CH 50V 0.01U	2	
C0714	ECQB1H473JF	P.CAPACITOR 50V 0.047U	1		C3004	ECEA1CKA100	E.CAPACITOR 16V 10U	1	
C0715	ECUM1H1032FN	C.CAPACITOR CH 50V 0.01U	1		C3006	ECUM1H1032FN	C.CAPACITOR CH 50V 0.01U	1	
C0716	ECEA1CKA100	E.CAPACITOR 16V 10U	1		C3007	ECEAOJKA221	E.CAPACITOR 6.3V 220U	1	
C0717	ECUX1H270JFV	C.CAPACITOR CH 50V 27P	1		C3008	ECUM1H102KBN	C.CAPACITOR CH 50V 1000P	1	
C0718	ECEA1HKA4R7	E.CAPACITOR 50V 0.47U	1		C3009	ECUM1H1032FN	C.CAPACITOR CH 50V 0.01U	1	
C0719	ECUX1H220JCV	C.CAPACITOR CH 50V 22P	1		C3010	ECUM1C1052FN	C.CAPACITOR CH 16V 1U	1	
C0720	ECUX1H1032FV	C.CAPACITOR CH 50V 0.01U	1		C3012	ECEAOJKA330	E.CAPACITOR 6.3V 33U	1	
C0723	ECEA1HKA0R1	E.CAPACITOR 50V 0.1U	1		C3013,14	ECUM1H102JCN	C.CAPACITOR CH 50V 1000P	2	
C0726	ECUX1H1032FV	C.CAPACITOR CH 50V 0.01U	1		C3017,18	ECUM1H1032FN	C.CAPACITOR CH 50V 0.01U	2	
C0730	ECUX1H1032FV	C.CAPACITOR CH 50V 0.01U	1		C3019	ECUM1H620JCN	C.CAPACITOR CH 50V 62P	1	
C0732	ECUX1H1032FV	C.CAPACITOR CH 50V 0.01U	1		C3027	ECEAOJKA470	E.CAPACITOR 6.3V 47U	1	
C1004	ECUM1H1032FN	C.CAPACITOR CH 50V 0.01U	1		C3028	ECUM1H151JCN	C.CAPACITOR CH 50V 150P	1	
C1005	ECEAOJKA220	E.CAPACITOR 6.3V 220U	1		C3029	ECUM1H220JCN	C.CAPACITOR CH 50V 22P	1	
C1006	ECUM1H1032FN	C.CAPACITOR CH 50V 0.01U	1		C3031	ECUM1H220JCN	C.CAPACITOR CH 50V 22P	1	
C1007	ECEAOJKA101	E.CAPACITOR 6.3V 100U	1		C3032	ECUM1H681JCN	C.CAPACITOR CH 50V 680P	1	
C1008	ECUM1H1032FN	C.CAPACITOR CH 50V 0.01U	1		C3033	ECUM1H330JCN	C.CAPACITOR CH 50V 33P	1	
C1009	ECEAOJKA220	E.CAPACITOR 6.3V 22U	1		C3040	ECUM1H392KBN	C.CAPACITOR CH 50V 3900P	1	
C1010	ECEAOJKA101	E.CAPACITOR 6.3V 100U	1		C3041	ECUM1H1042FN	C.CAPACITOR CH 50V 0.1U	1	
C1011	ECUM1H1032FN	C.CAPACITOR CH 50V 0.01U	1		C3042,43	ECUM1H1032FN	C.CAPACITOR CH 50V 0.01U	2	
C1012	ECEAOJKA101	E.CAPACITOR 6.3V 100U	1		C3045	ECUM1H1032FN	C.CAPACITOR CH 50V 0.01U	1	
C1013	ECEAOJKA220	E.CAPACITOR 6.3V 22U	1		C3046,47	ECUM1H102JCN	C.CAPACITOR CH 50V 1000P	2	
C1101	ECKRMS471MBH	C.CAPACITOR 470P	1	<1>	C3051	ECUM1H152KBN	C.CAPACITOR CH 50V 1500P	1	
C1104	ECKRMS471MBH	C.CAPACITOR 470P	1	<1>	C3052,53	ECEAOJKA470	E.CAPACITOR 6.3V 47U	2	
C1107	ECKRMS102MEH	C.CAPACITOR 1000P	1	<1>	C3054	ECUM1C1052FN	C.CAPACITOR CH 16V 1U	1	
C1110	ECQU2A683MN	P.CAPACITOR 250V 0.068U	1	<1>	C3055	ECUM1H1032FN	C.CAPACITOR CH 50V 0.01U	1	
C1111	ECQU2A154MV	P.CAPACITOR 100V 0.15U	1	<1>	C3057	ECUM1H180JCN	C.CAPACITOR CH 50V 18P	1	
C1112	ECEC2GG680	E.CAPACITOR 400V 68U	1		C3062	ECEA1CKA470	E.CAPACITOR 16V 47U	1	
C1113	ECKD2H103PV	C.CAPACITOR 500V 0.01U	1		C4001	ECUM1H1032FN	C.CAPACITOR CH 50V 0.01U	1	
C1114	ECCD3A470KGE	C.CAPACITOR 1KV 47P	1		C4002,03	ECEA1CKA100	E.CAPACITOR 16V 10U	2	
C1115	ECA1VXLV470	E.CAPACITOR 35V 47U	1		C4005	ECUM1H1032FN	C.CAPACITOR CH 50V 0.01U	1	
C1116	ECA1CKLV470	E.CAPACITOR 16V 47U	1		C4010	ECUM1H1042FN	C.CAPACITOR CH 50V 0.1U	1	
C1117	ECQV1H104JM	P.CAPACITOR 50V 0.1U	1		C4017	ECUM1H221JCN	C.CAPACITOR CH 50V 220P	1	
C1118	ECUM1H102KBN	C.CAPACITOR CH 50V 1000P	1		C4034	ECUM1C1052FN	C.CAPACITOR CH 16V 1U	1	
C1120	ECQB1H103JF	P.CAPACITOR 50V 0.01U	1		C4046	ECEA1CKA100	E.CAPACITOR 16V 10U	1	
C1121	ECUM1H391KBN	C.CAPACITOR CH 50V 390P	1		C4064	ECUM1H1032FN	C.CAPACITOR CH 50V 0.01U	1	
C1131	EEUFA1E681	E.CAPACITOR 25V 680P	1		C4503	ECUX1H152KBV	C.CAPACITOR CH 50V 1500P	1	
C1132	ECEA1EU221	E.CAPACITOR 25V 220U	1		C4504	ECEA1CU470	E.CAPACITOR 16V 47U	1	
C1133	ECKD2H101KB	C.CAPACITOR 500V 100P	1		C4505	ECA1VM470	E.CAPACITOR 35V 47U	1	
C1134	EEUFA1A122	E.CAPACITOR 10V 1200P	1		C4506	ECEA1CU100	E.CAPACITOR 16V 10U	1	
C1135	ECEA1AU331	E.CAPACITOR 10V 330U	1		C4507	ECQB1H223JF	P.CAPACITOR 50V 0.022U	1	
C1136	ECKD2H101KB	C.CAPACITOR 500V 100P	1		C4508	ECEA1EKN4R7	E.CAPACITOR 25V 4.7U	1	
C1137	ECA1HFQ560	E.CAPACITOR 50V 56U	1		C4509	ECEA1AU470	E.CAPACITOR 10V 47U	1	
C1138	ECUM1H1032FN	C.CAPACITOR CH 50V 0.01U	1		C4510	ECQB1H103JF	P.CAPACITOR 50V 0.01U	1	
C1140	ECA1VPQ560	E.CAPACITOR 35V 56U	1		C4511	ECQB1H332JF	P.CAPACITOR 50V 3300P	1	
C1141	ECUM1H1032FN	C.CAPACITOR CH 50V 0.01U	1		C4512	ECUX1H561JV	C.CAPACITOR CH 50V 560P	1	
C1142	ECKD2H101KB	C.CAPACITOR 500V 100P	1		C4513	ECUX1H681JV	C.CAPACITOR CH 50V 680P	1	
C1143	ECAOJFQ221	E.CAPACITOR 6.3V 220U	1		C4514	ECUX1H561JV	C.CAPACITOR CH 50V 560P	1	
C1144,45	ECUM1H1032FN	C.CAPACITOR CH 50V 0.01U	2		C4515	ECEA1EU4R7	E.CAPACITOR 25V 4.7U	1	
C1147	ECUM1H102KBN	C.CAPACITOR CH 50V 1000P	1		C4517	ECEA1AU101	E.CAPACITOR 10V 100U	1	
C1148	ECQV1H104JM	P.CAPACITOR 50V 0.1U	1		C4518	ECUX1C1042FV	C.CAPACITOR CH 16V 0.1U	1	
C1149	ECUM1H1032FN	C.CAPACITOR CH 50V 0.01U	1		C4521	ECUM1E473KBN	C.CAPACITOR CH 25V 0.047U	1	
C1150	ECA1CM101	E.CAPACITOR 16V 100U	1		C4522	ECEA1HU3R3	E.CAPACITOR 50V 3.3U	1	
C1151	ECEA1EGE470	E.CAPACITOR 25V 47U	1		C4524	ECEA1AU101	E.CAPACITOR 10V 100U	1	

Ref.No.	Part No.	Part Name & Description	Pcs	Remarks	Ref.No.	Part No.	Part Name & Description	Pcs	Remarks
C4528	ECUX1C1042FV	C.CAPACITOR CH 16V 0.1U	1		C7327	ECUX1C1042FV	C.CAPACITOR CH 16V 0.1U	1	
C4530	ECEA0JU470	E.CAPACITOR 6.3V 47U	1		C7328	ECEA1CKA470	E.CAPACITOR 16V 47U	1	
C4533	ECEA1AU330	E.CAPACITOR 10V 33U	1		C7329,30	ECUX1H471JCV	C.CAPACITOR CH 50V 470P	2	
C4537	ECUX1H102JCV	C.CAPACITOR CH 50V 1000P	1		C7331	ECEA1CKA100	E.CAPACITOR 16V 10U	1	
C4538	ECEA1HUR47	E.CAPACITOR 50V 0.47U	1		C7332,33	ECUX1C1042FV	C.CAPACITOR CH 16V 0.1U	2	
C4539	ECUX1C2242FV	C.CAPACITOR CH 16V 0.22U	1		C7334	ECEA0JKA101	E.CAPACITOR 6.3V 100U	1	
C4541	ECUX1C1042FV	C.CAPACITOR CH 16V 0.1U	1		C7335	ECUX1C1042FV	C.CAPACITOR CH 16V 0.1U	1	
C4545	ECUX1H102JCV	C.CAPACITOR CH 50V 1000P	1		C7338	ECUM1H471JCN	C.CAPACITOR CH 50V 470P	1	
C4551	ECQB1H223JF	P.CAPACITOR 50V 0.022U	1		C7339	ECUM1H182KBM	C.CAPACITOR CH 50V 1800P	1	
C4556	ECEA1CU100	E.CAPACITOR 16V 10U	1		C7340	ECUM1H270JCN	C.CAPACITOR CH 50V 27P	1	
C4558	ECEA1EKN4R7	E.CAPACITOR 25V 4.7U	1		C7341	ECEA1CKA100	E.CAPACITOR 16V 10U	1	
C4559	ECEA1AU470	E.CAPACITOR 10V 47U	1		C7342	ECUM1H561JCN	C.CAPACITOR CH 50V 560P	1	
C4560	ECQB1H103JF	P.CAPACITOR 50V 0.01U	1		C7343	ECEA1HKA010	E.CAPACITOR 50V 1U	1	
C4561	ECQB1H332JF	P.CAPACITOR 50V 3300P	1		C7344	ECUM1H471JCN	C.CAPACITOR CH 50V 470P	1	
C4562	ECUX1H561JV	C.CAPACITOR CH 50V 560P	1		C7345	ECUM1H182KBM	C.CAPACITOR CH 50V 1800P	1	
C4563	ECUX1H581JV	C.CAPACITOR CH 50V 580P	1		C7346	ECUM1H270JCN	C.CAPACITOR CH 50V 27P	1	
C4564	ECUX1H561JV	C.CAPACITOR CH 50V 560P	1		C7347	ECEA1CKA100	E.CAPACITOR 16V 10U	1	
C4565	ECEA1EU4R7	E.CAPACITOR 25V 4.7U	1		C7348	ECUM1H561JCN	C.CAPACITOR CH 50V 560P	1	
C4567	ECEA1AU101	E.CAPACITOR 10V 100U	1		C7350	ECEA1HKA010	E.CAPACITOR 50V 1U	1	
C4568	ECUX1C1042FV	C.CAPACITOR CH 16V 0.1U	1		C7351	ECUM1H471JCN	C.CAPACITOR CH 50V 470P	1	
C4572	ECEA1HU3R3	E.CAPACITOR 50V 3.3U	1		C7352	ECUM1H182KBM	C.CAPACITOR CH 50V 1800P	1	
C4576	ECUM1E473KBN	C.CAPACITOR CH 25V 0.047U	1		C7353	ECUM1H270JCN	C.CAPACITOR CH 50V 27P	1	
C4583	ECEA1AU330	E.CAPACITOR 10V 33U	1		C7354	ECEA1CKA100	E.CAPACITOR 16V 10U	1	
C4585,86	ECEA1AU101	E.CAPACITOR 10V 100U	2		C7355	ECUM1H561JCN	C.CAPACITOR CH 50V 560P	1	
C4591	ECUX1C1042FV	C.CAPACITOR CH 16V 0.1U	1		C7357	ECUX1C1042FV	C.CAPACITOR CH 16V 0.1U	1	
C4592	ECUX1H152KBM	C.CAPACITOR CH 50V 1500P	1		C7358	ECEA1HKA3R3	E.CAPACITOR 50V 3.3U	1	
C4593	ECUX1H221JCV	C.CAPACITOR CH 50V 220P	1		C7359	ECUX1C1042FV	C.CAPACITOR CH 16V 0.1U	1	
C4594,95	ECUX1H101JCV	C.CAPACITOR CH 50V 100P	2		C7365,66	ECEA1HKA010	E.CAPACITOR 50V 1U	2	
C4596	ECEA1CU100	E.CAPACITOR 16V 10U	1		C7369	ECEA0JKA470	E.CAPACITOR 6.3V 47U	1	
C4597	ECUX1H330JCV	C.CAPACITOR CH 50V 33P	1		C7370	ECUX1C1042FV	C.CAPACITOR CH 16V 0.1U	1	
C4604	ECUM1H182JN	C.CAPACITOR CH 50V 1800P	1		C7371,72	ECUX1H1032FV	C.CAPACITOR CH 50V 0.01U	2	
C4606	ECEA0JKA470	E.CAPACITOR 6.3V 47U	1		C7374,75	ECUX1H150JCV	C.CAPACITOR 5V 15P	2	
C4616	ECUX1H102JCV	C.CAPACITOR CH 50V 1000P	1		C7601	ECUM1H1032FN	C.CAPACITOR CH 50V 0.01U	1	
C4617	ECEA1OM22	E.CAPACITOR 10V 22U	1		C7602	ECQV1H104JM	P.CAPACITOR 50V 0.1U	1	
C4618	ECQB1H822J2	P.CAPACITOR 50V 8200P	1		C7603	ECEA1CKA101	E.CAPACITOR 16V 100U	1	
C4621	ECEA0JKA101	E.CAPACITOR 6.3V 100U	1		C7604	ECEA0JKA101	E.CAPACITOR 6.3V 100U	1	
C4629	ECQB1H822J2	P.CAPACITOR 50V 8200P	1		C7605	ECUM1H1042FN	C.CAPACITOR CH 50V 0.1U	1	
C4636	ECUX1H151JCV	C.CAPACITOR CH 50V 150P	1		C7606	ECEA1CKA101	E.CAPACITOR 16V 100U	1	
C4638	ECQB1H822J2	P.CAPACITOR 50V 8200P	1		C7607	ECUM1H1032FN	C.CAPACITOR CH 50V 0.01U	1	
C4652,53	ECUM1C1052FN	C.CAPACITOR CH 16V 1U	2		C7608	ERJ6GM20ROO	M.RESISTOR CH 1/10W 0	1	
C5005	ECEA1HKA3R3	E.CAPACITOR 50V 3.3U	1		C7609	ECEA0JKA101	E.CAPACITOR 6.3V 100U	1	
C5006	ECUM1H150JCN	C.CAPACITOR CH 50V 15P	1		C7612	ECEA0JKA101	E.CAPACITOR 6.3V 100U	1	
C5007-09	ECUM1H330JCN	C.CAPACITOR CH 50V 33P	3		C7613	ECUM1H180JCN	C.CAPACITOR CH 50V 18P	1	
C5012,13	ECUM1H1032FN	C.CAPACITOR CH 50V 0.01U	2		C7614	ECEA1HKA100	E.CAPACITOR 50V 10U	1	
C5014	ECEA0JKA470	E.CAPACITOR 6.3V 47U	1		C7615	ECEA1HKA010	E.CAPACITOR 50V 1U	1	
C5015,16	ECUM1H1032FN	C.CAPACITOR CH 50V 0.01U	2		C7621-23	ECKF1H1032F	C.CAPACITOR 50V 0.01U	3	
C6001	ECUM1H1042FN	C.CAPACITOR CH 50V 0.1U	1						
C6003	ECUM1C2242FN	C.CAPACITOR CH 16V 0.22U	1		D301	1SS283	DIODE	1	
C6004	ECEA0JKA220	E.CAPACITOR 6.3V 22U	1		D304	1SS254	DIODE	1	
C6005	ECUM1H1032FN	C.CAPACITOR CH 50V 0.01U	1		D305	MA723VT	DIODE	1	
C6006	ECEA0JKA470	E.CAPACITOR 6.3V 47U	1		D307	1SS254	DIODE	1	
C6007	ECQV1H334JM	P.CAPACITOR 50V 0.33U	1		D309-16	1SS254	DIODE	8	
C6009,10	ECUM1H270JCN	C.CAPACITOR CH 50V 27P	2		D1001	MA4051-L	DIODE	1	
C6013	ECUM1H1042FN	C.CAPACITOR CH 50V 0.1U	1		D1004	MA4051-L	DIODE	1	
C6016-19	ECUM1H271JCN	C.CAPACITOR CH 50V 270P	4		D1005	1SS355	DIODE	1	
C6020	ECEA1CKA100	E.CAPACITOR 16V 10U	1		D1007,08	1SS355	DIODE	2	
C6021	ECEA0JKA101	E.CAPACITOR 6.3V 100U	1		D1102	ERA15-08	DIODE	1	
C6023,24	ECUM1H1032FN	C.CAPACITOR CH 50V 0.01U	2		D1103	AP01C	DIODE	1	
C6027,28	ECUM1H1042FN	C.CAPACITOR CH 50V 0.1U	2		D1104	MA178	DIODE	1	
C7301,02	ECUX1H1032FV	C.CAPACITOR CH 50V 0.01U	2		D1105-07	ERA15-08	DIODE	3	
C7303	ECEA1CKA470	E.CAPACITOR 16V 47U	1		D1121	RL2Z	DIODE	1	
C7304	ECUX1H1032FV	C.CAPACITOR CH 50V 0.01U	1		D1122	Z1DQ04FC4	DIODE	1	
C7305	ECEA1CKA220	E.CAPACITOR 16V 22U	1		D1123	ERA22-02	DIODE	1	
C7306	ECUX1H391JCV	C.CAPACITOR CH 50V 390P	1		D1124	MA185	DIODE	1	
C7309-12	ECUX1H1032FV	C.CAPACITOR CH 50V 0.01U	4		D1125	11EQS04	DIODE	1	
C7313	ECEA0JKA220	E.CAPACITOR 6.3V 220U	1		D1126	MA4043-L	DIODE	1	
C7314	ECUX1H1032FV	C.CAPACITOR CH 50V 0.01U	1		D1127	1SS355	DIODE	1	
C7315	ECEA0JKA330	E.CAPACITOR 6.3V 33U	1		D2003	MA153	DIODE	1	
C7317	ECUX1H090DCV	C.CAPACITOR CH 50V 90P	1		D2004	1SS355	DIODE	1	
C7319	ECRHA020D54R	V.CAPACITOR	1		D2005	MA151K	DIODE	1	
C7320	ECEA0JKA101	E.CAPACITOR 6.3V 100U	1		D2007	1SS355	DIODE	1	
C7321	ECUX1H1032FV	C.CAPACITOR CH 50V 0.01U	1		D3001	1SS355	DIODE	1	
C7322	ECEA1EKA4R7	E.CAPACITOR 25V 4.7U	1		D3007	1SS254	DIODE	1	
C7323,24	ECUX1H391JCV	C.CAPACITOR CH 50V 390P	2		D3011,12	1SS355	DIODE	2	
C7325,26	ECEA1CKA100	E.CAPACITOR 16V 10U	2						

Ref.No.	Part No.	Part Name & Description	Pcs	Remarks
D3014-17	1SS355	DIODE	4	
D4003	1SS254	DIODE	1	
D4005	1SS254	DIODE	1	
D4011	1SS254	DIODE	1	
D4013	1SS254	DIODE	1	
D4501-04	MA141K	DIODE	4	
D4602	MA141K	DIODE	1	
D6001	1N59L.VT	LED	1	
D6002,03	1SS254	DIODE	2	
D6004	1SS355	DIODE	1	
D6005	1SS254	DIODE	1	
D6007	MA4075-L	DIODE	1	
D6009	MA151K	DIODE	1	
D6010,11	1SS254	DIODE	2	
D7301	MA3082-L	DIODE	1	
D7302	MA151K	DIODE	1	
D7303	MA151WK	DIODE	1	
D7304	MA717	DIODE	1	
D7306	MA151K	DIODE	1	
D7601	MA4300M	DIODE	1	
F1101	XBA2C16TBO	FUSE	1 <1>	
FL7301,02	VLFO633	FILTER	2	
IC301	TL8850P	IC	1	
IC302	AN3554NFBP	IC	1	
IC0701	LA7576	IC	1	
IC1001	HA17431PA	IC	1	
IC1101	TDA4605-3	IC	1	
IC1102	SI3120C	IC	1	
IC2001	XRA6887-V3	IC	1	
IC4501	XLH773AKS	IC	1	
IC4601	BA7755AF	IC	1	
IC6001	MN6755486H4L	IC	1	
IC6002,03	ON1387	PHOTO INTERRUPTER	2	
IC7301	MSP3410-15	IC	1	
IC7302	PST7043	IC	1	
IC7303	M5238FP	IC	1	
IC7304	HA17431PA	IC	1	
IC7305	MN155402VZBZ	IC	1	
IC7306	PST7043	IC	1	
K4	ERJ3GEYOR00	M.RESISTOR CH 1/16W	0 1	
K303,04	ERJ6GMZOR00	M.RESISTOR CH 1/10W	0 2	
K308	ERJ6GMZOR00	M.RESISTOR CH 1/10W	0 1	
K0702	ERJ3GEYOR00	M.RESISTOR CH 1/16W	0 1	
K0704,05	ERJ3GEYOR00	M.RESISTOR CH 1/16W	0 2	
K1003,04	ERJ6GMZOR00	M.RESISTOR CH 1/10W	0 2	
K1114	ERJ6GMZOR00	M.RESISTOR CH 1/10W	0 1	
K1118	ERJ6GMZOR00	M.RESISTOR CH 1/10W	0 1	
K3008	ERJ6GMZOR00	M.RESISTOR CH 1/10W	0 1	
K3010	ERJ6GMZOR00	M.RESISTOR CH 1/10W	0 1	
K3014	ERJ6GMZOR00	M.RESISTOR CH 1/10W	0 1	
K3016,17	ERJ6GMZOR00	M.RESISTOR CH 1/10W	0 2	
K3030	ERJ6GMZOR00	M.RESISTOR CH 1/10W	0 1	
K4001,02	ERJ6GMZOR00	M.RESISTOR CH 1/10W	0 2	
K4010	ERJ6GMZOR00	M.RESISTOR CH 1/10W	0 1	
K4015	ERJ6GMZOR00	M.RESISTOR CH 1/10W	0 1	
K4017,18	ERJ6GMZOR00	M.RESISTOR CH 1/10W	0 2	
K4036	ERJ6GMZOR00	M.RESISTOR CH 1/10W	0 1	
K6016,17	ERJ6GMZOR00	M.RESISTOR CH 1/10W	0 2	
K7304-07	ERJ3GEYOR00	M.RESISTOR CH 1/16W	0 4	
K7314	ERJ3GEYOR00	M.RESISTOR CH 1/16W	0 1	
K7317	ERJ3GEYOR00	M.RESISTOR CH 1/16W	0 1	
K7622,23	ERJ6GMZOR00	M.RESISTOR CH 1/10W	0 2	
L301	VLQ0599J470	COIL	47UH 1	
L302	VLQ0599J100	COIL	10UH 1	
L303	VLQ0599J270	COIL	27UH 1	

Ref.No.	Part No.	Part Name & Description	Pcs	Remarks
L304	VLQ0599J100	COIL	10UH 1	
L305	VLQ0599J680	COIL	68UH 1	
L306,07	VLQ0599J390	COIL	39UH 2	
L308	VLQ0599J150	COIL	15UH 1	
L310	VLQ0599J121	COIL	120UH 1	
L311	VLQ0599J101	COIL	100UH 1	
L312	VLQ0599J8R2	COIL	8.2UH 1	
L313	VLQ0599J680	COIL	68UH 1	
L314	VLQ0599J220	COIL	22UH 1	
L315	VLQ0599J101	COIL	100UH 1	
L316	VLQ0599J470	COIL	47UH 1	
L317	VLQ0599J101	COIL	100UH 1	
L318	VLQ0599J680	COIL	68UH 1	
L319	VLQ0599J270	COIL	27UH 1	
L322	ERJ6GMZOR00	M.RESISTOR CH 1/10W	0 1	
L323-28	VLP0145	COIL	6	
L330-33	VLP0145	COIL	4	
L334	VLQ0599J390	COIL	39UH 1	
L0701	VLQ0163JR39	COIL	0.39UH 1	
L0705	VLQ0163J5R6	COIL	5.6UH 1	
L0706	VLQEL05T120	COIL	12UH 1	
L1107	ELF18D290A	COIL	29UH 1 <1>	
L1108	ELF18D221F	COIL	220UH 1 <1>	
L1109	VLP0074	COIL	1	
L1110	VLP0085	COIL	1	
L1121	VLQ0611K220	COIL	22UH 1	
L1122	ELELN220KA	COIL	22UH 1	
L1123,24	VLQEL05S101K	COIL	100UH 2	
L3001	VLQ0599J3R3	COIL	3.3UH 1	
L3002	VLQ0599J680	COIL	68UH 1	
L3003	VLQ0599J68R	COIL	6.8UH 1	
L3004	VLQ0599J120	COIL	12UH 1	
L3006	VLQ0599J101	COIL	100UH 1	
L3008	VLQ0599J270	COIL	27UH 1	
L3009	VLQ0599J680	COIL	68UH 1	
L3011	VLQ0599J680	COIL	68UH 1	
L3012,13	ERJ6GMZOR00	M.RESISTOR CH 1/10W	0 2	
L4501,02	ELESE101KA	COIL	100UH 2	
L4601	VLQEL07F153	COIL	1	
L5001	VLQ0599J680	COIL	68UH 1	
L5002,03	VLQ0599J270	COIL	27UH 2	
L5004	VLQ0599J150	COIL	15UH 1	
L6001,02	VLQ0599J680	COIL	68UH 2	
L6003	VLQEL05S101K	COIL	100UH 1	
L6004	VLP0083	COIL	1	
L7301	ELEXH100JBV	COIL	10UH 1	
L7302	VLP0150	INDUCTOR	1	
L7601,02	VLQ0599J1R0	COIL	1UH 2	
L7603-05	VLQ0599J680	COIL	68UH 3	
L7606	VLQ0599J2R2	COIL	2.2UH 1	
L7607,08	VLQ0599J680	COIL	68UH 2	
L7609	VLQ0188KR27	COIL	0.27UH 1	
P1101	VJS3306	AC INLET	1 <1>	
P2001	VJS3316A002	CONNECTOR (FEMALE)	2P 1	
P3002	VJS3537A020G	CONNECTOR (FEMALE)	20P 1	
P4001	VJS3537A012G	CONNECTOR (FEMALE)	12P 1	
P5001	VJR0777B005W	CONNECTOR (MALE)	5P 1	
P6001	VJS3537A032G	CONNECTOR (FEMALE)	32P 1	
P6004	VJS3820	CONNECTOR	1	
PK0701	VJR0816A010W	CONNECTOR (MALE)	10P 1	
PK4001-03	VJR0757B018T	CONNECTOR (MALE)	18P 3	
PK7301	VJR0777B009W	CONNECTOR (MALE)	9P 1	
PK7302	VJR0777B008W	CONNECTOR (MALE)	8P 1	
PP0701	VJP3589A004B	CONNECTOR (MALE)	4P 1	
PP2001	VJP3042A018W	CONNECTOR (MALE)	18P 1	
PP2002	VJP3042A011W	CONNECTOR (MALE)	11P 1	
PP3901	VJP3042G020W	CONNECTOR (MALE)	20P 1	
PP3902	VJP3042A018W	CONNECTOR (MALE)	18P 1	
PP6005	VJP3043A003W	CONNECTOR (MALE)	3P 1	

Ref.No.	Part No.	Part Name & Description	Pcs	Remarks	Ref.No.	Part No.	Part Name & Description	Pcs	Remarks
PR1101	VSFO015A10	IC PROTECTOR	1	<1>	QR3002,03	DTC363EK	TRANSISTOR-RESISTOR	2	
PS301	VJR0776B009W	CONNECTOR (MALE) 9P	1		QR3005	MUN2213	TRANSISTOR-RESISTOR	1	
PS302	VJR0776B015W	CONNECTOR (MALE) 15P	1		QR3007	MUN2111	TRANSISTOR-RESISTOR	1	
PS303	VJR0776B008W	CONNECTOR (MALE) 8P	1		QR3008-18	MUN2212	TRANSISTOR	11	
PS304	VJR0776B003W	CONNECTOR (MALE) 3P	1		QR3019	XN4213	TRANSISTOR-RESISTOR	1	
					QR3020	MUN2212	TRANSISTOR	1	
					QR3021	MUN2211	TRANSISTOR-RESISTOR	1	
					QR3023	MUN2213	TRANSISTOR-RESISTOR	1	
					QR3026,27	MUN2113	TRANSISTOR-RESISTOR	2	
					QR4001	MUN2212	TRANSISTOR	1	
					QR4002,03	MUN2213	TRANSISTOR-RESISTOR	2	
Q301,02	MSD601	TRANSISTOR	2		QR4005	MUN2213	TRANSISTOR-RESISTOR	1	
Q303,04	MSC2295	TRANSISTOR	2		QR4508,09	UN5113	TRANSISTOR-RESISTOR	2	
Q305	MSB709	TRANSISTOR	1		QR4510	UN5212	TRANSISTOR-RESISTOR	1	
Q0701	MSD601-S	TRANSISTOR	1		QR6001	XN1211	TRANSISTOR-RESISTOR	1	
Q0702	MSB709	TRANSISTOR	1		QR6002	XN1213	TRANSISTOR-TRANSISTOR	1	
Q1002,03	2SD1996-S	TRANSISTOR	2		QR6004	UN2114	TRANSISTOR-RESISTOR	1	
Q1004	2SD1996	TRANSISTOR	1		QR6005	MUN2113	TRANSISTOR-RESISTOR	1	
Q1007	MSD602	TRANSISTOR	1		QR6009	MUN2112	TRANSISTOR-RESISTOR	1	
Q1101	STP3N60FI-M	IC	1		QR6010	XN1211	TRANSISTOR-RESISTOR	1	
Q1102	2SD601A	TRANSISTOR	1		QR6012	MUN2211	TRANSISTOR-RESISTOR	1	
Q1111	MOC8104FR2	TRANSISTOR	1	<1>	QR7301	MUN2213	TRANSISTOR-RESISTOR	1	
Q3001	XN4501	TRANSISTOR-RESISTOR	1		QR7302	MUN2112	TRANSISTOR-RESISTOR	1	
Q3002	MSB709	TRANSISTOR	1		QR7601	MUN2213	TRANSISTOR-RESISTOR	1	
Q3004	MSD601	TRANSISTOR	1						
Q3005	MSC2295	TRANSISTOR	1						
Q3006	MSB709	TRANSISTOR	1		R301,02	ERJ6QMYJ102	M.RESISTOR CH 1/10W 1K	2	
Q3007	MSC2295	TRANSISTOR	1		R303	ERJ6QMYJ272	M.RESISTOR CH 1/10W 2.7K	1	
Q3008	2SD1996	TRANSISTOR	1		R304	ERJ6QMYJ182	M.RESISTOR CH 1/10W 1.8K	1	
Q3009	2SB1322	TRANSISTOR	1		R305	ERJ6QMYJ681	M.RESISTOR CH 1/10W 680	1	
Q3010	MSB709	TRANSISTOR	1		R306	ERJ6QMYJ821	M.RESISTOR CH 1/10W 820	1	
Q3011	2SD601A	TRANSISTOR	1		R307	ERJ6QMYK225	M.RESISTOR CH 1/10W 2.2M	1	
Q3012	2SB1322	TRANSISTOR	1		R308	ERJ6QMYJ102	M.RESISTOR CH 1/10W 1K	1	
Q3013	MSB709	TRANSISTOR	1		R310	ERJ6QMYJ681	M.RESISTOR CH 1/10W 680	1	
Q3014	MSD601	TRANSISTOR	1		R311	ERJ6QMYJ102	M.RESISTOR CH 1/10W 1K	1	
Q3016,17	MSC2295	TRANSISTOR	2		R312	ERJ6QMYJ122	M.RESISTOR CH 1/10W 1.2K	1	
Q3018-20	MSD601	TRANSISTOR	3		R313,14	ERJ6QMYJ103	M.RESISTOR CH 1/10W 10K	2	
Q3021	MSB709	TRANSISTOR	1		R315	ERJ6QMYJ684	M.RESISTOR CH 1/10W 680K	1	
Q3023	MSC2295	TRANSISTOR	1		R316	ERJ6QMYJ472	M.RESISTOR CH 1/10W 4.7K	1	
Q4003,04	MSD601	TRANSISTOR	2		R317	ERJ6QMYG221	M.RESISTOR CH 1/10W 220	1	
Q4005	MSD1328	TRANSISTOR	1		R318	ERJ6QMYJ102	M.RESISTOR CH 1/10W 1K	1	
Q4501	2SD1991A-R	TRANSISTOR	1		R319	ERJ6QMYJ222	M.RESISTOR CH 1/10W 2.2K	1	
Q4551	2SB1320A-R	TRANSISTOR	1		R320	ERJ6QMYJ682	M.RESISTOR CH 1/10W 6.8K	1	
Q4552	2SD1819A	TRANSISTOR	1		R321	ERJ6QMYZ0R00	M.RESISTOR CH 1/10W 0	1	
Q5001	MSB709	TRANSISTOR	1		R324	ERJ6QMYJ472	M.RESISTOR CH 1/10W 4.7K	1	
Q5002	MSD601	TRANSISTOR	1		R325	ERJ6QMYJ562	M.RESISTOR CH 1/10W 5.6K	1	
Q5003	2SA1022	TRANSISTOR	1		R326	ERJ6QMYJ122	M.RESISTOR CH 1/10W 1.2K	1	
Q5005	XN1501	TRANSISTOR-TRANSISTOR	1		R327	ERJ6QMYJ473	M.RESISTOR CH 1/10W 47K	1	
Q5006	MSB709	TRANSISTOR	1		R328	ERJ6QMYJ152	M.RESISTOR CH 1/10W 1.5K	1	
Q5007	MSC2295	TRANSISTOR	1		R329	ERJ6QMYG471	M.RESISTOR CH 1/10W 470	1	
Q5008	MSB709	TRANSISTOR	1		R330	ERJ6QMYJ333	M.RESISTOR CH 1/10W 33K	1	
Q5009-13	MSC2295	TRANSISTOR	5		R331	ERJ6QMYJ473	M.RESISTOR CH 1/10W 47K	1	
Q6001	MSB709	TRANSISTOR	1		R332	ERJ6QMYJ103	M.RESISTOR CH 1/10W 10K	1	
Q6002	PN205L-NC-VT	PHOTO TRANSISTOR	1		R333	ERJ6QMYJ392	M.RESISTOR CH 1/10W 3.9K	1	
Q7301,02	2SD1996	TRANSISTOR	2		R334	ERJ6QMYJ103	M.RESISTOR CH 1/10W 10K	1	
Q7304	2SC2404-D	TRANSISTOR	1		R336	ERJ6QMYJ222	M.RESISTOR CH 1/10W 2.2K	1	
Q7305	MSD601-S	TRANSISTOR	1		R337	ERJ6QMYG201	M.RESISTOR CH 1/10W 200	1	
Q7308-10	2SB709A	TRANSISTOR	3		R339	ERJ6QMYJ222	M.RESISTOR CH 1/10W 2.2K	1	
Q7311-13	MSD1328-S	TRANSISTOR	3		R340	ERJ6QMYJ103	M.RESISTOR CH 1/10W 10K	1	
Q7601	2SB709A-R	TRANSISTOR	1		R341	ERJ6QMYJ101	M.RESISTOR CH 1/10W 100	1	
					R342,43	ERJ6QMYJ102	M.RESISTOR CH 1/10W 1K	2	
					R344	ERJ6QMYJ223	M.RESISTOR CH 1/10W 22K	1	
QR302	MUN2212	TRANSISTOR	1		R345	ERJ6QMYJ102	M.RESISTOR CH 1/10W 1K	1	
QR303	MUN2213	TRANSISTOR-RESISTOR	1		R346	ERJ6QMYJ473	M.RESISTOR CH 1/10W 47K	1	
QR305	MUN2212	TRANSISTOR	1		R347,48	ERJ6QMYJ102	M.RESISTOR CH 1/10W 1K	2	
QR306	MUN2213	TRANSISTOR-RESISTOR	1		R349	ERJ6QMYJ272	M.RESISTOR CH 1/10W 2.7K	1	
QR308	IMH5	TRANSISTOR-RESISTOR	1		R350	ERJ6QMYK225	M.RESISTOR CH 1/10W 2.2M	1	
QR310	MUN2213	TRANSISTOR-RESISTOR	1		R351	ERJ6QMYZ0R00	M.RESISTOR CH 1/10W 0	1	
QR311	MUN2111	TRANSISTOR-RESISTOR	1		R353	ERJ6QMYZ0R00	M.RESISTOR CH 1/10W 0	1	
QR312	MUN2113	TRANSISTOR-RESISTOR	1		R358	ERJ6QMYJ103	M.RESISTOR CH 1/10W 10K	1	
QR316	MUN2213	TRANSISTOR-RESISTOR	1		R359	ERJ6QMYJ124	M.RESISTOR CH 1/10W 120K	1	
QR320	XN1212	TRANSISTOR-RESISTOR	1		R361	ERJ6QMYJ223	M.RESISTOR CH 1/10W 22K	1	
QR322	MUN2213	TRANSISTOR-RESISTOR	1		R362	ERJ6QMYZ0R00	M.RESISTOR CH 1/10W 0	1	
QR1101	UN2114	TRANSISTOR-RESISTOR	1		R363	ERJ6QMYJ123	M.RESISTOR CH 1/10W 12K	1	
QR3001	MUN2111	TRANSISTOR-RESISTOR	1		R364	ERJ6QMYJ682	M.RESISTOR CH 1/10W 6.8K	1	

Ref.No.	Part No.	Part Name & Description	Pcs	Remarks	Ref.No.	Part No.	Part Name & Description	Pcs	Remarks
R367	ERJ6GMYJ103	M.RESISTOR CH 1/10W 10K	1		R2014	ERJ6GMYJ221	M.RESISTOR CH 1/10W 220	1	
R369	ERJ6GMYJ393	M.RESISTOR CH 1/10W 39K	1		R2015	ERJ6GMYJ471	M.RESISTOR CH 1/10W 470	1	
R371	ERJ6GMYJ000	M.RESISTOR CH 1/10W 0	1		R2016	ERDS2FJ6R8	C.RESISTOR 1/4W 6.8	1	
R372	ERJ6GMYJ103	M.RESISTOR CH 1/10W 10K	1		R2017	ERJ6GMYJ103	M.RESISTOR CH 1/10W 10K	1	
R373	ERJ6GMYJ334	M.RESISTOR CH 1/10W 330K	1		R2023, 24	ERJ6GMYJ223	M.RESISTOR CH 1/10W 22K	2	
R375	ERJ6GMYJ682	M.RESISTOR CH 1/10W 6.8K	1		R2026, 27	ERJ6GMYJ223	M.RESISTOR CH 1/10W 22K	2	
R376	ERJ6GMYJ103	M.RESISTOR CH 1/10W 10K	1		R2028	ERJ6GMYJ272	M.RESISTOR CH 1/10W 2.7K	1	
R377	ERJ6GMYJ681	M.RESISTOR CH 1/10W 680	1		R2040	ERJ6GMYJ222	M.RESISTOR CH 1/10W 2.2K	1	
R378	ERJ6GMYJ102	M.RESISTOR CH 1/10W 1K	1		R2041	ERJ6GMYJ562	M.RESISTOR CH 1/10W 5.6K	1	
RO702	ERJ3GEYJ272	M.RESISTOR CH 1/16W 2.7K	1		R2042	ERJ6GMYJ103	M.RESISTOR CH 1/10W 10K	1	
RO704	ERJ3GEYJ222	M.RESISTOR CH 1/16W 2.2K	1		R2045	ERJ6GMYJ000	M.RESISTOR CH 1/10W 0	1	
RO705	ERJ3GEYJ562	M.RESISTOR CH 1/16W 5.6K	1		R3001, 02	ERJ6GMYJ223	M.RESISTOR CH 1/10W 22K	2	
RO706, 07	ERJ3GEYJ272	M.RESISTOR CH 1/16W 2.7K	2		R3003	ERJ6GMYJ222	M.RESISTOR CH 1/10W 2.2K	1	
RO708	ERJ3GEYJ152	M.RESISTOR CH 1/16W 1.5K	1		R3004	ERJ6GMYJ272	M.RESISTOR CH 1/10W 2.7K	1	
RO709	ERJ3GEYJ105	M.RESISTOR CH 1/16W 1M	1		R3005	ERJ6GMYJ332	M.RESISTOR CH 1/10W 3.3K	1	
RO710	ERJ6GEYJ154	M.RESISTOR CH 1/10W 150K	1		R3007	ERJ6GMYJ222	M.RESISTOR CH 1/10W 2.2K	1	
RO713	ERJ3GEYJ331	M.RESISTOR CH 1/16W 330	1		R3008, 09	ERJ6GMYJ473	M.RESISTOR CH 1/10W 47K	2	
RO714	ERJ3GEYJ470	M.RESISTOR CH 1/16W 47	1		R3010	ERJ6GMYJ683	M.RESISTOR CH 1/10W 68K	1	
RO715	ERJ3GEYJ183	M.RESISTOR CH 1/16W 18K	1		R3011	ERJ6GMYJ103	M.RESISTOR CH 1/10W 10K	1	
RO716	VRE0040E151	M.RESISTOR CH 1/10W 150	1		R3012	ERJ6GMYJ473	M.RESISTOR CH 1/10W 47K	1	
RO717	ERJ3GEYJ000	M.RESISTOR CH 1/16W 0	1		R3013	ERJ6GMYJ103	M.RESISTOR CH 1/10W 10K	1	
RO718	ERJ3GEYJ102	M.RESISTOR CH 1/16W 1K	1		R3014	ERJ6GMYJ102	M.RESISTOR CH 1/10W 1K	1	
RO719	ERJ6GEYJ822	M.RESISTOR CH 1/10W 8.2K	1		R3017	ERJ6GMYJ333	M.RESISTOR CH 1/10W 33K	1	
RO720	ERJ3GEYJ102	M.RESISTOR CH 1/16W 1K	1		R3018	ERJ6GMYJ223	M.RESISTOR CH 1/10W 22K	1	
RO722	ERJ3GEYJ101	M.RESISTOR CH 1/16W 100	1		R3019, 20	ERJ6GMYJ561	M.RESISTOR CH 1/10W 560	2	
RO728	ERJ3GEYJ471	M.RESISTOR CH 1/16W 470	1		R3021	ERJ6GMYJ391	M.RESISTOR CH 1/10W 390	1	
RO729	ERJ3GEYJ102	M.RESISTOR CH 1/16W 1K	1		R3022	ERJ6GMYJ102	M.RESISTOR CH 1/10W 1K	1	
RO732	ERJ3GEYJ471	M.RESISTOR CH 1/16W 470	1		R3023, 24	ERJ6GMYJ821	M.RESISTOR CH 1/10W 820	2	
RO783	ERJ3GEYJ393	M.RESISTOR CH 1/16W 39K	1		R3025	ERJ6GMYJ122	M.RESISTOR CH 1/10W 1.2K	1	
R1002	ERDS2TJ561	C.RESISTOR 1/4W 560	1		R3026	ERJ6GMYJ102	M.RESISTOR CH 1/10W 1K	1	
R1003	ERJ6GMYG272	M.RESISTOR CH 1/10W 2.7K	1		R3029	ERJ6GMYJ222	M.RESISTOR CH 1/10W 2.2K	1	
R1004	ERJ6GMYJ114	M.RESISTOR CH 1/10W 110K	1		R3030	ERJ6GMYJ103	M.RESISTOR CH 1/10W 10K	1	
R1005	ERJ6GMYG272	M.RESISTOR CH 1/10W 2.7K	1		R3033	ERJ6GMYJ223	M.RESISTOR CH 1/10W 22K	1	
R1006	ERJ6GMYJ122	M.RESISTOR CH 1/10W 1.2K	1		R3034	ERJ6GMYJ103	M.RESISTOR CH 1/10W 10K	1	
R1007	ERJ6GMYJ102	M.RESISTOR CH 1/10W 1K	1		R3037-39	ERJ6GMYJ102	M.RESISTOR CH 1/10W 1K	3	
R1101	ERG12SJ153	M.RESISTOR 1/2W 15K	1		R3040	ERJ6GMYJ122	M.RESISTOR CH 1/10W 1.2K	1	
R1102	ERG3SJ563	M.RESISTOR 3W 56K	1		R3041	ERJ6GMYJ561	M.RESISTOR CH 1/10W 560	1	
R1104	ERJ6GMYJ391	M.RESISTOR CH 1/10W 390	1		R3042	ERJ6GMYJ122	M.RESISTOR CH 1/10W 1.2K	1	
R1105	ERG12SJ153	M.RESISTOR 1/2W 15K	1		R3043	ERJ6GMYJ223	M.RESISTOR CH 1/10W 22K	1	
R1107	ERJ6GEYJ164	M.RESISTOR CH 1/10W 160K	1		R3044	ERJ6GMYJ683	M.RESISTOR CH 1/10W 68K	1	
R1108	ERJ6GMYJ105	M.RESISTOR CH 1/10W 1M	1		R3045	ERJ6GMYJ390	M.RESISTOR CH 1/10W 39	1	
R1109	ERJ6GMYJ221	M.RESISTOR CH 1/10W 220	1		R3046	ERJ6GMYJ473	M.RESISTOR CH 1/10W 47K	1	
R1110	ERJ6GMYJ822	M.RESISTOR CH 1/10W 8.2K	1		R3047	ERJ6GMYJ333	M.RESISTOR CH 1/10W 33K	1	
R1111	ERDS2FJ102	C.RESISTOR 1/4W 1K	1		R3048	ERJ6GMYJ222	M.RESISTOR CH 1/10W 2.2K	1	
R1112	ERJ8GEYJ304	M.RESISTOR CH 1/8W 300K	1		R3049	ERJ6GMYG821	M.RESISTOR CH 1/10W 820	1	
R1113	ERJ8GEYJ474	M.RESISTOR CH 1/8W 470K	1		R3050	ERJ6GMYG123	M.RESISTOR CH 1/10W 12K	1	
R1114	ERX12SJR75	M.RESISTOR 1/2W 0.75	1		R3051	ERJ6GMYG512	M.RESISTOR CH 1/10W 5.1K	1	
R1115	ERJ6GMYJ103	M.RESISTOR CH 1/10W 10K	1		R3052	ERJ6GMYG272	M.RESISTOR CH 1/10W 2.7K	1	
R1116	ERJ6GMYJ100	M.RESISTOR CH 1/10W 10	1		R3053	ERJ6GMYG302	M.RESISTOR CH 1/10W 3K	1	
R1117	ERJ6GMYJ472	M.RESISTOR CH 1/10W 4.7K	1		R3054	ERJ6GMYJ102	M.RESISTOR CH 1/10W 1K	1	
R1118	ERJ8GEYJ000	M.RESISTOR CH 1/8W 0	1		R3055	ERJ6GMYJ823	M.RESISTOR CH 1/10W 82K	1	
R1122	ERC12AGH334	S.RESISTOR 1/2W 330K	1		R3056	ERJ6GMYJ473	M.RESISTOR CH 1/10W 47K	1	
R1123	ERJ6GMYJ000	M.RESISTOR CH 1/10W 0	1		R3057	ERJ6GMYJ222	M.RESISTOR CH 1/10W 2.2K	1	
R1124	ERJ6GEYK475	M.RESISTOR CH 1/10W 4.7M	1		R3058	ERJ6GMYG821	M.RESISTOR CH 1/10W 820	1	
R1125	ERJ6GMYJ271	M.RESISTOR CH 1/10W 270	1		R3059	ERJ6GMYG123	M.RESISTOR CH 1/10W 12K	1	
R1127	ERJ6GMYJ333	M.RESISTOR CH 1/10W 33K	1		R3060	ERJ6GMYG512	M.RESISTOR CH 1/10W 5.1K	1	
R1128	ERJ6GMYJ332	M.RESISTOR CH 1/10W 3.3K	1		R3061	ERJ6GMYG272	M.RESISTOR CH 1/10W 2.7K	1	
R1129	ERJ6GMYJ223	M.RESISTOR CH 1/10W 22K	1		R3062	ERJ6GMYG302	M.RESISTOR CH 1/10W 3K	1	
R1131	ERJ6GMYG620	M.RESISTOR CH 1/10W 62	1		R3063	ERJ6GMYJ222	M.RESISTOR CH 1/10W 2.2K	1	
R1132	ERJ6GMYG302	M.RESISTOR CH 1/10W 3K	1		R3064, 65	ERJ6GMYJ103	M.RESISTOR CH 1/10W 10K	2	
R1135	ERJ8GEYJ274	M.RESISTOR CH 1/8W 270K	1		R3066	ERJ6GMYJ561	M.RESISTOR CH 1/10W 560	1	
R1136	ERJ8GEYJ474	M.RESISTOR CH 1/8W 470K	1		R3067	ERJ6GMYJ273	M.RESISTOR CH 1/10W 27K	1	
R1137	ERG12SJ153	M.RESISTOR 1/2W 15K	1		R3068, 69	ERJ6GMYJ103	M.RESISTOR CH 1/10W 10K	2	
R2001	ERJ6GMYG512	M.RESISTOR CH 1/10W 5.1K	1		R3070	ERJ6GMYJ222	M.RESISTOR CH 1/10W 2.2K	1	
R2002	ERJ6GMYG913	M.RESISTOR CH 1/10W 91K	1		R3073	ERJ6GMYJ103	M.RESISTOR CH 1/10W 10K	1	
R2003	ERDS2FJ7R5	C.RESISTOR 1/4W 7.5	1		R3076, 77	ERJ6GMYJ103	M.RESISTOR CH 1/10W 10K	2	
R2004	ERDS2TJ102	C.RESISTOR 1/4W 1K	1		R3079	ERJ6GMYJ334	M.RESISTOR CH 1/10W 330K	1	
R2005, 06	ERJ6GMYJ102	M.RESISTOR CH 1/10W 1K	2		R3080	ERJ6GMYJ000	M.RESISTOR CH 1/10W 0	1	
R2007	ERJ6GMYJ103	M.RESISTOR CH 1/10W 10K	1		R4001	ERJ6GMYJ332	M.RESISTOR CH 1/10W 3.3K	1	
R2008	ERJ6GMYJ222	M.RESISTOR CH 1/10W 2.2K	1		R4003	ERJ6GMYJ221	M.RESISTOR CH 1/10W 220	1	
R2009	ERDS2FJ7R5	C.RESISTOR 1/4W 7.5	1		R4004, 05	ERJ6GMYJ472	M.RESISTOR CH 1/10W 4.7K	2	
R2010	ERJ6GMYJ222	M.RESISTOR CH 1/10W 2.2K	1		R4006, 07	ERDS2TJ472	C.RESISTOR 1/4W 4.7K	2	
R2011	ERJ6GMYJ102	M.RESISTOR CH 1/10W 1K	1		R4008, 09	ERJ6GMYJ273	M.RESISTOR CH 1/10W 27K	2	
R2012	ERDS2FJ6R8	C.RESISTOR 1/4W 6.8	1		R4014	ERJ6GMYJ562	M.RESISTOR CH 1/10W 5.6K	1	
R2013	ERJ6GMYJ103	M.RESISTOR CH 1/10W 10K	1		R4018	ERJ6GMYJ333	M.RESISTOR CH 1/10W 33K	1	

Ref.No.	Part No.	Part Name & Description	Pcs	Remarks	Ref.No.	Part No.	Part Name & Description	Pcs	Remarks
R4043	ERJ6GMYJ683	M.RESISTOR CH 1/10W 68K	1		R5006	ERJ6GMYJ124	M.RESISTOR CH 1/10W 120K	1	
R4046	ERJ6GMYJ273	M.RESISTOR CH 1/10W 27K	1		R5007	ERJ6GMYJ223	M.RESISTOR CH 1/10W 22K	1	
R4055	ERG2SJ821	M.RESISTOR 2W 820	1		R5012	ERJ6GMYJ563	M.RESISTOR CH 1/10W 56K	1	
R4057	ERJ6GMYJ333	M.RESISTOR CH 1/10W 33K	1		R5013	ERJ6GMYG123	M.RESISTOR CH 1/10W 12K	1	
R4064-66	ERGLSJ270	M.RESISTOR 1W 27	3		R5014	ERJ6GMYG223	M.RESISTOR CH 1/10W 22K	1	
R4067,68	ERJ6GMYJ393	M.RESISTOR CH 1/10W 39K	2		R5016,17	ERJ6GMYJ102	M.RESISTOR CH 1/10W 1K	2	
R4071,72	ERJ6GMYJ221	M.RESISTOR CH 1/10W 220	2		R5018	ERJ6GMYJ123	M.RESISTOR CH 1/10W 12K	1	
R4073	ERJ6GMZOR00	M.RESISTOR CH 1/10W 0	1		R5019	ERJ6GMYJ682	M.RESISTOR CH 1/10W 6.8K	1	
R4074	ERJ6GMYJ221	M.RESISTOR CH 1/10W 220	1		R5020	ERJ6GMYJ102	M.RESISTOR CH 1/10W 1K	1	
R4075	ERJ6GMZOR00	M.RESISTOR CH 1/10W 0	1		R5021,22	ERJ6GMYJ681	M.RESISTOR CH 1/10W 680	2	
R4086	ERJ6GMYJ221	M.RESISTOR CH 1/10W 220	1		R5023	ERJ6GMYJ271	M.RESISTOR CH 1/10W 270	1	
R4090,91	ERJ6GMYJ392	M.RESISTOR CH 1/10W 3.9K	2		R5025	ERJ6GMYJ102	M.RESISTOR CH 1/10W 1K	1	
R4092	ERJ6GEYJ101	M.RESISTOR CH 1/10W 100	1		R5027	ERJ6GMYJ122	M.RESISTOR CH 1/10W 1.2K	1	
R4501,02	ERJ3GEYOR00	M.RESISTOR CH 1/16W 0	2		R5028,29	ERJ6GMYJ102	M.RESISTOR CH 1/10W 1K	2	
R4503	ERJ3GEYG223	M.RESISTOR CH 1/16W 22K	1		R5030	ERJ6GMYJ471	M.RESISTOR CH 1/10W 470	1	
R4504,05	ERJ3GEYOR00	M.RESISTOR CH 1/16W 0	2		R5031	ERJ6GMYJ102	M.RESISTOR CH 1/10W 1K	1	
R4506,07	ERJ3GEYJ473	M.RESISTOR CH 1/16W 47K	2		R6001	ERJ6GMYJ201	M.RESISTOR CH 1/10W 200	1	
R4508	ERJ3GEYG224	M.RESISTOR CH 1/16W 220K	1		R6002	ERJ6GMYG272	M.RESISTOR CH 1/10W 2.7K	1	
R4509	VRB0071E622	M.RESISTOR CH 1/10W 6.2K	1		R6003	ERJ6GMYJ272	M.RESISTOR CH 1/10W 2.7K	1	
R4511	ERJ3GEYG273	M.RESISTOR CH 1/16W 27K	1		R6004	ERJ6GMYJ102	M.RESISTOR CH 1/10W 1K	1	
R4512	VRB0071E163	M.RESISTOR CH 1/10W 16K	1		R6005	ERJ6GMYJ333	M.RESISTOR CH 1/10W 33K	1	
R4513	ERJ3GEYG103	M.RESISTOR CH 1/16W 10K	1		R6006,07	ERJ6GMYJ683	M.RESISTOR CH 1/10W 68K	2	
R4518,19	ERJ3GEYOR00	M.RESISTOR CH 1/16W 0	2		R6008	ERJ6GMYJ272	M.RESISTOR CH 1/10W 2.7K	1	
R4522	ERJ3GEYJ225	M.RESISTOR CH 1/16W 2.2M	1		R6009	ERJ6GMYJ333	M.RESISTOR CH 1/10W 33K	1	
R4527	VRB0071E333	M.RESISTOR 33K	1		R6010	ERDS2TJ333	C.RESISTOR 1/4W 33K	1	
R4528	VRB0071E153	M.RESISTOR 15K	1		R6011,12	ERJ6GMYG223	M.RESISTOR CH 1/10W 22K	2	
R4529	ERJ3GEYG562	M.RESISTOR CH 1/16W 5.6K	1		R6013	ERJ6GMYJ103	M.RESISTOR CH 1/10W 10K	1	
R4530	ERJ3GEYJ334	M.RESISTOR CH 1/16W 330K	1		R6015	ERJ6GMZOR00	M.RESISTOR CH 1/10W 0	1	
R4534	ERJ3GEYJ102	M.RESISTOR CH 1/16W 1K	1		R6017	ERDS2TJ271	C.RESISTOR 1/4W 270	1	
R4535	ERJ3GEYJ104	M.RESISTOR CH 1/16W 100K	1		R6018-20	ERJ6GMZOR00	M.RESISTOR CH 1/10W 0	3	
R4539	ERJ3GEYJ104	M.RESISTOR CH 1/16W 100K	1		R6021	ERJ6GMYJ102	M.RESISTOR CH 1/10W 1K	1	
R4541	ERJ3GEYJ103	M.RESISTOR CH 1/16W 10K	1		R6022	ERJ6GMZOR00	M.RESISTOR CH 1/10W 0	1	
R4542	ERJ3GEYJ222	M.RESISTOR CH 1/16W 2.2K	1		R6023	ERJ6GMYJ101	M.RESISTOR CH 1/10W 100	1	
R4543	ERJ3GEYJ472	M.RESISTOR CH 1/16W 4.7K	1		R6024	ERJ6GMYJ104	M.RESISTOR CH 1/10W 1M	1	
R4551,52	ERJ3GEYJ393	M.RESISTOR CH 1/16W 39K	2		R6025	ERJ6GMYJ333	M.RESISTOR CH 1/10W 33K	1	
R4553,54	ERJ3GEYJ273	M.RESISTOR CH 1/16W 27K	2		R6026	ERJ6GEYJ103	M.RESISTOR CH 1/10W 10K	1	
R4558	ERJ3GEYG224	M.RESISTOR CH 1/16W 220K	1		R6027	ERJ6GMZOR00	M.RESISTOR CH 1/10W 0	1	
R4561	ERJ3GEYG273	M.RESISTOR CH 1/16W 27K	1		R6028	ERJ6GMYJ101	M.RESISTOR CH 1/10W 100	1	
R4562	VRB0034E10C	M.RESISTOR CH 1/10W	1		R6029	ERDS2TJ103	C.RESISTOR 1/4W 10K	1	
R4563	ERJ3GEYG272	M.RESISTOR CH 1/16W 2.7K	1		R6030	ERJ6GMYJ101	M.RESISTOR CH 1/10W 100	1	
R4568,69	ERJ3GEYJ273	M.RESISTOR CH 1/16W 27K	2		R6031	ERJ6GMYJ222	M.RESISTOR CH 1/10W 2.2K	1	
R4572	ERJ3GEYJ473	M.RESISTOR CH 1/16W 47K	1		R6032	ERJ6GMYJ102	M.RESISTOR CH 1/10W 1K	1	
R4573	ERJ3GEYJ152	M.RESISTOR CH 1/16W 1.5K	1		R6034,35	ERJ6GMYJ272	M.RESISTOR CH 1/10W 2.7K	2	
R4577	ERJ3GEYJ473	M.RESISTOR CH 1/16W 47K	1		R6036	ERJ6GMZOR00	M.RESISTOR CH 1/10W 0	1	
R4578	VRB0071E473	M.RESISTOR CH 1/10W 47K	1		R6037,38	ERJ6GMYJ221	M.RESISTOR CH 1/10W 220	2	
R4581	ERJ3GEYJ104	M.RESISTOR CH 1/16W 100K	1		R6040,41	ERJ6GMYJ272	M.RESISTOR CH 1/10W 2.7K	2	
R4583	ERJ3GEYJ102	M.RESISTOR CH 1/16W 1K	1		R6042	ERJ6GMYJ103	M.RESISTOR CH 1/10W 10K	1	
R4584	ERJ3GEYJ472	M.RESISTOR CH 1/16W 4.7K	1		R6043,44	ERJ6GMYJ221	M.RESISTOR CH 1/10W 220	2	
R4585,86	ERJ3GEYOR00	M.RESISTOR CH 1/16W 0	2		R6045	ERJ6GMYJ392	M.RESISTOR CH 1/10W 3.9K	1	
R4587,88	ERJ3GEYJ273	M.RESISTOR CH 1/16W 27K	2		R6047-50	ERJ6GMYJ102	M.RESISTOR CH 1/10W 1K	4	
R4591	ERJ3GEYJ473	M.RESISTOR CH 1/16W 47K	1		R6051	ERJ6GMYJ101	M.RESISTOR CH 1/10W 100	1	
R4592	ERJ3GEYJ563	M.RESISTOR CH 1/16W 56K	1		R6052	ERJ6GMZOR00	M.RESISTOR CH 1/10W 0	1	
R4593	ERJ3GEYJ472	M.RESISTOR CH 1/16W 4.7K	1		R6053-55	ERJ6GMYJ102	M.RESISTOR CH 1/10W 1K	3	
R4594	ERJ3GEYJ473	M.RESISTOR CH 1/16W 47K	1		R6056,57	ERJ6GMZOR00	M.RESISTOR CH 1/10W 0	2	
R4596	ERJ3GEYG473	M.RESISTOR CH 1/16W 47K	1		R6058	ERJ6GMYJ103	M.RESISTOR CH 1/10W 10K	1	
R4597	ERJ3GEYJ103	M.RESISTOR CH 1/16W 10K	1		R6059	ERJ6GMYJ102	M.RESISTOR CH 1/10W 1K	1	
R4598,99	ERJ3GEYG104	M.RESISTOR CH 1/16W 100K	2		R6060	ERJ6GMYJ183	M.RESISTOR CH 1/10W 18K	1	
R4603	ERJ3GEYG163	M.RESISTOR CH 1/16W 16K	1		R6061	ERJ6GMYJ472	M.RESISTOR CH 1/10W 4.7K	1	
R4606	VRB0071E562	M.RESISTOR 5.6K	1		R6062	ERJ6GMYJ244	M.RESISTOR CH 1/10W 240K	1	
R4610	ERJ3GEYJ473	M.RESISTOR CH 1/16W 47K	1		R6063,64	ERJ6GMYJ103	M.RESISTOR CH 1/10W 10K	2	
R4611	ERJ3GEYJ101	M.RESISTOR CH 1/16W 100	1		R6068	ERJ6GMYJ392	M.RESISTOR CH 1/10W 3.9K	1	
R4612	VRB0071E331	M.RESISTOR CH 1/10W 330	1		R6069	ERJ6GMYJ103	M.RESISTOR CH 1/10W 10K	1	
R4613	ERJ3GEYG394	M.RESISTOR CH 1/16W 390K	1		R6071	ERJ6GEYJ101	M.RESISTOR CH 1/10W 100	1	
R4615	VRB0071E133	M.RESISTOR CH 1/10W 13K	1		R6072	ERJ6GEYOR00	M.RESISTOR CH 1/10W 0	1	
R4616	ERJ3GEYJ105	M.RESISTOR CH 1/16W 1M	1		R6073	ERJ6GMYJ101	M.RESISTOR CH 1/10W 100	1	
R4638	ERJ3GEYOR00	M.RESISTOR CH 1/16W 0	1		R6075	ERJ6GMYJ103	M.RESISTOR CH 1/10W 10K	1	
R4649	ERJ3GEYJ470	M.RESISTOR CH 1/16W 47	1		R6077	ERJ6GMYJ103	M.RESISTOR CH 1/10W 10K	1	
R4653	ERJ3GEYJ331	M.RESISTOR CH 1/16W 330	1		R6079	ERJ6GMYJ103	M.RESISTOR CH 1/10W 10K	1	
R4656	ERJ3GEYG243	M.RESISTOR CH 1/16W 24K	1		R6082	ERJ6GMYJ822	M.RESISTOR CH 1/10W 8.2K	1	
R4657	ERJ3GEYJ392	M.RESISTOR CH 1/16W 3.9K	1		R6083	ERJ6GMYJ243	M.RESISTOR CH 1/10W 24K	1	
R4666	ERJ3GEYJ471	M.RESISTOR CH 1/16W 470	1		R7301	ERJ6GEYJ182	M.RESISTOR CH 1/10W 1.8K	1	
R4671	ERJ3GEYOR00	M.RESISTOR CH 1/16W 0	1		R7302	ERJ3GEYJ472	M.RESISTOR CH 1/16W 4.7K	1	
R5003	ERJ6GMYJ102	M.RESISTOR CH 1/10W 1K	1		R7303	ERJ3GEYJ152	M.RESISTOR CH 1/16W 1.5K	1	
R5004	ERJ6GMYJ271	M.RESISTOR CH 1/10W 270	1		R7308	ERJ3GEYJ121	M.RESISTOR CH 1/16W 120	1	
R5005	ERJ6GMYJ472	M.RESISTOR CH 1/10W 4.7K	1		R7309,10	ERJ6GEYJ561	M.RESISTOR CH 1/10W 560	2	

Ref.No.	Part No.	Part Name & Description	Pcs	Remarks	Ref.No.	Part No.	Part Name & Description	Pcs	Remarks
R7311	ERJ6GEYJ221	M.RESISTOR CH 1/10W 220	1		X301	VSX0162	CRYSTAL OSCILLATOR	1	
R7312	ERJ6GEYJ152	M.RESISTOR CH 1/10W 1.5K	1		X0703	EFCT5R5MW5	CRYSTAL OSCILLATOR	1	
R7313, 14	ERJ3GEYG272	M.RESISTOR CH 1/16W 2.7K	2		X0704	VLF1035	FILTER	1	
R7315	ERJ3GEYJ114	M.RESISTOR CH 1/16W 110K	1		X6001	VSX0583	CRYSTAL OSCILLATOR	1	
R7316	ERJ3GEYJ223	M.RESISTOR CH 1/16W 22K	1		X7302	VSX0683	CRYSTAL OSCILLATOR	1	
R7317	ERJ3GEYJ473	M.RESISTOR CH 1/16W 47K	1		X7303	EF0GC4004A4	CRYSTAL OSCILLATOR	1	
R7320	ERJ3GEYJ104	M.RESISTOR CH 1/16W 100K	1						
R7321-23	ERJ3GEYJ333	M.RESISTOR CH 1/16W 33K	3						
R7324	ERJ3GEYJ103	M.RESISTOR CH 1/16W 10K	1						
R7325	ERJ3GEYG122	M.RESISTOR CH 1/16W 1.2K	1				MISCELLANEOUS		
R7326	ERJ3GEYJ104	M.RESISTOR CH 1/16W 100K	1			EYF52BC	FUSE HOLDER	2	<1>
R7327-29	ERJ3GEYJ333	M.RESISTOR CH 1/16W 33K	3			VSC4141	SW SHIELD COVER	1	
R7330	ERJ3GEYOR00	M.RESISTOR CH 1/16W 0	1			VMD1926	LED HOLDER	1	FOR D6001
R7332	ERJ3GEYG152	M.RESISTOR CH 1/16W 1.5K	1			VMD1927	PHOTO TRANSISTOR HOLDER	1	FOR Q6002
R7333	ERJ3GEYJ104	M.RESISTOR CH 1/16W 100K	1			ENG47229G	TUNER	1	<1>
R7334-36	ERJ3GEYJ333	M.RESISTOR CH 1/16W 33K	3			VMD2029	REEL GUIDE	1	
R7337	ERJ3GEYOR00	M.RESISTOR CH 1/16W 0	1			VSC3553	SHIELD COVER (MAIN)	1	FOR NICAM C.B.A.
R7339	ERJ3GEYG152	M.RESISTOR CH 1/16W 1.5K	1			VSC3555	SHIELD COVER (BOTTOM)	1	FOR NICAM C.B.A.
R7341-43	ERJ6GEYJ471	M.RESISTOR CH 1/10W 470	3			VMP4471	TV DEMODULATOR ANGLE	1	FOR TV DEMODU. C.B.A.
R7344	ERJ3GEYJ102	M.RESISTOR CH 1/16W 1K	1						
R7346	ERJ3GEYJ473	M.RESISTOR CH 1/16W 47K	1						
R7350	ERJ3GEYJ102	M.RESISTOR CH 1/16W 1K	1						
R7351	ERJ3GEYJ473	M.RESISTOR CH 1/16W 47K	1						
R7352-56	ERJ3GEYJ103	M.RESISTOR CH 1/16W 10K	5			■ VEPO3B27F	INPUT/OUTPUT C.B.A.		(RTL)NV-HD650A
R7357	ERJ3GEYJ472	M.RESISTOR CH 1/16W 4.7K	1						
R7362	ERJ3GEYJ682	M.RESISTOR CH 1/16W 6.8K	1						
R7366	ERJ3GEYJ102	M.RESISTOR CH 1/16W 1K	1		C3901	ECEA1CKA470	E.CAPACITOR 16V 47U	1	
R7367	ERJ3GEYJ103	M.RESISTOR CH 1/16W 10K	1		C3902	ECUM1H103ZFN	C.CAPACITOR CH 50V 0.01U	1	
R7368, 69	ERJ3GEYJ102	M.RESISTOR CH 1/16W 1K	2		C3903	ECAQJM471	E.CAPACITOR 6.3V 470U	1	
R7370	ERJ3GEYJ103	M.RESISTOR CH 1/16W 10K	1		C3904	ECUM1H104ZFN	C.CAPACITOR CH 50V 0.1U	1	
R7371	ERJ3GEYJ102	M.RESISTOR CH 1/16W 1K	1		C3905	ECEA1CKA470	E.CAPACITOR 16V 47U	1	
R7376, 77	ERJ3GEYJ104	M.RESISTOR CH 1/16W 100K	2		C3908, 09	ECUM1H681JCN	C.CAPACITOR CH 50V 680P	2	
R7378	ERJ3GEYJ152	M.RESISTOR CH 1/16W 1.5K	1		C3910	ECUM1H104ZFN	C.CAPACITOR CH 50V 0.1U	1	
R7379	ERJ3GEYOR00	M.RESISTOR CH 1/16W 0	1		C3911	ECEA1CKA470	E.CAPACITOR 16V 47U	1	
R7380	ERJ3GEYG302	M.RESISTOR CH 1/16W 3K	1		C7701	ECEA1HKA010	E.CAPACITOR 50V 1U	1	
R7381	ERJ3GEYOR00	M.RESISTOR CH 1/16W 0	1		C7702	ECUM1H222KBN	C.CAPACITOR CH 50V 2200P	1	
R7382	ERJ3GEYG302	M.RESISTOR CH 1/16W 3K	1		C7703	ECUM1H180JCN	C.CAPACITOR CH 50V 18P	1	
R7383	ERJ3GEYOR00	M.RESISTOR CH 1/16W 0	1		C7704	ECUM1H102JCN	C.CAPACITOR CH 50V 1000P	1	
R7384	ERJ3GEYG302	M.RESISTOR CH 1/16W 3K	1		C7705, 06	ECUM1H103ZFN	C.CAPACITOR CH 50V 0.01U	2	
R7601	ERJ6GMJ151	M.RESISTOR CH 1/10W 150	1		C7707	ECEA0JKA220	E.CAPACITOR 6.3V 220U	1	
R7602, 03	ERJ6GMJ1683	M.RESISTOR CH 1/10W 68K	2		C7708	ECUM1H100DCN	C.CAPACITOR CH 50V 10P	1	
R7604	ERJ6GMJ151	M.RESISTOR CH 1/10W 150	1		C7709	ECUM1H300JCN	C.CAPACITOR CH 50V 30P	1	
R7605-07	ERJ6GMJ102	M.RESISTOR CH 1/10W 1K	3		C7710	ECEA0JKA470	E.CAPACITOR 6.3V 47U	1	
R7608	ERJ6GMZOR00	M.RESISTOR CH 1/10W 0	1		C7711	ECUM1H103ZFN	C.CAPACITOR CH 50V 0.01U	1	
R7609	ERJ6GMJ102	M.RESISTOR CH 1/10W 1K	1		C7716	ECUM1H103ZFN	C.CAPACITOR CH 50V 0.01U	1	
R7610	ERJ6GMJ222	M.RESISTOR CH 1/10W 2.2K	1		C7717	ECEA0JKA470	E.CAPACITOR 6.3V 47U	1	
R7611	ERJ6GMJ332	M.RESISTOR CH 1/10W 3.3K	1						
R7612	ERG2SJ331	M.RESISTOR 2W 330	1		D3901	MA4056M	DIODE	1	
R7614	ERJ6GMJ561	M.RESISTOR CH 1/10W 560	1		D7701	SVC251SPA	DIODE	1	
R7615	ERJ6GMJ103	M.RESISTOR CH 1/10W 10K	1						
R7616	ERG2SJ331	M.RESISTOR 2W 330	1		IC3901	MC14051BF	IC	1	
R7617	ERJ6GEYOR00	M.RESISTOR CH 1/10W 0	1		IC3902	MC14052BF	IC	1	
					IC7701	UPD4646CS05	IC	1	
TO703	EQV5EC071A	TRANSFORMER	1						
TO704	EQV5EC072A	TRANSFORMER	1						
T1101	VLT0750	TRANSFORMER	1	<1>	K7701	ERJ6GEYOR00	M.RESISTOR CH 1/10W 0	1	
					K7703	ERJ6GEYOR00	M.RESISTOR CH 1/10W 0	1	
VR301	EVMEASAO0B14	V.RESISTOR	1						
VR302	EVMEASAO0B53	V.RESISTOR 5K	1		L3901	VLQ0599J330	COIL 33UH	1	
VR303	EVMEASAO0B24	V.RESISTOR	1		L3902	VLQ0599J680	COIL 68UH	1	
VR0701	EVNCBAA00B24	V.RESISTOR 20K	1		L3903	VLQ0599J101	COIL 100UH	1	
VR2001	EVNCYAA03B54	V.RESISTOR 50K	1		L7701	VLQ0599J4R7	COIL 4.7UH	1	
VR3001	EVNCYAA03B23	V.RESISTOR 2K	1		L7702-04	VLQ0599J330	COIL 33UH	3	
VR3012, 13	EVNCYAA03B52	V.RESISTOR 500	2						
VR3014	EVNCYAA03B54	V.RESISTOR 50K	1						
VR4501	EVMECSAO0B53	V.RESISTOR	1		P3901	VJS3537B008G	CONNECTOR (FEMALE) 8P	1	
VR4502	EVMEASAO0BY4	V.RESISTOR	1						
VR4507	EVMEASAO0BY4	V.RESISTOR	1						
VR4509	EVMECSAO0BY3	V.RESISTOR	1		PS3901	VJS3042B020W	CONNECTOR (FEMALE)	1	
VR4550	EVMECSAO0B14	V.RESISTOR 10K	1		PS3902	VJS3042B018W	CONNECTOR (FEMALE) 18P	1	
VR4551, 52	EVMEASAO0B55	V.RESISTOR	2						
VR8001	EVNCYAA03B23	V.RESISTOR 2K	1						
					Q3901	2SB709A	TRANSISTOR	1	

Ref.No.	Part No.	Part Name & Description	Pcs	Remarks
R3901	ERJ6GEYJ471	M.RESISTOR CH 1/10W 470	1	
R3902	ERDS2TJ471	C.RESISTOR 1/4W 470	1	
R3903	ERJ6GEYJ223	M.RESISTOR CH 1/10W 22K	1	
R3904	ERJ6GEYJ750	M.RESISTOR CH 1/10W 75	1	
R3905,06	ERJ6GEYJ391	M.RESISTOR CH 1/10W 390	2	
R3907	ERJ6GEYJ750	M.RESISTOR CH 1/10W 75	1	
R3908,09	ERJ6GEYJ102	M.RESISTOR CH 1/10W 1K	2	
R3910-13	ERJ6GEYJ474	M.RESISTOR CH 1/10W 470K	4	
R7701	ERJ6GEYJ152	M.RESISTOR CH 1/10W 1.5K	1	
R7702	ERJ6GEYJ104	M.RESISTOR CH 1/10W 100K	1	
R7703	ERJ6GEYJ512	M.RESISTOR CH 1/10W 5.1K	1	
S3901	ESD172253	SWITCH	1	
		MISCELLANEOUS		
	VEJ1681	I/O JACK PLATE	1	
	■ VEPO3B27A	INPUT/OUTPUT C.B.A.		(RTL)NV-HD650EA
C3901	ECEA1CKA470	E.CAPACITOR 16V 47U	1	
C3902	ECUM1H1032FN	C.CAPACITOR CH 50V 0.01U	1	
C3903	ECAOJM471	E.CAPACITOR 6.3V 470U	1	
C3904	ECUM1H1042FN	C.CAPACITOR CH 50V 0.1U	1	
C3905	ECEA1CKA470	E.CAPACITOR 16V 47U	1	
C3908,09	ECUM1H681JCN	C.CAPACITOR CH 50V 680P	2	
C3910	ECUM1H1042FN	C.CAPACITOR CH 50V 0.1U	1	
C3911	ECEA1CKA470	E.CAPACITOR 16V 47U	1	
C7701	ECEA1HKA010	E.CAPACITOR 50V 1U	1	
C7702	ECUM1H222KBN	C.CAPACITOR CH 50V 2200P	1	
C7703	ECUM1H180JCN	C.CAPACITOR CH 50V 18P	1	
C7704	ECUM1H102JCN	C.CAPACITOR CH 50V 1000P	1	
C7705,06	ECUM1H1032FN	C.CAPACITOR CH 50V 0.01U	2	
C7707	ECEAOJKA220	E.CAPACITOR 6.3V 220U	1	
C7708	ECUM1H100DCN	C.CAPACITOR CH 50V 10P	1	
C7709	ECUM1H300JCN	C.CAPACITOR CH 50V 30P	1	
C7710	ECEAOJKA470	E.CAPACITOR 6.3V 47U	1	
C7711	ECUM1H1032FN	C.CAPACITOR CH 50V 0.01U	1	
C7716	ECUM1H1032FN	C.CAPACITOR CH 50V 0.01U	1	
C7717	ECEAOJKA470	E.CAPACITOR 6.3V 47U	1	
D3901	MA4056M	DIODE	1	
D7701	SVC251SPA	DIODE	1	
IC3901	MC14051BF	IC	1	
IC3902	MC14052BF	IC	1	
IC7701	UPD6464CS05	IC	1	
K7701	ERJ6GEYOR00	M.RESISTOR CH 1/10W 0	1	
K7703	ERJ6GEYOR00	M.RESISTOR CH 1/10W 0	1	
L3901	VLQ0599J330	COIL 33UH	1	
L3902	VLQ0599J680	COIL 68UH	1	
L3903	VLQ0599J101	COIL 100UH	1	
L7701	VLQ0599J4R7	COIL 4.7UH	1	
L7702-04	VLQ0599J330	COIL 33UH	3	
P3901	VJS3537B008G	CONNECTOR (FEMALE) 8P	1	
PS3901	VJS3042B020W	CONNECTOR (FEMALE)	1	
PS3902	VJS3042B018W	CONNECTOR (FEMALE) 18P	1	

Ref.No.	Part No.	Part Name & Description	Pcs	Remarks
Q3901	2SB709A	TRANSISTOR	1	
R3901	ERJ6GEYJ471	M.RESISTOR CH 1/10W 470	1	
R3902	ERDS2TJ471	C.RESISTOR 1/4W 470	1	
R3903	ERJ6GEYJ223	M.RESISTOR CH 1/10W 22K	1	
R3904	ERJ6GEYJ750	M.RESISTOR CH 1/10W 75	1	
R3905,06	ERJ6GEYJ391	M.RESISTOR CH 1/10W 390	2	
R3907	ERJ6GEYJ750	M.RESISTOR CH 1/10W 75	1	
R3908,09	ERJ6GEYJ102	M.RESISTOR CH 1/10W 1K	2	
R3910-13	ERJ6GEYJ474	M.RESISTOR CH 1/10W 470K	4	
R7701	ERJ6GEYJ152	M.RESISTOR CH 1/10W 1.5K	1	
R7702	ERJ6GEYJ104	M.RESISTOR CH 1/10W 100K	1	
R7703	ERJ6GEYJ512	M.RESISTOR CH 1/10W 5.1K	1	
S3901	ESD172253	SWITCH	1	
		MISCELLANEOUS		
	VEJ1493	I/O JACK PLATE	1	
	■ VEPO4469N	MOTOR DRIVE C.B.A.		(RTL)
C2501,02	ECEA1HKA2R2	E.CAPACITOR 50V 2.2U	2	
C2503	ECA1EM470	E.CAPACITOR 25V 47U	1	
C2504	ECEA1HQR22	E.CAPACITOR 50V 0.22U	1	
C2505	ECEA1HKA010	E.CAPACITOR 50V 1U	1	
C2506	ECA1EM470	E.CAPACITOR 25V 47U	1	
C2507,08	ECUM1E333KBN	C.CAPACITOR CH 25V 0.033U	2	
C2509	ECUM1H1032FN	C.CAPACITOR CH 50V 0.01U	1	
C2510	ECAOJM221	E.CAPACITOR 6.3V 220U	1	
C2511	ECUM1E333KBN	C.CAPACITOR CH 25V 0.033U	1	
C2512	ECQV1H683JM	P.CAPACITOR 50V 0.068U	1	
C2513	ECUM1H1042FN	C.CAPACITOR CH 50V 0.1U	1	
C2514-16	ECUM1E333KBN	C.CAPACITOR CH 25V 0.033U	3	
C2517	ECUM1H680JCN	C.CAPACITOR CH 50V 68P	1	
C2518	ECUM1C4742FN	C.CAPACITOR CH 16V 0.47U	1	
C2519	ECUM1H680JCN	C.CAPACITOR CH 50V 68P	1	
C2520	ECUM1C4742FN	C.CAPACITOR CH 16V 0.47U	1	
C2521	ECUM1H1032FN	C.CAPACITOR CH 50V 0.01U	1	
C2523	ECEA1HKA2R2	E.CAPACITOR 50V 2.2U	1	
C2525	ECEAOJKA470	E.CAPACITOR 6.3V 47U	1	
C2540	ECEA1HKA47	E.CAPACITOR 50V 0.47U	1	
C4712	ECUM1H102JCN	C.CAPACITOR CH 50V 1000P	1	
C4713	ECEA1CKA330	E.CAPACITOR 16V 33U	1	
C4714	EQP1222JZ	P.CAPACITOR 100V 2200P	1	
C4715	ECCD2H181J	C.CAPACITOR 500V 180P	1	
C4716	ECUM1H103KBN	C.CAPACITOR CH 50V 0.01U	1	
C4732	ECUM1H821JCN	C.CAPACITOR CH 50V 820P	1	
C4736	ECUM1H103KBN	C.CAPACITOR CH 50V 0.01U	1	
C4737	ECUM1H472KBN	C.CAPACITOR CH 50V 4700P	1	
C4738	ECEA1CKA330	E.CAPACITOR 16V 33U	1	
C4739	EQB1H333JZ	F.CAPACITOR 50V 0.033U	1	
D2501,02	MA185	DIODE	2	
D4702,03	MA151K	DIODE	2	
IC2501	BA6871S	IC	1	
K4707	ERJ6GM20R00	M.RESISTOR CH 1/10W 0	1	
K4711	ERJ6GM20R00	M.RESISTOR CH 1/10W 0	1	
L2503	VLFO083	COIL	1	
L4702	ELESE471KA	COIL	1	
L4704	ELESE101KA	COIL 100UH	1	
L4705,06	ERJ6GEYOR00	M.RESISTOR CH 1/10W 0	2	

[illegible]

Ref.No.	Part No.	Part Name & Description	Pcs	Remarks
X7501	VSX0608	CRYSTAL OSCILLATOR	1	
X7502	VSX0094	CRYSTAL OSCILLATOR	1	
		MISCELLANEOUS		
	VJF1139	FIP HOLDER	1	
	VMD1047	LED HOLDER	1	
	VMD2035	JOG SHUTTLE HOLDER	1	
	VMD2247	IR RECEIVER HOLDER	1	
	VGU4537	SLIDE KNOB	1	
	VEP07773E	TIMER C.B.A.		(RTL)NV-HD650EA
C7501	ECEA0JKA470	E.CAPACITOR 6.3V 47U	1	
C7502	ECUM1H1042FN	C.CAPACITOR CH 50V 0.1U	1	
C7504	ECUM1H1032FN	C.CAPACITOR CH 50V 0.01U	1	
C7507	ECEA0JKA470	E.CAPACITOR 6.3V 47U	1	
C7508	ECUM1H1042FN	C.CAPACITOR CH 50V 0.1U	1	
C7509	ECEA1HKA100	E.CAPACITOR 50V 10U	1	
C7510	ECUM1H1032FN	C.CAPACITOR CH 50V 0.01U	1	
C7511	ECUM1H560JCN	C.CAPACITOR CH 50V 56P	1	
C7513	ECUM1H270JCN	C.CAPACITOR CH 50V 27P	1	
C7514	ECUM1H220JCN	C.CAPACITOR CH 50V 22P	1	
C7515	ECUM1H1042FN	C.CAPACITOR CH 50V 0.1U	1	
C7516	ECADJ221	E.CAPACITOR 6.3V 220U	1	
C7517	VCE0073	E.CAPACITOR	1	
C7519, 20	ECEA1EKA4R7	E.CAPACITOR 25V 4.7U	2	
C7521	ECUM1H223KEN	C.CAPACITOR CH 50V 0.022U	1	
C7522	ECEA0JKA330	E.CAPACITOR 6.3V 33U	1	
C7524	ECUM1H1042FN	C.CAPACITOR CH 50V 0.1U	1	
C7525	ECUM1H1032FN	C.CAPACITOR CH 50V 0.01U	1	
C7526, 27	ECUM1H1042FN	C.CAPACITOR CH 50V 0.1U	2	
C7528, 29	ECUM1H4732FN	C.CAPACITOR CH 50V 0.047U	2	
C7531	ECUM1H1032FN	C.CAPACITOR CH 50V 0.01U	1	
C7533, 34	ECUM1H1032FN	C.CAPACITOR CH 50V 0.01U	2	
C7536	ECUM1H1042FN	C.CAPACITOR CH 50V 0.1U	1	
C7540	ECUM1H1032FN	C.CAPACITOR CH 50V 0.01U	1	
D7501-08	1SS254	DIODE	8	
D7510, 11	1SS254	DIODE	2	
D7516	1SS254	DIODE	1	
D7519, 20	1SS254	DIODE	2	
D7526	1SS254	DIODE	1	
D7528, 29	1SS254	DIODE	2	
D7531	1SS254	DIODE	1	
D7532	MA4220	DIODE	1	
D7533	MA723VT	DIODE	1	
D7541	HLMK-D215	DIODE	1	
D7542	1SS254	DIODE	1	
D7544	1SS254	DIODE	1	
D7546	1SS254	DIODE	1	
D7554, 55	1SS355	DIODE	2	
D7560	1SS355	DIODE	1	
D7564	1SS355	DIODE	1	
DP7501	VS10336	DISPLAY TUBE	1	
IC7501	M37507V8AH	IC	1	
IC7502	M6M80041P	IC	1	
IC7504	PST7023	IC	1	
IC7505	S80743AL	IC	1	
IC7506	BA6810F	IC	1	
IR7501	RPM675CBRX10	IR RECEIVER UNIT	1	
K7503	ERJ6GM20R00	M.RESISTOR CH 1/10W 0	1	

Ref.No.	Part No.	Part Name & Description	Pcs	Remarks
LB7501,02	VLP0145	COIL	2	
P7501	VJS3537B032G	CONNECTOR (FEMALE) 32P	1	
P7502	VJS3537B012G	CONNECTOR (FEMALE) 12P	1	
P7503	VJS3301	CONNECTOR (FEMALE)	1	
PP7501	VJF3405A009W	CONNECTOR (MALE) 9P	1	
QR7502	MUN2213	TRANSISTOR-RESISTOR	1	
QR7503	MUN2211	TRANSISTOR-RESISTOR	1	
QR7505-08	MUN2113	TRANSISTOR-RESISTOR	4	
QR7509-11	MUN2111	TRANSISTOR-RESISTOR	3	
QR7512,13	MUN2112	TRANSISTOR-RESISTOR	2	
R7501-03	ERJ6GMXJ221	M.RESISTOR CH 1/10W 220	3	
R7504	ERJ6GMXJ103	M.RESISTOR CH 1/10W 10K	1	
R7505	ERJ6GMXJ222	M.RESISTOR CH 1/10W 2.2K	1	
R7506-11	ERJ6GMXJ332	M.RESISTOR CH 1/10W 3.3K	6	
R7513	ERJ6GMXJ132	M.RESISTOR CH 1/10W 1.3K	1	
R7514	ERJ6GMXJ221	M.RESISTOR CH 1/10W 220	1	
R7515	ERDS2TJ470	C.RESISTOR 1/4W 47	1	
R7516	ERJ6GMXJ332	M.RESISTOR CH 1/10W 3.3K	1	
R7518	ERJ6GMXJ221	M.RESISTOR CH 1/10W 220	1	
R7519	ERJ6GMXJ102	M.RESISTOR CH 1/10W 1K	1	
R7520, 21	ERJ6GMXJ221	M.RESISTOR CH 1/10W 220	2	
R7527	ERJ6GMXJ223	M.RESISTOR CH 1/10W 22K	1	
R7528	ERJ6GMXJ102	M.RESISTOR CH 1/10W 1K	1	
R7529, 30	ERJ6GMXJ473	M.RESISTOR CH 1/10W 47K	2	
R7531	ERJ6GMXJ103	M.RESISTOR CH 1/10W 10K	1	
R7532	ERJ6GMXJ272	M.RESISTOR CH 1/10W 2.7K	1	
R7535	ERJ6GMXJ132	M.RESISTOR CH 1/10W 1.3K	1	
R7537, 38	ERJ6GMXJ221	M.RESISTOR CH 1/10W 220	2	
R7539	ERJ6GMXJ101	M.RESISTOR CH 1/10W 100	1	
R7540	ERJ6GMXJ331	M.RESISTOR CH 1/10W 330	1	
R7541	ERJ6GMXJ221	M.RESISTOR CH 1/10W 220	1	
R7542	ERJ6GMXJ224	M.RESISTOR CH 1/10W 220K	1	
R7545	ERJ6GMXJ103	M.RESISTOR CH 1/10W 10K	1	
R7546	ERJ6GMXJ181	M.RESISTOR CH 1/10W 180	1	
R7547	ERJ6GM20R00	M.RESISTOR CH 1/10W 0	1	
R7548-50	ERJ6GMXJ103	M.RESISTOR CH 1/10W 10K	3	
R7552	ERJ6GMXJ103	M.RESISTOR CH 1/10W 10K	1	
R7555, 56	ERJ6GMXJ223	M.RESISTOR CH 1/10W 22K	2	
R7558	ERJ6GMXJ221	M.RESISTOR CH 1/10W 220	1	
RX7501,02	EXBF6E104J	RESISTOR-RESISTOR	2	
RX7503	EXBF8E104J	COMBI. R-R	100K	1
S7501-09	EVQ11409K	SWITCH	9	
S7510	VSQ0822	SWITCH	1	
S7512, 13	EVQ11409K	SWITCH	2	
S7518	ESD170206	SWITCH	1	
VC7501	ECRHA010A54R	V.CAPACITOR	1	
VR4004	EVANCYAA03B53	V.RESISTOR	5K	1
X7501	VSX0608	CRYSTAL OSCILLATOR	1	
X7502	VSX0094	CRYSTAL OSCILLATOR	1	
	VJF1139	FIP HOLDER	1	
	VMD1047	LED HOLDER	1	
	VMD2035	JOG SHUTTLE HOLDER	1	
	VMD2247	IR RECEIVER HOLDER	1	

I N T E R N A L R E F E R E N C E C O D E S

NOTE: This chart is only for internal reference.

Do not order any parts according to these codes.

P. C. B.	F I L M C O D E
MAIN SYUGO	HOA002-0317A
LUMINANNCE & CHROMINANCE	HOA000-03D27
SQ PB	HOA000-03A03
HIFI AUDIO	HOA000-04447
INPUT/OUTPUT	HOA000-03B27
TIMER SYUGO	HOA001-0318A
TV DEMODULATOR	HOA000-07801
DECODER(A)	HOA000-07784
NICAM DECODER(EA)	HOA000-07787
MOTOR DRIVE	HOA001-04469
HEAD AMP	HOA000-05227
CYLINDER DRIVE	HOA000-00X69
LOADING MOTOR	HOA000-00S75

Panasonic
MATSUSHITA ELECTRIC